






* 3 : 1KD-FTV * 4 : 5L-E *48 : w/ DPF *49 : w/o DPF

































- *24 : w/ Entry & Start System
- *25 : w/o Entry & Start System
- *28 : w/ Parking Assist (TOYOTA Parking Assist-Sensor) (4 Sensor Type)
- *29 : w/o Parking Assist (TOYOTA Parking Assist-Sensor) (4 Sensor Type)
- *41 : Before Oct. 2010 Production *42 : From Oct. 2010 Production










- * 1 : 1GR-FE
- * 2 : 2TR-FE
- *15 : w/ Stowing Function
- *23 : w/ Rear Differential Lock 3-Door
- *35 : w/ Power Seat Except Lumbar Support Control Only
- *36 : w/ Power Seat Lumbar Support Control Only
- *37 : Lumbar Support Control Only
- *38 : w/o Power Seat

- *39 : w/ Seat Position Memory
- *40 : w/o Seat Position Memory
- *43 : RHD Before Oct. 2010 Production
- *44 : RHD From Oct. 2010 Production
- *45 : LHD Except *46
- *46 : LHD w/ Seat Position Memory From Oct. 2010 Production



17 Rd1


W-B

Junction Connector

W-B

No. 2 Seat Cushion Frame Sub-Assembly

LH



- *20 : 6 Speaker
- *21 : 9 Speaker
- *22 : w/ Rear Differential Lock 5-Door

- *30 : w/ Navigation System *31 : w/o Navigation System *32 : w/ Rear Seat Entertainment System
- *33 : RHD 6 Speaker w/o Multi-Media Interface ECU

