



Canonical Error Curves: default plant + controller inner_pitch_ki=0.9


level_straight lateral error




level_straight height error




level_turn lateral error



level_turn height error



level_loiter lateral error



level_loiter height error

