# Gotek Virtual Floppy Drive Instructions

The Gotek Drive is Keyed and the Floppy cable or adapter can only be installed one way.

If you are using one of my Gotek Adapters - line up the power connector and floppy connector and gently but firmly insert into the back of the Gotek Drive.

Make sure you select the correct drive letter for your Gotek before installation – the Jumper needs to be S1 for external use (DS1 / Drive B) or S0 (DS0 or Drive A) for Internal use with EX/HX machines.