

Lngineering

TurtleBot Parts


Kinect Modification Kit

Includes


- 1x Connector Housing
- 2x Female crimp pins
- Heat shrink



http://www.lHeartEngineering.com



Step 1: While making sure that the cable is not plugged in for power, cut the cable to about 14" in length.



Step 2: Remove about 1.5" of the jacket of the cable.





Step 3: Remove 0.125" of insulation from the brown and white wires.



Step 4: Attach female crimp pins to the end of both wires.






Step 5: ?Ensure that the crimps are properly formed as shown above.



Step 6: Insert the white wire into the connector with the terminal stops facing up.

Engineering Kinect Modification v0.1 Jun 29, 2011



Step 7: Insert the brown wire as shown



Step 8: A small screwdriver can be used to ensure the connections are seated.



Step 9: Heat shrink can be applied if desired.



Step 10: Completed cable is ready for testing.