






Diagram illustrating connections between COLO and RN nodes:

- Left side: COLO0 to RN1_4, COLO1 to RN1_1, COLO2 to RN0_4, COLO3 to RN0_3, COLO4 to RN0_2, COLO5 to RN0_1, COLO6 to RN1_3. A blue 'X' is placed below RN1_4.
- Right side: COLO0 to A, COLO1 to A, COLO2 to A, COLO3 to A, COLO4 to A, COLO5 to A, COLO6 to A. A blue 'X' is placed below A.

[illegible]

Pin functionalities.

J4

HRS_FH345RJ-12S-0.5SH(50)

VBUS ← R4 10k → GND

ACCES_1 ← R8 1k → ACCES_4

ACCES_6 ← R9 1k → ACCES_7

Sheet: /
File: keyboard_right.kicad_sch

Size: A4	Date: 2023-07-18
KiCad E.D.A. 9.0.4	

Rev: 1.0
Id: 2/2

