

Configure Address Objects



For supported software information, click here.

Traffic that enters Versa Operating SystemTM (VOSTM) devices through physical network interfaces (PNICs) or virtual network interfaces (VNICs) is associated with a security zone, which applies the appropriate zone protection to ensure that only clean traffic enters the VOS device. Versa SD-Security allows you to apply various types of security policies and profiles to the traffic it enters a security zone, including policies and profiles for stateful firewalls, DDoS, and SD-WAN. All these security policies have match criteria based on source zone, destination zone, source address, destination address, geolocation, IP headers, service, and schedule. When you define a security policy, you can configure objects such as addresses, address groups, services, schedules, and logging profiles. You can reuse these objects in multiple security policies. You can add a maximum of 32,000 address objects for each tenant.


This article describes how to configure address objects that you can include in security policies and profiles. For information about defining security policies that include address objects and address group objects, see Configure Stateful Firewall article.

Configure Address Objects


An address object specifies match criteria based on source IP address, destination IP address, or a combination of both. You include address objects in a policy rule, and you can use the same address object in multiple policies and policy rules.

To configure an address object:

- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Objects & Connectors > Objects > Address in the left menu bar.



4. Click the 🖹 Add icon. In the Add Address window, enter information for the following fields.



Field	Description
Name (Required)	Enter a name for the address object. Value: Text string from 1 through 255 characters Default: None
Description	Enter a text description for the address object. Value: Text string from 1 through 255 characters Default: None
Tags	Enter a keyword or phrase that allows you to filter the address object. Value: Text string from 1 through 255 characters Default: None
Type and Address/Prefix (Required)	Select the type of IP address to match and the value to match. The name of the Address/Prefix field changes depending on the value you select in the Type field.
 IPv4 (type); IPv4 Address/Prefix (match) 	Evaluate the address match using an IP address within the IPv4 prefix specified in the IPv4 Address/ Prefix field. This is the default.
 IPv4 Wildcard Mask (type); IPv4 Wildcard Mask (match) 	Add Address Name * Description Tags Add a tag Type * IPv4 Wildcard Mask *
	(For Releases 20.2.2 and later.) Enter a wildcard

mask for an IPv4 address. The bits in the mask can be on (1) or off (0). Only the bits that are enabled in the mask are used to determine whether an IPv4 address matches. For example, if you enter the IPv4 wildcard mask 100.100.0.0/255.255.0.0, the IP address 100.100.5.6 matches and the IP address 200.100.5.6 does not match. As another example, if you enter the IPv4 wildcard mask 1.1.0.1/ 255.255.0.255, the IP address 1.1.20.1 matches, while 1.1.20.5 does not match.

You can configure overlapping wildcard addresses.

A single session can match a maximum of 16 wildcard addresses.

You can configure wildcard address objects individually or as part of address groups.

You cannot combine an address prefix (or range) match with wildcard addresses to match a source or destination address.


You can define IPv4 address wildcard masks in address object rules used for rules in the following types of policies:

- Application QoS (App QoS)—For more information, see <u>Configure CoS</u>.
- Policy-based forwarding (PBF)—For more information, see <u>Configure Policy-Based</u> <u>Forwarding</u>.
- SD-WAN—For more information, see <u>Configure</u> <u>SD-WAN Policy</u> and <u>Configure SD-WAN Traffic</u> Steering.
- Security—For more information, see <u>Configure</u> <u>NGFW</u>.

You cannot use IPv4 address wildcard masks for rules in the following types of policies:

- CGNAT—For more information, see <u>Configure</u> <u>CGNAT</u>.
- HTTP/HTTPS proxy—For more information, see <u>Configure HTTP/HTTPS Proxy</u>.

	 IP filtering—For more information, see <u>Configure IP Filtering</u>. QoS—For more information, see <u>Configure CoS</u>. 				
∘ IPv4 Range (type); IPv4 Range (range)	Add Address Name *				
	Description Tags				
	Add a tag				
	Type * IPv4 Range *				
ii vartaiige (raiige)	□ IPv4 Range ✓				
	Range field. Add Address				
	Name *				
	Description Tags				
	Description Tags Add a tag				
 IPv6 Address/Prefix (type); IPv6 Address/Prefix (range) 	Type * IPv6 Address/Prefix *				
 IPv6 Address/Prefix (type); IPv6 Address/Prefix (range) 	Add a tag				



IPv6 Wildcard Mask (type);
 IPv6 Wildcard Mask (match)

mask for an IPv6 address. The bits in the mask can be on (1) or off (0). Only the bits that are enabled in the mask are used to determine whether an IPv6 address matches. For example, if you enter the IPv6 wildcard mask 2002:E000::/20, the first 20 bits must be an exact match, and the IPv6 address must start with 2002:E.

You can configure overlapping wildcard addresses.

A single session can match a maximum of 16 wildcard addresses.


You can configure wildcard address objects individually or as part of address groups.

You cannot combine an address prefix (or range) match with wildcard addresses to match a source or destination address.

You can define IPv6 address wildcard masks in address object rules used for rules in the following types of policies:

- Application QoS (App QoS)—For more information, see <u>Configure CoS</u>.
- Policy-based forwarding (PBF)—For more information, see <u>Configure Policy-Based</u> <u>Forwarding</u>.
- SD-WAN—For more information, see <u>Configure</u>

SD-WAN Policy and Configure SD-WAN Traffic Steering. Security—For more information, see <u>Configure</u> NGFW. You cannot use IPv6 address wildcard masks for rules in the following types of policies: • CGNAT—For more information, see Configure CGNAT. • HTTP/HTTPS proxy—For more information, see Configure HTTP/HTTPS Proxy. • IP filtering—For more information, see Configure IP Filtering. QoS—For more information, see <u>Configure CoS</u>. Add Address Name * Description Tags Add a tag FQDN * Type * FQDN FQDN (type); FQDN (match) Evaluate the address match using an IP address returned in a DNS query that resolves the fully qualified domain name (FQDN) into an IP address. The FQDN cannot contain any wildcard characters. Ensure that you also configure a routing instance through which the DNS server is reachable so that the VOS device can resolve the FQDN. For more information, see Configure DNS Servers.



dynamic address object without updating the

command.

configuration, issue the **request orgs org-services** tenant name **objects dynamic-address add name** tenant name **address** private-internet-IP address CLI

5. Click OK.


View References to and Edit Address Objects

For Releases 22.1.3 and later.


For address objects that you have created, you can display the templates and devices that reference them. If the address object is referenced by a common template, also called a datastore template, different service templates for the same tenant can refer to the same address objects. When the address objects are displayed, you can edit them.

To view and edit the references to an address object:

- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Objects & Connectors > Objects > Address in the left menu bar.
- 4. Click the vertical ellipsis to view the references to the address object.



5. In the Address horizontal bar, click an item in the Instance Occurrence column to display where the address objects are referred.



6. Click Edit icon to edit the address object.


Delete Address Object References

For Releases 22.1.3 and later.


You can delete an object reference, which allows you to delete it from a template or device.

To delete an address object reference:


- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Objects & Connectors > Objects > Address.
- 4. Select the device, and then click the Delete icon.



5. In the Confirm Delete popup window, click Yes.



6. If an address object is referenced in a template or device, a popup window displays.



- 7. To view the address object references, click View Reference.
- 8. Click Delete Anyway to delete the address object reference.

Upload Address Files

You can upload address files to block (deny list) or allow (accept list) an IP address or a group of IP addresses. You can then associate an address file with an address group and apply the address group to a security access policy. Depending on the policy, the addresses are allowed or blocked.

The address file must be a text file saved in CSV format.

Each entry must include the following:

- · Name—Name of the address file to associate with the IP address or IP address group
- Type—IPv4-prefix, IPv4-range, IPv6-prefix, or IPv6-range
- · Value—IP address, subnet mask, or range

For example:

```
address_list1,ipv4-prefix,167.114.0.0/16
address_list2,ipv4-range,223.252.16.1-223.252.16.10
address_list3,ipv4-prefix,223.252.11.0/24
address_list4,ipv6-prefix,2a03:2880:2040:7f21:face:b00c:0:25de/128
address_list5,ipv6-prefix,2a03:2880:2040:7f21:face:b00c::/96
```

If you create a Microsoft Excel file and save it as a .csv file, you must enter the Name, Type, and Value data in separate


columns without commas after each entry. For example:

Row	Name	Туре	Value		
1	address_list1	ipv4-prefix	167.114.0.0/16		
2	address_list2	ipv4-range	223.252.16.1–223.252.16.10		
3	address_list3	ipv4-prefix	223.252.11.0/24		
4	address_list4	ipv6-prefix	223.252.11.0/24		
5	address_list5	ipv6-prefix	2a03:2880:2040:7f21:face:b00c:0:25de/128		
6	address_list6	ipv6-prefix	2880:2040:7f21:face:b00c::/96		


Note that if you upload a file that has the same name as an existing file, it replaces the existing file and overwrites all the addresses in the file.

To upload an address file:


- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Objects & Connectors > Objects > Custom Objects > Address Files in the left menu bar. The main pane displays a table of uploaded address files, and the Director tab in the horizontal menu is selected.



4. Click the Upload icon. The Upload Address Files to Director popup window displays.



- 5. Click Browse, select an address file, and then click OK. The main pane displays the address file that has been uploaded to the Director node.
- 6. Select the Appliance tab.
- 7. Click the Upload icon. The Upload Address Files to Appliance popup window displays.




- 8. In The Filename field, select an address file. This drop-down list displays the files that you upload from the Director tab.
- 9. Click OK.

Configure Address Group Objects


You can group website addresses, address objects, and other address groups to form address groups. Grouping addresses allows you to collectively apply the same security policies and rules to multiple addresses that require the same security handling instead of having to apply security policies to addresses individually. There is not limit to the address objects that you can add in an address group.

To configure address group objects:

- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Objects & Connectors > Objects > Address Groups. The main pane displays the configured address group objects.




4. Click the + Add icon. The Add Address Group window displays. If you select Static as the value for Type, the following screen displays. Enter information for the following fields.





Field	Description			
Name (Required)	Enter a name for the address group object. Value: Text string from 1 through 255 characters Default: None			
Description	Enter a text description for the address group object. Value: Text string from 1 through 255 characters Default: None			
Tags	Enter a keyword or phrase that allows you to filter the address object. Value: Text string from 1 through 255 characters Default: None			
Туре	(For Releases 22.1.1 and later.) Select the address type for the group: • Static (default) • Dynamic If you select Static, the following fields display in the lower part of the screen:			



Add Address	- Crouns			
Add Address	s Groups			
Name *				
Description		Tags		Туре
		Add Tag		D
Match Term	ns (OR)			
	Name		Tags (AND)	Act
			No Record Added	
				Ol
(For Relea	ses 22 1 1 and	later) Cli	ck + Add in the	
•		,		
1110710011	iatori romio (or	() 0010011	diopiayo.	
Add Matab	Torms (OD)			
Add Match	iei ilis (OK)			
Name *				
Match-Term-	-1			
Tags (AND)				
Add Tag				
				OI
The te by the you ca name Tags (is ena displa associ the ne displa	erm Match Term serial number of an edit. For exar display sas Mat (AND)—If cloud bled for the CMs ys the tags for the iated with CMS exessary tag. If coyed, you can en	displays of the ma mple, the tch-Term- workload S connect he cloud connecto cloud reso ter custo	by default followed tch term, which first match term 1. I protection (CWP) tor, this field service provider or. You can select purce tags are not m tags. For more	
	Description Match Term Match Term The Add M Add Match-Term Tags (AND) Add Tag Match-Term Tags (AND) Add Tag Tags (AND) Tags (AND) The te by the you can ame Tags (and the term of the ter	Match Terms (OR) (For Releases 22.1.1 and Match Terms (OR) section The Add Match Terms (OR) Add Match Terms (OR) Match Term-1 Tags (AND) Add Tag Match Term Match Term by the serial number of you can edit. For examiname display sas Match Terms (OR) Tags (AND)—If cloud is enabled for the CM displays the tags for the associated with CMS the necessary tag. If of displayed, you can ended to the control of	Description Tags Add Tag Match Terms (OR) Name Add Match Terms (OR) section to add in The Add Match Terms (OR) screen Add Match Terms (OR) Name Match Term (OR) Name Name Name Name Name Name Name Name Name Natch Term displays by the serial number of the maryou can edit. For example, the name display sas Match-Term- Tags (AND)—If cloud workload is enabled for the CMS connected is enabled for the CMS connected displays the tags for the cloud associated with CMS connected the necessary tag. If cloud rescent displayed, you can enter custo	Description Tags Add Tag Match Terms (OR) Name Tags (AND) No Record Added (For Releases 22.1.1 and later.) Click + Add in the Match Terms (OR) section to add matching terms. The Add Match Terms (OR) screen displays. Add Match Terms (OR) Name * Match Term-1 Tags (AND) Add Tag Match Term—Enter a name for the match term. The term Match Term displays by default followed by the serial number of the match term, which you can edit. For example, the first match term name display sas Match-Term-1.


5. Click OK.

Apply an Address Object to an Access Policy


You apply an address object, address or address group, to a security access policy. To define and configure a security access policy, see Configure Security Access Policy Rules in the Configure Stateful Firewall article.

To apply an address object to an access policy:


- 1. In Director view:
 - a. Select the Administration tab in the top menu bar.
 - b. Select Appliances in the left menu bar.
 - c. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Configuration tab in the top menu bar.
- 3. Select Services > Next Gen Firewall > Security > Policies in the left menu bar.
- 4. Click the Rules tab and select a security access policy rule.




5. In the Edit Rule popup window, click Source tab.




- 6. Click + in the Source Address section to select address objects or address groups objects to associate with the rule. For more information, see Configure Address Objects and Configure Address Group Objects, above.
- 7. To add an address object click + New Address. The Add Address screen displays. For more information, see Configure Address Objects, above.
- 8. To add an address group object click + New Address Group. The Add Address Groups screen displays. For more information, see Configure Address Group Objects, above.
- 9. Click the eye icon to edit the object address. The Edit Address screen displays. For more information, see Configure Address Objects, above.



- 7. Click OK.
- 8. Click the Destination tab.



- 9. Click + in the Destination Address section to select address objects or address groups objects to associate with the rule. For more information, see <u>Configure Address Objects</u> and <u>Configure Address Group Objects</u>, above.
- 10. To add an address object click + New Address. The Add Address screen displays. For more information, see Configure Address Objects, above.
- 11. To add an address group object click + New Address Group. The Add Address Groups screen displays. For more information, see <u>Configure Address Group Objects</u>, above.
- 12. Click the eye icon to edit the object address. The Edit Address screen displays. For more information, see Configure Address Objects, above.




13. Click OK.

Monitor Policies

You monitor policies that you associate with address objects to view the traffic flow details when a policy is used. For more information, see Monitor Device Services.

To monitor policies:

- 1. Select the Administration tab in the top menu bar.
 - a. Select Appliances in the left menu bar.
 - b. Select a device name in the main panel. The view changes to Appliance view.
- 2. Select the Monitor tab in the top menu bar.
- 3. Select the Provider Organization > Services tab.
- 4. Select NGFW > Policies. The NGFW policy statistics displays.



Click a rule name to view its configuration.

Supported Software Information

Releases 20.2 and later support all content described in this article, except:

- Release 22.1.1 adds support for adding match terms and cloud workload protection tags for dynamic address groups.
- Release 22.1.2 adds support for specifying a wildcard mask in IPv6 addresses.
- Release 22.1.3 adds support for viewing, editing, and deleting address object references.

Additional Information

Configure CGNAT
Configure CoS
Configure DNS Servers

Configure HTTP/HTTPS Proxy

Configure IP Filtering

Configure NGFW

Configure Policy-Based Forwarding

Configure SD-WAN Policy

Configure SD-WAN Traffic Steering

Configure Stateful Firewall

Monitor Device Service

Overview of Configuration Templates