


View the Branch Device Configuration




For supported software information, click here.

To view the devices configured for a branch or, for multitenancy, branches:


- 1. In the Director view, select the Administration tab in the top menu bar.
- 2. Select Appliances in the left menu bar. For Releases 22.1.1 and later, the following window displays.




3. Hover over the Versa Operating SystemTM (VOSTM) device name to display basic configuration information about the device.



For Releases 21.2.3 and earlier, the following window displays.



4. Click the button to display basic configuration information about the Versa Operating SystemTM (VOSTM) devices in Card view.



Supported Software Information

Releases 20.2 and later support all content described in this article.

Additional Information

Factory Default Settings for Branch Devices