A2.2 Write address channel signals

Table A2-2 shows the AXI write address channel signals. Unless the description indicates otherwise, a signal is used by AXI3 and AXI4.

Table A2-2 Write address channel signals

Signal	Source	Description
AWID	Master	Write address ID. This signal is the identification tag for the write address group of signals. See *Transaction ID* on page A5-77.
AWADDR	Master	Write address. The write address gives the address of the first transfer in a write burst transaction. See *Address structure* on page A3-44.
AWLEN	Master	Burst length. The burst length gives the exact number of transfers in a burst. This information determines the number of data transfers associated with the address. This changes between AXI3 and AXI4. See *Burst length* on page A3-44.
AWSIZE	Master	Burst size. This signal indicates the size of each transfer in the burst. See *Burst size* on page A3-45.
AWBURST	Master	Burst type. The burst type and the size information, determine how the address for each transfer within the burst is calculated. See *Burst type* on page A3-45.
AWLOCK	Master	Lock type. Provides additional information about the atomic characteristics of the transfer. This changes between AXI3 and AXI4. See *Locked accesses* on page A7-95.
AWCACHE	Master	Memory type. This signal indicates how transactions are required to progress through a system. See *Memory types* on page A4-65.
AWPROT	Master	Protection type. This signal indicates the privilege and security level of the transaction, and whether the transaction is a data access or an instruction access. See *Access permissions* on page A4-71.
AWQOS	Master	*Quality of Service*, QoS. The QoS identifier sent for each write transaction. Implemented only in AXI4. See *QoS signaling* on page A8-98.
AWREGION	Master	Region identifier. Permits a single physical interface on a slave to be used for multiple logical interfaces. Implemented only in AXI4. See *Multiple region signaling* on page A8-99.
AWUSER	Master	User signal. Optional User-defined signal in the write address channel. Supported only in AXI4. See *User-defined signaling* on page A8-100.
AWVALID	Master	Write address valid. This signal indicates that the channel is signaling valid write address and control information. See *Channel handshake signals* on page A3-38.
AWREADY	Slave	Write address ready. This signal indicates that the slave is ready to accept an address and associated control signals. See *Channel handshake signals* on page A3-38.

Copyright © 2003, 2004, 2010, 2011 ARM. All rights reserved.
Non-Confidential