C11.1 About ACE-Lite

The ACE-Lite interface is a defined subset of the full ACE interface. ACE-Lite is used by master components that do not have hardware coherent caches, but are required to:

- indicate if issued transactions could be held in the hardware coherent caches of other masters
- issue barrier transactions
- issue broadcast cache maintenance operations.

ACE-Lite consists of an AXI4 interface with additional signals on the read address channel and write address channel. See *Read address channel (AR) signals* on page C2-152 and *Write address channel (AW) signals* on page C2-152 for more information.

ACE-Lite does not include:

- a snoop address channel
- a snoop response channel
- a snoop data channel
- a read acknowledge signal
- a write acknowledge signal
- any additional read response bits.

Copyright © 2003, 2004, 2010, 2011 ARM. All rights reserved.
Non-Confidential