C6.1 About the interconnect requirements

It is the responsibility of the interconnect to:

- receive transactions from an initiating master
- determine the order of transactions when multiple transactions are received at the same time 仲裁
- issue snoop transactions, as required, for each transaction from an initiating master 发送嗅探请求
- receive snoop responses and data, when data is provided, from a snooped master 接收嗅探信息包括响应和数据
- generate the response for the initiating master 响应master设备发送的请求
- carry out any required access to main memory. 需要的时候负责访问main memory

Copyright © 2003, 2004, 2010, 2011 ARM. All rights reserved.
Non-Confidential