

Shell & Tube Heat Exchanger

Thermal Fluids and Energy
Systems Lab

(ME EN 4650)

Prof. M Metzger
*Department of Mechanical Engineering
University of Utah*




2

Heat Exchanger Performance

What we want to know:

- performance vs flow rates
 - heat transfer rate, q
 - effectiveness, ϵ
 - overall heat transfer coefficient, U
- predict outlet temperatures, $T_{h,o}$ & $T_{c,o}$



What we can measure:

- flow rates (rotameter)
- temperatures @ inlets & outlets (thermocouples)
- temperature of casing
- " of ambient air




 THE UNIVERSITY OF UTAH

2

3


Double Pipe Heat Exchanger



3

4

Shell & Tube Heat Exchanger






 THE UNIVERSITY OF UTAH

4

5

Shell & Tube Heat Exchanger: One Shell Pass – Two Tube Passes


**U-tube heat exchanger****Straight-tube heat exchanger
(two pass tube-side)**

THE UNIVERSITY OF UTAH

5

6

Multiple Passes



One shell pass,
two tube passes

Two shell passes,
four tube passes

 THE UNIVERSITY OF UTAH

6

7

Other Types of Heat Exchangers



Fin and tube heat exchanger





Plate heat exchangers

THE UNIVERSITY OF UTAH

8

Experimental Apparatus

Crossflow, One Shell-Pass, One Tube-Pass




Shell Outside Diameter (in)	2.12	heat transfer surface area
Shell (and Tube) Length (in) = L	9.00	(based on tube inside diameter)
Baffle Spacing (in)	1.13	
Tube Outside Diameter (in) = D _o	0.250	$A_t = N \pi D_i L$
Tube Wall Thickness (in) = t	0.028	
Number of Tubes = N	31	$D_i = D_o - 2t = 0.194"$
Number of Tube Passes		$A_t = 170.04 \text{ in}^2 (0.1097 \text{ m}^2)$
Tube Material	copper	
Shell Material	brass	

 THE UNIVERSITY OF UTAH

8

9

Measurements




Quantity	Symbol	Units	Instrument
Temperature of hot-side	$T_{h,i}, T_{h,o}$	°F	thermocouple
Temperature of cold-side	$T_{c,i}, T_{c,o}$	°F	thermocouple
Temperature of shell casing	T_s	°F	thermocouple
Temperature of ambient air	T_∞	°F	thermocouple
Volume flow rate	\dot{V}_c, \dot{V}_h	gpm	rotameter

THE UNIVERSITY OF UTAH

9

10

Experimental Apparatus



THE UNIVERSITY OF UTAH

10

11

Figures and Tables

Table 1a

Case	Flow Rate (kg/s)		Temperature (°C)		U_i (W/K m ⁻²)	Heat Transfer Rate (kW)		
	\dot{m}_c	\dot{m}_h	ΔT_h	ΔT_c		q_c	q_h	Δq (%)
1a	(fast)	(fast)						
1b	(fast)	(slow)						
2a	(slow)							
2b	(slow)							

$$\text{Avg temp: } T_{\text{avg}} = \frac{T_i + T_o}{2}$$

$$\text{Density: } \rho_w = f(T_{\text{avg}})$$

$$\text{mass flow rate: } \dot{m} = \rho_w V$$

"WaterProperties.m"

Table 1b

Case	Flow Rate (kg/s)		C_r	NTU	ε		
	\dot{m}_c	\dot{m}_h			measured	theory	$\Delta\varepsilon$ (%)
1a	(fast)	(fast)					
1b	(fast)	(slow)					
2a	(slow)		heat capacity ratio	transfer units	effectiveness		
2b	(slow)		(slow)				

$$\text{heat capacity: } C_c = \dot{m}_c C_p c \quad \& \quad C_h = \dot{m}_h C_p h \quad @ T_{\text{avg}}$$

$$\text{heat capacity ratio: } C_r = \frac{C_{\min}}{C_{\max}} \quad \text{where} \quad C_{\min} = \min(C_c, C_h) \quad \& \quad C_{\max} = \max(C_c, C_h)$$


THE UNIVERSITY OF UTAH

11

12

Figures and Tables (cont)

Figure 1c




THE UNIVERSITY OF UTAH


12

13

Temperature Profiles



Steady Energy Equation (no changes in KE or PE, no work, no losses to surroundings)



USE g_h in theoretical calculations



$$\dot{q}_h = \dot{m}_h \Delta h_h = \dot{m}_h C_{ph} \Delta T_h$$

$$\dot{q}_h = \dot{m}_h C_{ph} (T_{h,o} - T_{h,i}) \quad [W]$$

$$\dot{q}_c = \dot{m}_c C_{pc} (T_{c,i} - T_{c,o})$$


MUST : $\dot{q}_c = \dot{q}_h \Rightarrow \Delta \dot{q} = \frac{|\dot{q}_h - \dot{q}_c|}{\frac{1}{2}(\dot{q}_h + \dot{q}_c)} \times 100\%$

THE UNIVERSITY OF UTAH

13

14

Temperature Profiles: Special Heat Exchangers





THE UNIVERSITY OF UTAH

14

15

Log Mean Temperature Difference (LMTD)



Modified Newton's Law of Cooling

$$\dot{Q} = \bar{U}_i A_i F \Delta T_{lm}$$

$$\Delta T_{lm} = \frac{\Delta T_2 - \Delta T_1}{\ln(\Delta T_2 / \Delta T_1)}$$

$$\Delta T_1 = T_{h,i} - T_{c,o} \quad \& \quad \Delta T_2 = T_{h,o} - T_{c,i}$$

Overall heat transfer coefficient

$$\bar{U}_i = \frac{\dot{Q}}{A_i F \Delta T_{lm}}$$

\bar{U}_i = overall heat transfer coefficient
 A_i = total inside tube surface area

$A_i = N\pi D_i L$
 F = correction factor ($= 1$ for counter-flow, single tube, single pass)


use \dot{Q}_h from calculation

use measurements

THE UNIVERSITY OF UTAH

16



Effectiveness



16

17

Effectiveness – NTU Method



$$\text{effectiveness: } \varepsilon = \frac{q}{(C_{\min} \Delta T_{\max})} \quad , \quad \Delta T_{\max} = T_{h,i} - T_{c,i}$$

$$\text{Theory: } \varepsilon = f(\text{NTU}, C_r) \quad \text{where} \quad C_r = \frac{C_{\min}}{C_{\max}} \quad (C_r \leq 1)$$

$$\text{Number of transfer units: } \text{NTU} = \frac{\sum_i A_i}{C_{\min}} \quad \text{use calculation from measurements}$$

Theoretical effectiveness (counterflow, single tube-pass, single shell-pass)


$$\varepsilon = \begin{cases} \frac{1 - \exp[-\text{NTU}(1 - C_r)]}{1 - C_r \exp[-\text{NTU}(1 - C_r)]} & , \quad C_r < 1 \\ \frac{\text{NTU}}{\text{NTU} + 1} & , \quad C_r = 1 \end{cases}$$

THE UNIVERSITY OF UTAH

17

18



Theoretical Effectiveness vs NTU (single tube-pass, single shell-pass, counterflow)



THE UNIVERSITY OF UTAH

19

Heat Exchanger Design: Predicting Hot-Side Outlet Temperature



$$\dot{q}_h = C_h (T_{h,i} - T_{h,o}) \quad \text{and} \quad \dot{q} = \varepsilon C_{\min} (T_{h,i} - T_{c,i})$$

Set equal:

$$\frac{C_h}{C_h} (T_{h,i} - T_{h,o}) = \varepsilon \frac{C_{\min}}{C_h} (T_{h,i} - T_{c,i})$$

Solve for $T_{h,o}$:

$$T_{h,o} = -\varepsilon \frac{C_{\min}}{C_h} (T_{h,i} - T_{c,i}) + T_{h,i}$$

$$T_{h,o} = T_{h,i} \left(1 - \varepsilon \frac{C_{\min}}{C_h} \right) + T_{c,i} \left(\varepsilon \frac{C_{\min}}{C_h} \right)$$

theory



C_c, C_h : specified flow rates & inlet temperatures

THE UNIVERSITY OF UTAH

19

20

Heat Lost to Surroundings: Natural Convection from Shell Casing



$$\dot{Q}_{\text{conv}} = \bar{h} (T_s - T_\infty) \pi D_s L$$

Empirical Nusselt Number Relationship

$$\bar{N}_{u_D} = f(R_{a_D}, \Pr), \quad R_{a_D} = \frac{g \beta (T_s - T_\infty) D_s^3}{\nu \alpha}, \quad \Pr = \frac{\nu}{\alpha}, \quad \alpha = \frac{k}{\rho c_p}$$

for ideal gases, $\beta = \frac{1}{T_{\text{film}}}$


$$\bar{N}_{u_D} = \left[0.6 + \frac{0.387 R_{a_D}^{1/6}}{\left[1 + (0.559/\Pr)^{9/16} \right]^{8/27}} \right]^2, \text{ for } R_{a_D} < 10^{12}$$

THE UNIVERSITY OF UTAH

20

21

Heat Lost to Surroundings: Thermal Radiation



$$q_{\text{rad}} = \epsilon \sigma (T_s^4 - T_\infty^4) \pi D_s L$$

are in Kelvin!

$\epsilon \approx 0.95$ (guess)

$5.6703 \times 10^{-8} \text{ W/m}^2 \text{K}^4$ heat transfer surface area

THE UNIVERSITY OF UTAH

21

22

Questions??

Thank you for your attention!

Let me or the TAs know if you have questions



22