	Α	В	С	D	Е	F F	G
	BY8301-16P	MP3-FLASH-16P	-	_	Send command [Without	·	-
1	command	command	Function	Send command [With checksum]	calibration]	Notes	Parameters
2	0x03	0x01	[The next song]	7E FF 06 01 00 00 00 FE FA EF	7E FF 06 01 00 00 00 EF		
3	0x04	0x02	[Previous track]	7E FF 06 02 00 00 00 FE F9 EF	7E FF 06 02 00 00 00 EF		
4		0x03	[The specified track num]	7E FF 06 03 00 00 01 FE F7 EF	7E FF 06 03 00 00 01 EF	Specifies track 1	1-255
5				7E FF 06 03 00 00 02 FE F6 EF	7E FF 06 03 00 00 02 EF	Specifies track 2	1-255
6				7E FF 06 03 00 00 0A FE EE EF	7E FF 06 03 00 00 0A EF	Specifies track 10 (number in Hex)	1-255
7	0x05	0x04	Volume+				
8	0x06	0x05	Volume-				
9	0x31	0x06	[Specifies the volume]	7E FF 06 06 00 00 1E FE D7 EF	7E FF 06 06 00 00 1E EF	Specifies that the volume is 30	0-30
10	0x32	0x07	[The specified EQ]	7E FF 06 07 00 00 01 FE F3 EF	7E FF 06 07 00 00 01 EF	Reservation	0/1/2/3/4/5
11		0x08	[Loop playlist]	7E FF 06 08 00 00 01 FE F2 EF	7E FF 06 08 00 00 01 EF	Loop Playlist 1	1-255
12				7E FF 06 08 00 00 02 FE F1 EF	7E FF 06 08 00 00 02 EF	Loops Playlist 2	1-255
13				7E FF 06 08 00 00 0A FE E9 EF	7E FF 06 08 00 00 0A EF	Loops Playlist 10	1-255
14		0x09	[Specifies the playback device]	7E FF 06 09 00 00 01 FE F1 EF	7E FF 06 09 00 00 01 EF	Specifies the playback FLASH	FLASH
15	0x07	0x0A	[Enter sleep mode]	7E FF 06 0A 00 00 00 FE F1 EF	7E FF 06 0A 00 00 00 EF	Go to sleep Low power consumption	Power remained at 10MA
16		0x0B	[Wake up sleeping]	7E FF 06 0B 00 00 00 FE F0 EF	7E FF 06 0B 00 00 00 EF		
17	0x09	0x0C	[Module reset]	7E FF 06 0C 00 00 00 FE EF EF	7E FF 06 0C 00 00 00 EF		
18	0x01	0x0D	[Play]	7E FF 06 0D 00 00 00 FE EE EF	7E FF 06 0D 00 00 00 EF		
19	0x02	0x0E	[Pause]	7E FF 06 0E 00 00 00 FE ED EF	7E FF 06 0E 00 00 00 EF		
20	0x0E	0x16	To stop playback	7E FF 06 16 00 00 00 FE E5 EF	7E FF 06 16 00 00 00 EF	Stop software decoding	
21		0x21	Combination play	7E FF 09 21 00 05 01 02 03 04	7E FF 09 21 00 05 01 02 03	Combination play 5、1、2、3、4	
22		0.04		FE C8 EF	04 EF		
24		0x21	Combination play	7E FF 0C 21 00 05 01 02 03 04	7E FF 0C 21 00 05 01 02 03	Combination play 5、1、2、3、4、	
25		0.22	Die 11 de de de	06 07 08 FE B0 EF	04 06 07 08 EF	6, 7, 8	
26		0x22	Play with volume	7E FF 06 22 00 1E 01 FE BA EF 7E FF 06 22 00 0F 01 FE C9 EF	7E FF 06 22 00 1E 01 EF 7E FF 06 22 00 0F 01 EF	30 Level volume play1 15 Level volume play1	
27				7E FF 06 22 00 0F 01 FE C9 EF	7E FF 06 22 00 0F 01 EF	15 Level volume play2	
28	0v42	0x30	Play it a specified folder tracks	7E FF 06 22 00 0F 02 FE C8 EF	7E FF 06 30 00 01 01 EF	FOLDER1 Subsection1	
29	0.42	0,30	Flay it a specified folder tracks	7E FF 06 30 00 01 01 FE C8 EF	7E FF 06 30 00 02 01 EF	FOLDER2 Subsection1	
30				7E FF 06 30 00 02 01 FE C7 EF	7E FF 06 30 00 02 01 EF	FOLDER3 Subsection1	
31				7E FF 06 30 00 03 03 FE C5 EF	7E FF 06 30 00 03 03 EF	FOLDER3 Subsection3	
32				7211 00 30 00 03 03 12 03 21	7211 00 30 00 03 03 21	TOEDERS SUBSCERIONS	
33		0x31	Specifies the folder tracks cycle sowing	7E FF 06 31 00 03 03 FE C4 EF	7E FF 06 31 00 03 03 EF	FOLDER3 3 Music looping	
34		UNU I	becomes and related at delite of the serving	7E FF 06 31 00 01 03 FE C6 EF	7E FF 06 31 00 01 03 EF	FOLDER1 Subsection3 Song cycle sowing	
35		0x32	Specify a folder loop	7E FF 06 32 00 03 01 FE C5 EF	7E FF 06 32 00 03 01 EF	FOLDER3 Subsection3 Song cycle 30Ming	
36		0x33	7				
37		0x3C	STAY				
38		0x3D	STAY				
39		0x3E	STAY				
40		0x3F	Send initialization parameters				0x1F (5 Each bit represents a folder)
41		0x40	Returns an error, request to resend				
42		0x41	Answer				
	0x 10	0x42	Query the current state	7E FF 06 42 00 00 00 FE B9 EF	7E FF 06 42 00 00 00 EF	Query the playback status	0 (Stop it) 1 (Play) 2 (Pause) 3 (F. f) 4 (Rewind)
44		0x43	[Query volume]	7E FF 06 43 00 00 00 FE B8 EF	7E FF 06 43 00 00 00 EF		
	0x 12	0x44	[Query the currentEQ]	7E FF 06 44 00 00 00 FE B7 EF	7E FF 06 44 00 00 00 EF		0-5(NO\POP\ROCK\JAZZ\CLASSIC\BASS(Power failure memory)
46	0x 13	0x45	Queries the current playback mode				0-4 (All/Folder/Singles play/Random/Play again)
47	0x 14	0x46	Query the current software version				
48		0x47	The current play mode	7E FF 06 47 00 00 00 FE B4 EF	7E FF 06 47 00 00 00 EF		
49	0x 17	0x49	FLASHTotal number of files	7E FF 06 49 00 00 00 FE B2 EF	7E FF 06 49 00 00 00 EF		
50		0x4D	FLASHCurrent folder track pointers	7E FF 06 4D 00 00 00 FE AE EF	7E FF 06 4D 00 00 00 EF		
51		0x60	Currently online folder	7E FF 06 60 00 00 00 FE 9B EF	7E FF 06 60 00 00 00 EF	Query online folder	
52		0x61	Pointer to current folder	7E FF 06 61 00 00 00 FE 9A EF	7E FF 06 61 00 00 00 EF	Queries the current playback folder	
53		0x62	Check the specified total number of folder tracks	7E FF 06 62 00 00 01 FE 98 EF	7E FF 06 62 00 00 01 EF	QueryFOLDER1Total files	