µOS++ III SMP

Test commands, one by one

µOS++ III SMP — test commands, one by one

Every QEMU, hardware and host test of the AArch32, AArch64, Cortex-M33, RP2350, STM32F4 and POSIX platforms, written as the explicit commands that the runners execute — `test_smpl/run-qemu.sh`, `test_smpl/run-hw.sh` and `test_smpl/run-host.sh`, each board's `hw.sh`, and the `add_test()` commands of the kernel platforms — without the scripts.

Platform	Port	QEMU tests	Hardware tests	Host tests	Section
`aarch32-rpi-zero-2w`	`micro-os-plus-iii-aarch32`	15	15	—	3.3, 4.3
`aarch32-rpi3b`	`micro-os-plus-iii-aarch32`	15	14	—	3.4, 4.4
`aarch64-rpi-zero-2w`	`micro-os-plus-iii-aarch64`	15	15	—	3.5, 4.5
`aarch64-rpi3b`	`micro-os-plus-iii-aarch64`	15	14	—	3.6, 4.6
`aarch32-luckfox-lyra`	`micro-os-plus-iii-aarch32`	—	20	—	4.7
`2xcortex-m33`	`micro-os-plus-iii-cortexm`	4	—	—	5.2
`pico2-1cpu`	`micro-os-plus-iii-cortexm`	4	—	—	5.3
`cortexm-pico2`	`micro-os-plus-iii-cortexm`	6	20	—	5.4, 6.3, 6.4
`cortexm-pico2-rp2350b-psram`	`micro-os-plus-iii-cortexm`	3	15	—	5.5, 6.5
`cortexm-pico2-pizero`	`micro-os-plus-iii-cortexm`	—	14	—	6.6
`cortexm-nucleof411`	`micro-os-plus-iii-cortexm`	—	4	—	7.2
`cortexm-weactf411`	`micro-os-plus-iii-cortexm`	—	5	—	7.3
`cortexm-weactf412`	`micro-os-plus-iii-cortexm`	—	5	—	7.4
`native` (`native-cmake-sys`)	`micro-os-plus-iii-posix-arch`	—	—	16	8

The image names and the test lists were read on 2026-10-09 from the **debug** builds (`*-cmake-gcc-debug`, `native-cmake-sys-debug`) made from:

Repository	Branch	Commit
`micro-os-plus-iii`	`smp`	`d780c76c`
`micro-os-plus-iii-aarch32`	`smp`	`e721dea`
`micro-os-plus-iii-aarch64`	`smp`	`8151c26`
`micro-os-plus-iii-cortexm`	`smp`	`71e98ff`
`micro-os-plus-iii-posix-arch`	`smp`	`4ed05ad`

1. Paths and tools

```
WORK=/tmp
K=$WORK/micro-os-plus-iii                # kernel
A32=$WORK/micro-os-plus-iii-aarch32      # AArch32 port
A64=$WORK/micro-os-plus-iii-aarch64      # AArch64 port
C=$WORK/micro-os-plus-iii-cortexm        # Cortex-M port
P=$WORK/micro-os-plus-iii-posix-arch     # POSIX port
BUILD=$K/tests/build

QEMU=$HOME/.local/xPacks/@xpack-dev-tools/qemu-arm/9.2.4-1.1/.content/bin/qemu-system-aarch64
QEMUARM=$HOME/.local/xPacks/@xpack-dev-tools/qemu-arm/9.2.4-1.1/.content/bin/qemu-system-arm
OPENOCD=$HOME/.local/xPacks/@xpack-dev-tools/openocd/0.12.0-7.1/.content/bin/openocd
SCRIPTS=$HOME/.local/xPacks/@xpack-dev-tools/openocd/0.12.0-7.1/.content/openocd/scripts
TC32=$HOME/.local/xPacks/@xpack-dev-tools/arm-none-eabi-gcc/15.2.1-1.1.1/.content/bin
TC64=$HOME/.local/xPacks/@xpack-dev-tools/aarch64-none-elf-gcc/15.2.1-1.1.1/.content/bin
```

These are the versions the scripts pick on this machine: the newest `qemu-arm` and `openocd` xPacks installed, and the 15.x toolchains.

2. Install and build

```
cd $A32 && xpm install && xpm link
cd $A64 && xpm install && xpm link
cd $C   && xpm install && xpm link
cd $P   && xpm install && xpm link

cd $K/tests
for c in aarch32-rpi-zero-2w aarch32-rpi3b aarch64-rpi-zero-2w aarch64-rpi3b aarch32-luckfox-lyra \
         2xcortex-m33 pico2-1cpu cortexm-pico2 cortexm-pico2-rp2350b-psram cortexm-pico2-pizero \
         cortexm-nucleof411 cortexm-weactf411 cortexm-weactf412; do
  xpm install     --config $c-cmake-gcc-debug
  xpm run prepare --config $c-cmake-gcc-debug
  xpm run build   --config $c-cmake-gcc-debug
done
xpm install     --config native-cmake-sys-debug
xpm run prepare --config native-cmake-sys-debug
xpm run build   --config native-cmake-sys-debug
```

(Replace `-debug` by `-release` for the release images.) The AArch32 and AArch64 images are in `$BUILD/<platform>-cmake-gcc-debug/platform-bin/port-tests/test/`:

File	Used by
`<test>-qemu.bin`	QEMU (raw image)
`shim8.img`	QEMU, AArch32 only (the AArch64-to-AArch32 boot shim)
`<test>-hwd`	hardware (the ELF; a link to `<test>-hwd.elf`)

3. QEMU

3.1 The command

AArch32 — QEMU's `raspi3b` starts its cores in AArch64, so it boots `shim8.img`, which drops to AArch32 and jumps to the test image loaded at `0x10000`:

```
timeout <seconds> $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  [-drive file=<card image>,if=sd,format=raw] \
  -kernel $D/shim8.img -device loader,file=$D/<test>-qemu.bin,addr=0x10000 \
  < /dev/null
```

AArch64 — the test image is the kernel:

```
timeout <seconds> $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  [-drive file=<card image>,if=sd,format=raw] \
  -kernel $D/<test>-qemu.bin \
  < /dev/null
```

The test passed when its output has a line `RESULT: PASS`. `RESULT: SKIP` is a skip (`usb_test`: QEMU has no USB device mode). `RESULT: FAIL`, no `RESULT` line, or exit status 124 (the `timeout` expired) is a failure.

3.2 The SD card image

Four tests need a card: a fresh image before the run, deleted after it.

```
# sd_test: a card seeded with a flatfs volume, by the test's own tool
python3 <port>/test/<board>/sd_test/flatfs_tool.py make-seed /tmp/sd_test.disk.img

# smp-mat-sdcard-test, smp-num-test, smp-pipeline-test: a blank 4 GiB sparse file
truncate -s 4G /tmp/<test>.disk.img

rm -f /tmp/<test>.disk.img      # after the run
```

Checked on 2026-10-09 with these exact commands: AArch32 and AArch64 `smp_test0` (`RESULT: PASS (10 heartbeats on core 0)`, exit 0), and AArch32 `sd_test` with a seeded card (`RESULT: PASS (SD + flatfs verified)`, exit 0).

3.3 `aarch32-rpi-zero-2w` — QEMU

```
D=$BUILD/aarch32-rpi-zero-2w-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/cmsis-os-validator-qemu.bin,addr=0x10000 \
  < /dev/null
```

`mutex-stress`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/mutex-stress-qemu.bin,addr=0x10000 \
  < /dev/null
```

`rtos-apis`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/rtos-apis-qemu.bin,addr=0x10000 \
  < /dev/null
```

`sd_test`

```
python3 $A32/test/rpi-zero-2w/sd_test/flatfs_tool.py make-seed /tmp/sd_test.disk.img
timeout 450 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/sd_test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/sd_test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/sd_test.disk.img
```

`smp-mat-sdcard-test`

```
truncate -s 4G /tmp/smp-mat-sdcard-test.disk.img
timeout 2000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-mat-sdcard-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-mat-sdcard-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-mat-sdcard-test.disk.img
```

`smp-mat-test`

```
timeout 900 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp-mat-test-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp-num-test`

```
truncate -s 4G /tmp/smp-num-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-num-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-num-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-num-test.disk.img
```

`smp-pipeline-test`

```
truncate -s 4G /tmp/smp-pipeline-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-pipeline-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-pipeline-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-pipeline-test.disk.img
```

`smp-pro-cons-test`

```
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp-pro-cons-test-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test0`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test0-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test1`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test1-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test2`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test2-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test3`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test3-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test4`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test4-qemu.bin,addr=0x10000 \
  < /dev/null
```

`usb_test`

```
timeout 200 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/usb_test-qemu.bin,addr=0x10000 \
  < /dev/null
```

3.4 `aarch32-rpi3b` — QEMU

```
D=$BUILD/aarch32-rpi3b-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/cmsis-os-validator-qemu.bin,addr=0x10000 \
  < /dev/null
```

`mutex-stress`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/mutex-stress-qemu.bin,addr=0x10000 \
  < /dev/null
```

`rtos-apis`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/rtos-apis-qemu.bin,addr=0x10000 \
  < /dev/null
```

`sd_test`

```
python3 $A32/test/rpi3b/sd_test/flatfs_tool.py make-seed /tmp/sd_test.disk.img
timeout 450 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/sd_test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/sd_test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/sd_test.disk.img
```

`smp-mat-sdcard-test`

```
truncate -s 4G /tmp/smp-mat-sdcard-test.disk.img
timeout 2000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-mat-sdcard-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-mat-sdcard-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-mat-sdcard-test.disk.img
```

`smp-mat-test`

```
timeout 900 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp-mat-test-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp-num-test`

```
truncate -s 4G /tmp/smp-num-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-num-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-num-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-num-test.disk.img
```

`smp-pipeline-test`

```
truncate -s 4G /tmp/smp-pipeline-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-pipeline-test.disk.img,if=sd,format=raw \
  -kernel $D/shim8.img -device loader,file=$D/smp-pipeline-test-qemu.bin,addr=0x10000 \
  < /dev/null
rm -f /tmp/smp-pipeline-test.disk.img
```

`smp-pro-cons-test`

```
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp-pro-cons-test-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test0`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test0-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test1`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test1-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test2`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test2-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test3`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test3-qemu.bin,addr=0x10000 \
  < /dev/null
```

`smp_test4`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/smp_test4-qemu.bin,addr=0x10000 \
  < /dev/null
```

`usb_test`

```
timeout 200 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/shim8.img -device loader,file=$D/usb_test-qemu.bin,addr=0x10000 \
  < /dev/null
```

3.5 `aarch64-rpi-zero-2w` — QEMU

```
D=$BUILD/aarch64-rpi-zero-2w-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/cmsis-os-validator-qemu.bin \
  < /dev/null
```

`mutex-stress`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/mutex-stress-qemu.bin \
  < /dev/null
```

`rtos-apis`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/rtos-apis-qemu.bin \
  < /dev/null
```

`sd_test`

```
python3 $A64/test/rpi-zero-2w/sd_test/flatfs_tool.py make-seed /tmp/sd_test.disk.img
timeout 450 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/sd_test.disk.img,if=sd,format=raw \
  -kernel $D/sd_test-qemu.bin \
  < /dev/null
rm -f /tmp/sd_test.disk.img
```

`smp-mat-sdcard-test`

```
truncate -s 4G /tmp/smp-mat-sdcard-test.disk.img
timeout 2000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-mat-sdcard-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-mat-sdcard-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-mat-sdcard-test.disk.img
```

`smp-mat-test`

```
timeout 900 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp-mat-test-qemu.bin \
  < /dev/null
```

`smp-num-test`

```
truncate -s 4G /tmp/smp-num-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-num-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-num-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-num-test.disk.img
```

`smp-pipeline-test`

```
truncate -s 4G /tmp/smp-pipeline-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-pipeline-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-pipeline-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-pipeline-test.disk.img
```

`smp-pro-cons-test`

```
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp-pro-cons-test-qemu.bin \
  < /dev/null
```

`smp_test0`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test0-qemu.bin \
  < /dev/null
```

`smp_test1`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test1-qemu.bin \
  < /dev/null
```

`smp_test2`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test2-qemu.bin \
  < /dev/null
```

`smp_test3`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test3-qemu.bin \
  < /dev/null
```

`smp_test4`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test4-qemu.bin \
  < /dev/null
```

`usb_test`

```
timeout 200 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/usb_test-qemu.bin \
  < /dev/null
```

3.6 `aarch64-rpi3b` — QEMU

```
D=$BUILD/aarch64-rpi3b-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/cmsis-os-validator-qemu.bin \
  < /dev/null
```

`mutex-stress`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/mutex-stress-qemu.bin \
  < /dev/null
```

`rtos-apis`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/rtos-apis-qemu.bin \
  < /dev/null
```

`sd_test`

```
python3 $A64/test/rpi3b/sd_test/flatfs_tool.py make-seed /tmp/sd_test.disk.img
timeout 450 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/sd_test.disk.img,if=sd,format=raw \
  -kernel $D/sd_test-qemu.bin \
  < /dev/null
rm -f /tmp/sd_test.disk.img
```

`smp-mat-sdcard-test`

```
truncate -s 4G /tmp/smp-mat-sdcard-test.disk.img
timeout 2000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-mat-sdcard-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-mat-sdcard-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-mat-sdcard-test.disk.img
```

`smp-mat-test`

```
timeout 900 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp-mat-test-qemu.bin \
  < /dev/null
```

`smp-num-test`

```
truncate -s 4G /tmp/smp-num-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-num-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-num-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-num-test.disk.img
```

`smp-pipeline-test`

```
truncate -s 4G /tmp/smp-pipeline-test.disk.img
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -drive file=/tmp/smp-pipeline-test.disk.img,if=sd,format=raw \
  -kernel $D/smp-pipeline-test-qemu.bin \
  < /dev/null
rm -f /tmp/smp-pipeline-test.disk.img
```

`smp-pro-cons-test`

```
timeout 1000 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp-pro-cons-test-qemu.bin \
  < /dev/null
```

`smp_test0`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test0-qemu.bin \
  < /dev/null
```

`smp_test1`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test1-qemu.bin \
  < /dev/null
```

`smp_test2`

```
timeout 300 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test2-qemu.bin \
  < /dev/null
```

`smp_test3`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test3-qemu.bin \
  < /dev/null
```

`smp_test4`

```
timeout 150 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/smp_test4-qemu.bin \
  < /dev/null
```

`usb_test`

```
timeout 200 $QEMU -M raspi3b -smp 4 -nographic -serial none \
  -semihosting-config enable=on,target=native \
  -kernel $D/usb_test-qemu.bin \
  < /dev/null
```

4. Hardware

4.1 What a hardware run does

One test at a time: the image is loaded into RAM over whatever was there before, and the Pi has no reset a script can drive, so each test starts with a reset through the watchdog. These commands do not use the UART console; keep your own terminal on it (for example `tio -b 115200 /dev/ttyACM0`). The test's semihosting output appears in the OpenOCD output; the test passed when it prints `RESULT: PASS`. Then stop OpenOCD (Ctrl-C).

The session file is written with a quoted here-document (so that the Tcl `$core` stays literal); the ELF path is then put in with `sed`.

Only core 0 is started at the entry. Cores 1–3 are resumed where they were halted: after the watchdog reset they wait in the firmware's own loop, and the test releases them itself (`release_one()` in `test/boards/rpi-zero-2w/src/smp.cpp`) after it has written their `__smp_spin` slot. So nothing is read from the

ELF and nothing is written to `__smp_spin`. This is what `hw.sh` does (`UOS_HW_RESUME=cpsr-first` / `pc-first`, `UOS_HW_SPIN_WORDS=0`); the previous flow, which started all four cores and zeroed `__smp_spin`, is kept in `hw.sh.bak`.

It needs an SD card whose kernel leaves cores 1–3 in the firmware's loop, booting the same width as the port, because the two ports release the cores differently:

Port	SD card `config.txt`	Cores 1–3 wait for	After the reset, cores 1–3 are at
AArch32	`arm_64bit=0`	their mailbox 3	`pc=0x7a`, Thumb, Hypervisor
AArch64	`arm_64bit=1` (e.g. `$A64/test/boards/rpi-zero-2w/hw-park/`)	their release word at `0xd8 + 8*core`	`pc=0x7c`, EL2H

Tested on a Pi Zero 2 W on 2026-10-09: every test below except `usb_test` passed this way, on both ports.

4.2 Raspberry Pi (Zero 2 W and 3 B), both ports

	AArch32	AArch64
OpenOCD config, J-Link (default)	`$A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg`	`$A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg`
OpenOCD config, Olimex ARM-USB-OCD	`$A32/test/boards/rpi-zero-2w/openocd-olimex.cfg`	`$A64/test/boards/rpi-zero-2w/openocd-olimex.cfg`
`-c init`	yes (the config is declarative)	yes (the config is declarative)
entry	`0x1003c`	`0x80000`
start core 0	set CPSR to `0x600001da`, then resume at the entry	set PC to the entry, then resume
cores 1–3	`resume` where they are	`resume` where they are

The Pi 3 B uses the Zero 2 W's configs (same BCM2837). Each test is three steps:

1. **Reset** through the watchdog (`PM_RSTC` / `PM_WDOG` at `0x3f10001c` and `0x3f100024`), then wait 12 s for the board to boot.
2. **Write the session** (`/tmp/session.tcl`): halt the four cores, enable semihosting on each, load the ELF, start core 0 at the entry, let cores 1–3 go on where they are.
3. **Run OpenOCD** with the config and the session.

The sections below write every test with the J-Link config; for the Olimex probe replace `openocd-jlink-rpi3.cfg` by `openocd-olimex.cfg`.

4.3 `aarch32-rpi-zero-2w` — hardware

```
D=$BUILD/aarch32-rpi-zero-2w-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/cmsis-os-validator-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`mutex-stress` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/mutex-stress-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`rtos-apis` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/rtos-apis-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`sd_test` (allow about 450 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/sd_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-sdcard-test` (allow about 900 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-sdcard-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-test` (allow about 900 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-num-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-num-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pipeline-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pipeline-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pro-cons-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pro-cons-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test0` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test0-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test1` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test1-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test2` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test2-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test3` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test3-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test4` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test4-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`usb_test` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/usb_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

4.4 `aarch32-rpi3b` — hardware

```
D=$BUILD/aarch32-rpi3b-cmake-gcc-debug/platform-bin/port-tests/test
```

`ctest` registers no hardware case for `usb_test` on the Pi 3 B; its image is built but not listed here.

`cmsis-os-validator` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/cmsis-os-validator-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`mutex-stress` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/mutex-stress-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`rtos-apis` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/rtos-apis-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`sd_test` (allow about 450 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/sd_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-sdcard-test` (allow about 900 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-sdcard-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-test` (allow about 900 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-num-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-num-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pipeline-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pipeline-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pro-cons-test` (allow about 600 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pro-cons-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test0` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test0-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test1` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test1-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test2` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test2-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test3` (allow about 120 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test3-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test4` (allow about 300 s)

```
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x1003c ---"
targets bcm2837.cpu0
reg cpsr 0x600001da
resume 0x1003c
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test4-hwd|g" /tmp/session.tcl
$OPENOCD -s $A32/test/boards/rpi-zero-2w -s $SCRIPTS -f $A32/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

4.5 `aarch64-rpi-zero-2w` — hardware

```
D=$BUILD/aarch64-rpi-zero-2w-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/cmsis-os-validator-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`mutex-stress` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/mutex-stress-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`rtos-apis` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/rtos-apis-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`sd_test` (allow about 450 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/sd_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-sdcard-test` (allow about 900 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-sdcard-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-test` (allow about 900 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-num-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-num-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pipeline-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pipeline-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pro-cons-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pro-cons-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test0` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test0-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test1` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test1-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test2` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test2-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test3` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test3-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test4` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test4-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`usb_test` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/usb_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

4.6 `aarch64-rpi3b` — hardware

```
D=$BUILD/aarch64-rpi3b-cmake-gcc-debug/platform-bin/port-tests/test
```

`ctest` registers no hardware case for `usb_test` on the Pi 3 B; its image is built but not listed here.

`cmsis-os-validator` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/cmsis-os-validator-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`mutex-stress` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/mutex-stress-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`rtos-apis` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/rtos-apis-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`sd_test` (allow about 450 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/sd_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-sdcard-test` (allow about 900 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-sdcard-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-mat-test` (allow about 900 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-mat-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-num-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-num-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pipeline-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pipeline-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp-pro-cons-test` (allow about 600 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp-pro-cons-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test0` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test0-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test1` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test1-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test2` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test2-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test3` (allow about 120 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test3-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-rpi3.cfg -c init -f /tmp/session.tcl
```

`smp_test4` (allow about 300 s)

```
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-
rpi3.cfg -c init \
  -c "targets bcm2837.cpu0; halt; mww 0x3f100024 0x5a000001; mww 0x3f10001c 0x5a000020; shutdown"
sleep 12
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: halt cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 1 2 3 ---"
foreach core {0 1 2 3} { targets [format {bcm2837.cpu%d} $core]; arm semihosting enable }
echo "--- stage: load_image __ELF__ ---"
targets bcm2837.cpu0
load_image __ELF__
echo "--- stage: resume cores 0 1 2 3 at 0x80000 ---"
targets bcm2837.cpu0
reg pc 0x80000
echo "  start PC core 0 = [reg pc]"
resume
foreach core {1 2 3} {
  targets [format {bcm2837.cpu%d} $core]
  resume
}
EOF
sed -i "s|__ELF__|$D/smp_test4-hwd|g" /tmp/session.tcl
$OPENOCD -s $A64/test/boards/rpi-zero-2w -s $SCRIPTS -f $A64/test/boards/rpi-zero-2w/openocd-jlink-
rpi3.cfg -c init -f /tmp/session.tcl
```

4.7 `aarch32-luckfox-lyra` — hardware

The Luckfox Lyra (RK3506, three Cortex-A7) is reached over SWD by a CMSIS-DAP probe (`$A32/test/boards/luckfox-lyra/openocd.cfg`, which runs `init` itself). Only core 0 is a debug target at load time — the image releases the other two — so only core 0 is halted, loaded and resumed, and there are no `__smp_spin` words to zero. Before the load, the MMU and caches the miniloader left on are switched off. There is no reset step. The entry read from every Lyra ELF is `0x20003c`.

```
D=$BUILD/aarch32-luckfox-lyra-cmake-gcc-debug/platform-bin/port-tests/test
CFG=$A32/test/boards/luckfox-lyra
```

`mutex-stress-test` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/mutex-stress-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`sd_test` (allow about 450 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/sd_test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp-mat-sdcard-test` (allow about 900 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp-mat-sdcard-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp-mat-test` (allow about 900 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp-mat-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp-num-test` (allow about 600 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp-num-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp-pipeline-test` (allow about 600 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp-pipeline-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp-pro-cons-test` (allow about 600 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp-pro-cons-test-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test0` (allow about 120 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test0-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test1` (allow about 120 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test1-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test2` (allow about 120 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test2-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test3` (allow about 120 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test3-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test4` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test4-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test5` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test5-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test6` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test6-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test7` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test7-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test_int` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test_int-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test_int2` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test_int2-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test_int3` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test_int3-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test_int4` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test_int4-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

`smp_test_int5` (allow about 300 s)

```
cat > /tmp/session.tcl <<'EOF'
echo "--- stage: JTAG clock -> 4000 kHz ---"
adapter speed 4000
echo "--- stage: halt cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; halt }
echo "--- stage: enable semihosting on cores 0 ---"
foreach core {0} { targets [format {rk3506.a7.%d} $core]; arm semihosting enable }
echo "--- stage: pre-load ---"
targets rk3506.a7.0
if {[catch {
  set _t [target current]
  set _s [$_t arm mrc 15 0 1 0 0]
  $_t arm mcr 15 0 1 0 0 [expr {$_s & ~0x1005}]
  $_t arm mcr 15 0 7 5 0 0
  $_t arm mcr 15 0 7 5 6 0
  $_t arm mcr 15 0 8 7 0 0
} _e]} { echo "SANITIZE-ERR: $_e" } else { echo [format "SANITIZE-OK: SCTLR 0x%08x -> MMU/caches
off" $_s] }
echo "--- stage: load_image __ELF__ ---"
targets rk3506.a7.0
load_image __ELF__
echo "--- stage: resume cores 0 at 0x20003c ---"
foreach core {0} {
  targets [format {rk3506.a7.%d} $core]
  resume 0x20003c
}
EOF
sed -i "s|__ELF__|$D/smp_test_int5-hwd|g" /tmp/session.tcl
$OPENOCD -s $CFG -s $SCRIPTS -f $CFG/openocd.cfg -f /tmp/session.tcl
```

5. Cortex-M on QEMU

5.1 The commands

These tests are started by `ctest` directly (no runner script). A test passed when QEMU exits with status 0; the suites end with `Hasta la Vista!`, the port tests print `RESULT: PASS`. `ctest` gives each 1200 s (suites) or 300 s (port tests).

Checked on 2026-10-09 with these exact commands: `2xcortex-m33` `fp-switch-test` and `pico2-1cpu` `mutex-stress-test` (exit 0), `cortexm-pico2` `smp-test1` (`RESULT: PASS`, exit 0).

5.2 `2xcortex-m33` — QEMU

The harness suites on two Cortex-M33 (SSE-200) on QEMU's `mps2-an521`.

```
D=$BUILD/2xcortex-m33-cmake-gcc-debug/platform-bin
```

`rtos-apis-test`

```
timeout 1200 $QEMUARM --machine mps2-an521 --cpu cortex-m33 --smp 2 \
  --global sse-200.CPU0_FPU=on --global sse-200.CPU0_DSP=on \
  --global sse-200.CPU1_FPU=on --global sse-200.CPU1_DSP=on \
  --kernel $D/rtos-apis-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`mutex-stress-test`

```
timeout 1200 $QEMUARM --machine mps2-an521 --cpu cortex-m33 --smp 2 \
  --global sse-200.CPU0_FPU=on --global sse-200.CPU0_DSP=on \
  --global sse-200.CPU1_FPU=on --global sse-200.CPU1_DSP=on \
  --kernel $D/mutex-stress-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`fp-switch-test`

```
timeout 1200 $QEMUARM --machine mps2-an521 --cpu cortex-m33 --smp 2 \
  --global sse-200.CPU0_FPU=on --global sse-200.CPU0_DSP=on \
  --global sse-200.CPU1_FPU=on --global sse-200.CPU1_DSP=on \
  --kernel $D/fp-switch-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`cmsis-os-validator-test`

```
timeout 1200 $QEMUARM --machine mps2-an521 --cpu cortex-m33 --smp 2 \
  --global sse-200.CPU0_FPU=on --global sse-200.CPU0_DSP=on \
  --global sse-200.CPU1_FPU=on --global sse-200.CPU1_DSP=on \
  --kernel $D/cmsis-os-validator-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

5.3 `pico2-1cpu` — QEMU

The harness suites on one Cortex-M33 on QEMU's `mps2-an505`.

```
D=$BUILD/pico2-1cpu-cmake-gcc-debug/platform-bin
```

`rtos-apis-test`

```
timeout 1200 $QEMUARM --machine mps2-an505 --cpu cortex-m33 \
  --kernel $D/rtos-apis-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`mutex-stress-test`

```
timeout 1200 $QEMUARM --machine mps2-an505 --cpu cortex-m33 \
  --kernel $D/mutex-stress-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`fp-switch-test`

```
timeout 1200 $QEMUARM --machine mps2-an505 --cpu cortex-m33 \
  --kernel $D/fp-switch-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`cmsis-os-validator-test`

```
timeout 1200 $QEMUARM --machine mps2-an505 --cpu cortex-m33 \
  --kernel $D/cmsis-os-validator-test.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

5.4 `cortexm-pico2` — QEMU

The port tests that have a QEMU build run on a generic Cortex-M7 (QEMU's `mps2-an500`).

```
D=$BUILD/cortexm-pico2-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/cmsis-os-validator-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`fp-switch`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/fp-switch-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`mutex-stress`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/mutex-stress-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`rtos-apis`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/rtos-apis-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`sc-test-ko`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/sc-test-ko-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`smp-test1`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/smp-test1-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

5.5 `cortexm-pico2-rp2350b-psram` — QEMU

The port tests that have a QEMU build run on a generic Cortex-M7 (QEMU's `mps2-an500`).

```
D=$BUILD/cortexm-pico2-rp2350b-psram-cmake-gcc-debug/platform-bin/port-tests/test
```

`fp-switch`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/fp-switch-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`sc-test-ko`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/sc-test-ko-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

`smp-test1`

```
timeout 300 $QEMUARM -M mps2-an500 -cpu cortex-m7 \
  -kernel $D/smp-test1-qemu.elf --nographic -d unimp,guest_errors \
  --semihosting-config enable=on,target=native < /dev/null
```

6. RP2350 hardware (Pico 2, WeAct RP2350B, Pi-Zero RP2350B)

6.1 What a hardware run does

OpenOCD over a CMSIS-DAP probe. The test image is written to the flash (`program ... verify`), the chip is reset with `reset init` (a bare `reset` does not re-run the bootrom/XIP setup), semihosting is enabled on both cores, and core 1 is resumed **before** core 0 (a debug-halted core 1 does not answer the core-1 launch). The test's console is the board's serial port; its `RESULT:` line is also written through semihosting, so it appears in the OpenOCD output. When `RESULT: PASS` (or `RESULT: FAIL`) appears, stop OpenOCD (Ctrl-C).

One test per power cycle: power-cycle the board before the next test.

Each test is two commands: stop any OpenOCD already attached to that board's config, then run OpenOCD.

6.2 The boards

Platform	OpenOCD config	Probe	Flash
`cortexm-pico2`	`$C/test/boards/pico2/openocd.cfg`	CMSIS-DAP (any)	4 MB
`cortexm-pico2-rp2350b-psram`	`$C/test/boards/pico2-rp2350b-psram/openocd.cfg`	CMSIS-DAP `0xc251:0xf001`	16 MB
`cortexm-pico2-pizero`	`$C/test/boards/pico2-pizero/openocd.cfg`	CMSIS-DAP `0x0416:0x5951`	16 MB

6.3 `cortexm-pico2` — hardware, programmed into flash

```
D=$BUILD/cortexm-pico2-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/cmsis-os-validator-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`exc-test`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/exc-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`fp-switch`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/fp-switch-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`mutex-stress`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/mutex-stress-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`rtos-apis`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/rtos-apis-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`sc-test-ko`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/sc-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-mat-test`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-mat-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-ko`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-usb-cdc-acm`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-usb-cdc-acm-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-usb-hid`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-usb-hid-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test0`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test0-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test1`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test1-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test2`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test2-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test3`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test3-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test4`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test4-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test5`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test5-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

6.4 `cortexm-pico2` — hardware, loaded into RAM

These four tests have their own runner (`$C/test/pico2/<test>/hw.sh`, which the board's `hw.sh` hands them to): the image is loaded into SRAM without writing the flash, the vector table is moved to `0x20000000`, and core 0 is started from the image's initial stack pointer and reset vector.

`cmsis-os-validator-ram`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "rp2350.cm0 configure -work-area-phys 0x20070000 -work-area-size 0x8000" \
  -c "load_image \"$D/cmsis-os-validator-ram-hwd\"" \
  -c "verify_image \"$D/cmsis-os-validator-ram-hwd\"" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "set v [read_memory 0x20000000 32 2]" \
  -c "mww 0xe000ed08 0x20000000" \
  -c "reg sp [lindex \$v 0]" \
  -c "reg pc [expr {[lindex \$v 1] & ~1}]" \
  -c "resume"
```

`mutex-stress-ram`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "rp2350.cm0 configure -work-area-phys 0x20070000 -work-area-size 0x8000" \
  -c "load_image \"$D/mutex-stress-ram-hwd\"" \
  -c "verify_image \"$D/mutex-stress-ram-hwd\"" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "set v [read_memory 0x20000000 32 2]" \
  -c "mww 0xe000ed08 0x20000000" \
  -c "reg sp [lindex \$v 0]" \
  -c "reg pc [expr {[lindex \$v 1] & ~1}]" \
  -c "resume"
```

`rtos-apis-ram`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "rp2350.cm0 configure -work-area-phys 0x20070000 -work-area-size 0x8000" \
  -c "load_image \"$D/rtos-apis-ram-hwd\"" \
  -c "verify_image \"$D/rtos-apis-ram-hwd\"" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "set v [read_memory 0x20000000 32 2]" \
  -c "mww 0xe000ed08 0x20000000" \
  -c "reg sp [lindex \$v 0]" \
  -c "reg pc [expr {[lindex \$v 1] & ~1}]" \
  -c "resume"
```

`smp-mat-test-ram`

```
pkill -9 -f "openocd.*boards/pico2/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "rp2350.cm0 configure -work-area-phys 0x20070000 -work-area-size 0x8000" \
  -c "load_image \"$D/smp-mat-test-ram-hwd\"" \
  -c "verify_image \"$D/smp-mat-test-ram-hwd\"" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "set v [read_memory 0x20000000 32 2]" \
  -c "mww 0xe000ed08 0x20000000" \
  -c "reg sp [lindex \$v 0]" \
  -c "reg pc [expr {[lindex \$v 1] & ~1}]" \
  -c "resume"
```

6.5 `cortexm-pico2-rp2350b-psram` — hardware

```
D=$BUILD/cortexm-pico2-rp2350b-psram-cmake-gcc-debug/platform-bin/port-tests/test
```

`exc-test`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/exc-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`fp-switch`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/fp-switch-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`sc-test-ko`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/sc-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-mat-test`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-mat-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-ko`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-nested`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-nested-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-nested-clock`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-nested-clock-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-nested-clock_200`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-nested-clock_200-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-nested-clock_250`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-nested-clock_250-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test0`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test0-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test1`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test1-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test2`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test2-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test3`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test3-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test4`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test4-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test5`

```
pkill -9 -f "openocd.*boards/pico2-rp2350b-psram/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-rp2350b-psram/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test5-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

6.6 `cortexm-pico2-pizero` — hardware

```
D=$BUILD/cortexm-pico2-pizero-cmake-gcc-debug/platform-bin/port-tests/test
```

`exc-test`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/exc-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`psram-exec`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/psram-exec-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`psram-mat-test-250`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/psram-mat-test-250-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`sc-test-ko`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/sc-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-mat-test`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-mat-test-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-ko`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-ko-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-usb-cdc-acm`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-usb-cdc-acm-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test-usb-hid`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test-usb-hid-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test0`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test0-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test1`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test1-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test2`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test2-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test3`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test3-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test4`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test4-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

`smp-test5`

```
pkill -9 -f "openocd.*boards/pico2-pizero/openocd.cfg"
$OPENOCD -s $SCRIPTS -f $C/test/boards/pico2-pizero/openocd.cfg \
  -c "init" \
  -c "reset init" \
  -c "program \"$D/smp-test5-hwd\" verify" \
  -c "reset init" \
  -c "targets rp2350.cm1" \
  -c "arm semihosting enable" \
  -c "resume" \
  -c "targets rp2350.cm0" \
  -c "arm semihosting enable" \
  -c "resume"
```

7. STM32F4 hardware (Nucleo-F411RE, WeAct F411CE, WeAct F412RE)

7.1 What a hardware run does

OpenOCD halts the chip, writes the test image to the flash, enables semihosting (the trace output is a semihosting call, which faults when no debugger listens), then resets the chip into the image (`reset run`). The semihosting output and the `RESULT:` line appear in the OpenOCD output; the board's UART console (115200 8N1) is separate. When `RESULT: PASS` (or `RESULT: FAIL`) appears, stop OpenOCD (Ctrl-C).

Platform	OpenOCD config	Probe
`cortexm-nucleof411`	`$C/test/boards/nucleof411/openocd.cfg`	the Nucleo's ST-Link (`board/st_nucleo_f4.cfg`, connect under reset)
`cortexm-weactf411`	`$C/test/boards/weactf411/openocd.cfg`	CMSIS-DAP `0x0d28:0x0204` (another one: add `-c 'set CMSIS_DAP_VID_PID {0x1a86 0x8011}'` before `-f`)
`cortexm-weactf412`	`$C/test/boards/weactf412/openocd.cfg`	ST-Link (V2 / V2-1 / V3)

The SWD clock of the two WeAct configs is 1000 kHz; another one is set with `-c 'set ADAPTER_KHZ <n>'` before `-f`.

7.2 `cortexm-nucleof411` — hardware

```
D=$BUILD/cortexm-nucleof411-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/nucleof411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/cmsis-os-validator-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mos-test1`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/nucleof411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mos-test1-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mutex-stress`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/nucleof411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mutex-stress-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`rtos-apis`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/nucleof411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/rtos-apis-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

7.3 `cortexm-weactf411` — hardware

```
D=$BUILD/cortexm-weactf411-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/cmsis-os-validator-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mos-test1`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mos-test1-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mutex-stress`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mutex-stress-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`rtos-apis`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/rtos-apis-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`spi-pipeline`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf411/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/spi-pipeline-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

7.4 `cortexm-weactf412` — hardware

```
D=$BUILD/cortexm-weactf412-cmake-gcc-debug/platform-bin/port-tests/test
```

`cmsis-os-validator`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf412/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/cmsis-os-validator-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mos-test1`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf412/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mos-test1-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`mutex-stress`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf412/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/mutex-stress-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`rtos-apis`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf412/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/rtos-apis-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

`uart-test1`

```
$OPENOCD -s $SCRIPTS -f $C/test/boards/weactf412/openocd.cfg \
  -c "init" \
  -c "reset halt" \
  -c "program \"$D/uart-test1-hwd\"" \
  -c "arm semihosting enable" \
  -c "reset run"
```

The legacy single-core platforms `nucleo-f411re`, `nucleo-f767zi` and `nucleo-h743zi` are not here: xpack-dev-smp.md §21.3 records that they fail at configure.

8. POSIX native (the host, `native-cmake-sys`)

8.1 The commands

The port tests are host executables; `test_smpl/run-host.sh` starts each one through `/usr/bin/env` under `timeout`, giving the tests that use a card the path of a disk image file in `UOS_SD_IMAGE`. A test passed when it prints `RESULT: PASS`. The CMSIS-RTOS validator is started by `ctest` directly and passes when it exits with status 0 (`Test Result: PASSED`).

Checked on 2026-10-09 with these exact commands: `smp_test0` (`RESULT: PASS (10 heartbeats on core 0)`) and `flatfs-test` with its image (`RESULT: PASS`), both exit 0.

```
D=$BUILD/native-cmake-sys-debug/platform-bin/port-tests
mkdir -p $D/.host-logs
```

8.2 The tests

`flatfs-test`

```
timeout 300 /usr/bin/env UOS_SD_IMAGE=$D/.host-logs/flatfs-test.disk.img $D/flatfs-test-host
```

`mutex-ceiling-test`

```
timeout 300 /usr/bin/env $D/mutex-ceiling-test-host
```

`mutex-stress`

```
timeout 300 /usr/bin/env $D/mutex-stress-host
```

`rtos-apis`

```
timeout 300 /usr/bin/env $D/rtos-apis-host
```

`smp-mat-test`

```
timeout 900 /usr/bin/env $D/smp-mat-test-host
```

`smp-mutex-stress`

```
timeout 300 /usr/bin/env $D/smp-mutex-stress-host
```

`smp-num-test`

```
timeout 1000 /usr/bin/env UOS_SD_IMAGE=$D/.host-logs/smp-num-test.disk.img $D/smp-num-test-host
```

`smp-pipeline-test`

```
timeout 1000 /usr/bin/env UOS_SD_IMAGE=$D/.host-logs/smp-pipeline-test.disk.img $D/smp-pipeline-test-host
```

`smp-pro-cons-test`

```
timeout 1000 /usr/bin/env $D/smp-pro-cons-test-host
```

`smp-rtos-apis`

```
timeout 300 /usr/bin/env $D/smp-rtos-apis-host
```

`smp_test0`

```
timeout 150 /usr/bin/env $D/smp_test0-host
```

`smp_test1`

```
timeout 150 /usr/bin/env $D/smp_test1-host
```

`smp_test2`

```
timeout 300 /usr/bin/env $D/smp_test2-host
```

`smp_test3`

```
timeout 150 /usr/bin/env $D/smp_test3-host
```

`smp_test4`

```
timeout 150 /usr/bin/env $D/smp_test4-host
```

`cmsis-os-validator`

```
cd $BUILD/native-cmake-sys-debug/platform-bin
timeout 600 ./cmsis-os-validator-test
```

9. The same tests through `ctest`

The commands above are what these run:

```
cd $BUILD/<platform>-cmake-gcc-debug
ctest -N                                        # the test names
ctest -R '^<platform>-<test>-qemu$' -V          # one QEMU test (run-qemu.sh)
ctest -L qemu -V                                # all the QEMU tests
ctest -R '^<platform>-<test>-hwd$' -V           # one hardware test (the board's hw.sh)
```

For the native platform the names are `native-<test>-host`; for the Cortex-M QEMU suites, `<platform>-<suite>-test`. The Cortex-M boards' `hw.sh` run OpenOCD themselves (sections 6 and 7); `ctest` gives them 240 s (`cortexm-pico2`) or 600 s (the others).

The AArch32/AArch64 board `hw.sh` looks for the shared runner in the kernel folder next to the port: `micro-os-plus-iii`, as here, else `micro-os-plus-iii-smp`, each with or without `.git`. A kernel kept anywhere else needs `UOS_SMP_DIR`:

```
UOS_SMP_DIR=$K ctest -R '^aarch32-rpi3b-smp_test0-hwd$' -V
```

`ctest` calls `hw.sh <test> 600`, so every hardware case gets 600 s; the per-test times in section 4 are the ones `run-hw.sh` uses when no time is given.