Νεκτάριος Μπούμπαλος 20441 Δανάη Σπέντζου 20237

1η Άσκηση

a)

IN 10H

MVI A,OOH

LXI H,0900H

MOV M,A

STORE_LOOP:

INR A

INX H

MOV M,A

CPI 7FH

JNZ STORE LOOP

Η πρώτη εντολή IN 10Η απενεργοποιεί την προστασία της μνήμης. Στη συνέχεια, η εντολή MVI A,OOΗ αποθηκεύει την τιμή 00Η στον επεξεργαστή. Η εντολή LXI Η,0900Η αποθηκεύει τη διεύθυνση 0900Η στους επεξεργαστές ΗL. Στη συνέχεια, η εντολή MOV M,A αποθηκεύει την τιμή του A στη διεύθυνση που κατέχουν οι επεξεργαστές ΗL.

Η διαδικασία αυτή επαναλαμβάνεται σε μια επαναληπτική δομή μέχρι να αποθηκευθούν όλες οι τιμές από το 0 έως το 255 με φθίνουσα σειρά στη διαδοχικές θέσεις της μνήμης από τη διεύθυνση 0900Η και κάθε φορά αυξάνοντας κατά ένα τη διεύθυνση και την τιμή του Α. Η εντολή CPI 7FH ελέγχει αν η τιμή του Α είναι μικρότερη από τη μέγιστη τιμή 7FH (ή 127 στο δεκαδικό σύστημα) και η εντολή JNZ STORE_LOOP επαναλαμβάνει τη διαδικασία αποθήκευσης της τιμής στην επόμενη θέση μνήμης μέχρι να αποθηκευτούν όλες οι τιμές στην μνήμη.

LOAD:

LXI B,0000H

MOV A, M
MVI D,09H
ALL_DIGITS:
DCR D
JZ NEXT
RRC
JNC ALL_DIGITS
COUNT_ONES:
INX B
JMP ALL_DIGITS
NEXT:
DCR L
JNZ LOAD
γ)
γ)
γ) MVI E, FFH
MVI E, FFH
MVI E, FFH MVI D,00H
MVI E, FFH MVI D,00H MOV A, M
MVI E, FFH MVI D,00H MOV A, M STATEMENT:
MVI E, FFH MVI D,00H MOV A, M STATEMENT: CPI 10H

INR D DONT_COUNT: INR L MOV A, M DCR E JZ CHECK_LAST JMP STATEMENT CHECK_LAST: CPI 10H JC END CPI 61H JNC END INR D END: **END** 2η Άσκηση LXI B,0064H ; Load value 0064H into register pair B (B = 00H, C = 64H) START: ; Label for the start of the program LDA 2000H ; Load input from dip switches into accumulator RLC ; Rotate accumulator left, which places the value of the MSB in the carry flag JNC OFF ; If the MSB is not set, jump to label OFF JMP START ; Otherwise, jump back to the START label to check again

OFF: ; Label for when the MSB switch is off

LDA 2000H ; Load input from dip switches into accumulator

RLC ; Rotate accumulator left, which places the value of the MSB in the carry flag

JC ON1 ; If the MSB is set (i.e. the switch is turned on), jump to label ON1

JMP OFF ; Otherwise, continue waiting until the switch is turned on

ON1: ; Label for when the MSB switch is on

MVI D, C8H ; Load the value C8H (200 decimal) into register D, which will be used for the delay loop

LDA 2000H ; Load input from dip switches into accumulator

RLC ; Rotate accumulator left, which places the value of the MSB in the carry flag

JNC OPEN ; If the MSB is turned off, the push-button (off-on-off) is activated, jump to label OPEN

JMP ON1 ; Otherwise, continue waiting until the switch is turned off

OPEN: ; Label for when the push-button is activated

LDA 2000H ; Load input from dip switches into accumulator

RLC ; Rotate accumulator left, which places the value of the MSB in the carry flag

JC ON_AGAIN; If the MSB is still on, the timer keeps on going, jump to label ON_AGAIN

JMP OPEN ; Otherwise, continue waiting until the switch is turned on again

ON_AGAIN: ; Label for resetting the timer when the MSB switch is turned off

LDA 2000H ; Load input from dip switches into accumulator

RLC ; Rotate accumulator left, which places the value of the MSB in the carry flag

JNC RESTART; If the MSB is turned off, jump to label RESTART to reset the timer

MVI A,00H ; Load the value 00H into the accumulator

STA 3000H ; Store the value in the accumulator to the memory location 3000H, which turns on all

LEDs

CALL DELB; Call subroutine DELB to delay for 1/10 seconds

DCR D ; Decrement the value of register D

JNZ ON AGAIN; If D is not zero, jump back to label ON AGAIN

MVI A,FFH ; Load the value FFH into the accumulator

```
STA 3000H ; Store the value in the accumulator to the memory location 3000H, which turns off all
LEDs
JMP OFF ; Jump to label OFF to start waiting for the MSB switch to be turned on again
RESTART: ; Label for resetting the timer when the MSB switch is turned off during LED display
 MVI D, C8H; Load the value C8H (200 decimal) into register D
JMP OPEN ;
3η Άσκηση
i)
START:
MVI D,08H
               ;D = 8
               ;Load input from dip switches to A
LDA 2000H
MVI B,00H
               ;B = 0
CHECK:
                               ;Starting from LSB to MSB we find the first
;dip switch that's on
RRC
DCR D
               ;Decrease D
JZ TURNOFF
               ;If D = 0 then no dip switch was on so turn off
;all LEDs and start again
INR B
               ;Increase B (B is equal to the current position that
;we're checking)
JNC CHECK
               ;If a dip switch is on then stop looping
MVI A, FEH
DCR B
TURN_ON:
RLC
               ;Rotate left until we reach the correct position
```

DCR B JNZ TURN_ON STA 3000H ;Turn on the LED JMP START ;Start checking again TURNOFF: ;Getting here means that no dip switch was on MVI A, FFH STA 3000H ;Turn off all LEDs JMP START **END** ii) START: **CALL KIND** CPI 00H; If we press 0 then go to OFF JZ OFF CPI 09H; If we press 9 then go to OFF JNC OFF MOV B,A ;Save A to register B MVI A,00H ;A = 0 DCR B ;Decrease B JZ OPEN ;If B = 0 then open all LEDs (We pressed 1) INR A ;Increase A REPEAT:

;If B = 0 then go to OPEN with the current data of A

INR A

RLC

DCR B

JZ OPEN

;Rotate left

JMP REPEAT	
OPEN:	
STA 3000H	;Open the LEDs starting from the number that we pressed
;up to the MSB	
JMP START	;Start checking again
OFF:	;If we pressed 0 or 9 then turn off all LEDs and go to START
MVI A,FFH	
STA 3000H	
JMP START	
END	
iii)	
START:	
IN 10H	
LXI H,0A00H	
MVI B,04H	
L1:	
MVI M,10H	
INX H	
DCR B	
JNZ L1	
LINEO:	
MVI A,FEH	
STA 2800H	
LDA 1800H	
ANI 07H	

MVI C,86H
CPI 06H
JZ SHOW
MVI C,85H
CPI 05H
JZ SHOW
LINE1:
MVI A,FDH
STA 2800H
LDA 1800H
ANI 07H
MVI C,84H
CPI 06H; RUN
JZ SHOW
MVI C,80H
CPI 05H; FETCH_REG
JZ SHOW
MVI C,82H
CPI 03H; FETCH_ADDRS
JZ SHOW
LINE2:
MVI A,FBH
STA 2800H
LDA 1800H
ANI 07H

MVI C,00H		
CPI 06H; 0		
JZ SHOW		
MVI C,83H		
CPI 05H; STORE	/IN	CR
JZ SHOW		
MVI C,81H		
CPI 03H; DECR		
JZ SHOW		
LINE3:		
MVI A,F7H		
STA 2800H		
LDA 1800H		
ANI 07H		
MVI C,01H	; 1	
CPI 06H		
JZ SHOW		
MVI C,02H	; 2	
CPI 05H		
JZ SHOW		
MVI C,03H	; 3	
CPI 03H		
JZ SHOW		
LINE4:		
MVI A,EFH		
STA 2800H		
LDA 1800H		
ANI 07H		
MVI C,04H		

CPI 06H; 4 JZ SHOW MVI C,05H CPI 05H; 5 JZ SHOW MVI C,06H CPI 03H; 6 JZ SHOW LINE5: MVI A,DFH STA 2800H LDA 1800H ANI 07H MVI C,07H CPI 06H; 7 JZ SHOW MVI C,08H CPI 05H; 8 JZ SHOW MVI C,09H CPI 03H; 9 JZ SHOW LINE6: MVI A,BFH STA 2800H LDA 1800H ANI 07H MVI C,0AH CPI 06H; A

INX H

ANI FOH RLC RLC RLC RLC MOV M,A LXI D,0A00H CALL STDM CALL DCD JMP START **END** 4η Άσκηση START: ;Load input from dip switches to A LDA 2000H ;Save A to register B MOV B,A A0_B0: ANI 01H ;A = A AND 00000001 MOV C,A ;C = A ;A is equal to the input of dip switches MOV A,B ANI 02H ;A = A AND 00000010 AND0:

MOV A,C

RRC

ANA C

MOV D,A

A1_B1:

MOV A,B

ANI 04H ;A = A AND 00000100

MOV C,A ;C = A

MOV A,B

ANI 08H ;A = A AND 00001000

AND1:

RRC

ANA C

RRC

MOV E,A

RRC

ORA E ;Save X1 at 2nd LSB

MOV D,A ;Save X0 at LSB

A2_B2:

MOV A,B

ANI 10H ;A = A AND 00010000

MOV C,A ;C = A

MOV A,B

ANI 20H ;A = A AND 00100000


XOR0:

RRC

XRA C

MOV E,A

A3_B3: MOV A,B ANI 40H ;A = A AND 01000000 MOV C,A ;C = A MOV A,B ANI 80H ;A = A AND 10000000 XOR1: RRC XRA B RRC RRC MOV B,A RRC ORA D MOV D,A ;Χ3 αποθηκεύτηκε OR_X2: MOV A,B ORA E RRC RRC ORA D ; Χ2 αποθηκεύτηκε στον Α LED: CMA ;Inverse logic STA 3000H ;Turn on the correct LEDs JMP START ;Start checking again END Άσκηση 5η



Παρατηρούμε την εσωτερική δομή ενός SRAM 256x4 bit (16x16x4), όπου η πρόσβαση στις διάφορες γραμμές του πίνακα μνήμης γίνεται με βάση τις γραμμές διεύθυνσης A4-A7. Τέσσερις πολυπλέκτες 16-σε-1 επιλέγουν μία από τις 16 τετράδες-στήλες του πίνακα, βασιζόμενοι στις γραμμές διευθύνσεων A0-A3 και την επιλεγμένη γραμμή του πίνακα. Έτσι, μπορούμε είτε να εγγράψουμε τα δεδομένα D0-D3 στις επιλεγμένες θέσεις του πίνακα, είτε να διαβάσουμε τα δεδομένα από αυτές.


Για παράδειγμα, αν έχουμε μια διεύθυνση Α0...Α7 = 0110 1001, επιλέγουμε την 9η γραμμή και την 6η τετράδα του πίνακα μνήμης.

Όταν το σήμα CS (Chip Select) γίνει 0, ενεργοποιείται η λειτουργία της μνήμης. Στη συνέχεια, αν το σήμα WE (Write Enable) γίνει 0 και το σήμα RD (Read) γίνει 1, τότε ενεργοποιούνται οι απομονωτές με μπλε περίγραμμα και γίνεται εγγραφή στη μνήμη. Αντίθετα, αν το σήμα WE (Write Enable) γίνει 1 και το σήμα RD (Read) γίνει 0, τότε ενεργοποιούνται οι απομονωτές με κόκκινο περίγραμμα και γίνεται ανάγνωση από τη μνήμη.


Οι απομονωτές με μπλε περίγραμμα επιτρέπουν την εγγραφή δεδομένων στην επιλεγμένη θέση της μνήμης, ενώ οι απομονωτές με κόκκινο περίγραμμα επιτρέπουν την ανάγνωση δεδομένων από την επιλεγμένη θέση της μνήμης. Με βάση την κατάσταση αυτών των σημάτων, επιλέγεται η σωστή λειτουργία (εγγραφή ή ανάγνωση) για τη μνήμη.

Άσκηση 6η

A)



B)



7Η ΑΣΚΗΣΗ

A)

Abuman 7ⁿ

Lapens Munhus:

15	19	13	19	11	10	9	8	7	6	5	4	3	હ	1	0	Address	Memory	
0	0	0	0	0	0	0	0	0	0	٥	0	٥	0	٥	0	0000	RON1-8K	
	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1 FFF		
0	0	1	0	0	٥	٥	٥	0	٥	0	٥	0	٥	٥	٥	2000	2	
0	0	1	0	1	1	4	ı	L	1	1	1	1	1	1	1	AFFF	RAM1 - 1K	
0	0	1	L	0	٥	٥	٥	٥	٥	٥	٥	٥	٥	٥	0	3000		
0	0	2	2		1	1	1	1	ı	1	ı	1	1	1	1	3FFF	RAM2-4K	
0	1	0	0	٥	0	0	0	٥	0	0	٥	٥	٥	0	0	4000	RAM3-9K	
0	2	0	0	1	1	1	4	7	1	1	1	T	1	1	1	4 FFF		
0	1	0	1	D	0	0	0	0	۵	0	٥	0	0	0	0	5000		
0	ı	0	1	1	1	1	1	1	1	1	T	4	1	1	1	SFFF	ROM1-4K	
0	1	1	0	0	0	٥	0	0	0	0	0	6	0	0	0	6000	ROM2-9K	
0	1	1	0	1	1	1	1	1	1	9	_1	1	1	1	2	6FF		

