

ESIM Wiring Diagram Lookup

Find the ESIM circuit for this VIN and copy what the tests need

2018 Alfa Romeo Stelvio 2.0T (GU) | VIN ZASFAKPN5J7B88115

Why. The ESIM wiring test and wiTECH Test A need this car's exact ESIM connector, pin numbers, wire colours, ECU pin and ground point. Those are only in FCA service information for the VIN. This sheet is how to find them and what to write down.

Menu names vary. FCA's service information and wiTECH change between releases, and Alfa Romeo content may be organised differently from Chrysler/Jeep content. Treat the paths below as where to look, not exact clicks. No pin numbers are given here on purpose: copy them from the diagram for this VIN.

Where to find it

1. Route 1: from the fault code in wiTECH (quickest)

- Connect wiTECH, select the car, open the **ECM**, then its DTC list.
- Select **P0456** (or P0455 / P0440) and open its **diagnostic procedure**.
- FCA diagnostic procedures for EVAP codes usually include a **schematic** of the circuits the test uses, with connector views. Look for the ESIM (Evaporative System Integrity Module) and the ECU pins it connects to.

2. Route 2: FCA service information (full wiring diagrams)

- FCA's service information for independent shops is **TechAuthority** (techauthority.com); dealers use DealerCONNECT Service Library. Your wiTECH account may or may not include service information; if not, TechAuthority sells short subscriptions.
- Select the vehicle by **VIN** (ZASFAKPN5J7B88115), so the diagram matches this build.
- Open the **wiring diagrams** and search for: **ESIM, Evaporative System Integrity Module, EVAP, leak detection, canister**.
- Also open the **connector pin-out / connector views** for the ESIM connector and the ECU connector, and the **ground locations** page for the ground the ESIM uses.

3. Route 3: if neither is available

- Ask a dealer service advisor to print the ESIM circuit page and the ESIM and ECU connector views for the VIN. It is a two-minute lookup for them.

How to read it

- Follow each wire from the ESIM connector to where it ends: one should go to an **ECU pin** (the switch **signal**), and one to a **ground** (a ground point or an ECU sensor-ground pin). Some designs use more pins; note every one.
- Write down, for each ESIM pin: pin number, wire colour code, circuit name, and the far end (ECU connector and pin, or ground point ID).
- Note any **inline connector** the wires pass through on the way (a common corrosion point near the wheel well).
- If the diagram or its circuit description gives the switch's **reference voltage** or state logic (closed = sealed), note it: Test B step B2 compares against it.
- Take a photo or print of the page for the job file.

Fill-in sheet (copy into the wiring test PDF)

Item	From the diagram for this VIN
Source (wiTECH procedure / TechAuthority page / dealer print)	
ESIM connector ID and location	
ESIM pin 1: colour / circuit / far end	
ESIM pin 2: colour / circuit / far end	
Other ESIM pins (if any)	
ECU connector and signal pin	
Ground: ground point ID or ECU sensor-ground pin	
Inline connectors on the route	
Switch reference voltage / logic (if stated)	
wiTECH parameter name for the switch (Test A)	

Then

- Run **wiTECH Test A** (vacuum on the ESIM while watching the ECU's switch reading).
- If Test A fails, run the **ESIM Wiring Test** PDF's Test B with the pins above.
- Record results in cuore so the evidence gate and history keep them.