

Ridgeline Hiking Boots - Waterproofing How-To

1. Clean boots thoroughly with a soft brush and let them dry completely.
2. Apply waterproofing treatment evenly across the entire upper, including seams.
3. Pay extra attention to the junction between the upper and the rubber rand.
4. Allow to dry for 24 hours before wearing.
5. Reapply every 2-3 months with regular use, or sooner if water stops beading.