Outlook

ARAJET "DIFERENCIAS EN RAMPA" REVISION 20241031

Desde Jose Rodriguez <jrodriguez-alc@aviamltd.com>

Fecha Jue 31/10/24 16:25

Para Aimee Then <athen@aviamltd.com>; Alma Puello <apuello@aviamltd.com>; Angel Mejia <amejia@aviamltd.com>; Cinthia Garcia <cgarcia@aviamltd.com>; Edward Tavarez <etavarez@aviamltd.com>; Fausto Castillo <fcastillo@ccs.com.do>; Francisco Castellanos <fcastellanos@aviamltd.com>; Francisco Constanzo <fconstanzo@aviamltd.com>; Gustavo Martinez <gmartinez@aviamltd.com>; Iris Rehberger <irehberger@aviamltd.com>; Jensy Sarita <jsarita@aviamltd.com>; Jose Guareno <joguareno@aviamltd.com>; Jose Vinas <jvinas@aviamltd.com>; Juan Reynoso <jjreynoso@aviamltd.com>; Julio Baez <jbaez-alc@aviamltd.com>; Luis Cabrera <lcabrera@aviamltd.com>; Maizalda Polanco <mpolanco@ccs.com.do>; Maizalda Polanco <mpolanco@aviamltd.com>; Mariano de la Rosa <mdelarosa@aviamltd.com>; Miguel del Rosario <mdelrosario@aviamltd.com>

REVISION: 20241031

Sres.

favor tomar en cuenta las siguientes diferencias para los vuelos de **ARAJET**

-LAS MALETAS EN CONEXION VENDRAN CON UN TICKET AMARILLO (VER FOTO)

-SE PROHIBE USAR EL GANCHO PARA SUJETAR EL CONECTOR DEL GPU (VER FOTO)

-SIEMPRE REVISAR EL COMPARTIMIENTO 4. EN ALGUNOS VUELOS TRAEN BASURA INTERNACIONAL QUE SE DEBE RETIRAR EN PUNTA CANA.

-PARA LA COLOCACION DE CALZOS EN LA AERONAVE. AL COLOCAR LOS CALZOS DEBEN ENTRAR DESDE LA NARIZ DEL AVION.

4.2.2 Diagramas de colocación de calzos



-PARA LA COLOCACION DE LOS CONOS (SOLAMENTE SE COLOCAN ESTOS CONOS AUNQUE EL AVION TENGA LA ALETA SCIMITAR)

4.3.2 Colocación de conos para aviones a reacción bimotores montados en ala

-LIR

arajet	MANUAL DE OPERACIONES TERRESTRES Control de Carga	Ref. ARA-MAN-GRH-600 Rev. 00 Fecha. 15-02-2024 Página 6 de 16

```
LOADING INSTRUCTION/REPORT     PREPARED BY Carlos.Bido                    EDNO 01
ALL WEIGHTS IN KILOS

FROM/TO FLIGHT       A/C REG   VERSION      GATE TARMAC  CREW     DATE      TIME
CUN SDQ DWI4011      HI1082    8C177Y                    2/4      22Feb24   1593

PLANNED JOINING LOAD
SDQ  C  3 Y118  C     0  M     0  B  1077
JOINING SPECS

LOADING INSTRUCTION                                                          ACTUAL
************************************                                         WEIGHT
CPT 1 MAX 809 CHECK CPT COMBINATION ::
                                      ********************
:H1
:REPORT
************************************:: CPT 1 TOTAL :
CPT 2 MAX 2670 CHECK CPT COMBINATION ::
                                      ********************
:H2
:ONLOAD SDQ B/401/27
:REPORT
************************************:: CPT 2 TOTAL :
CPT 3 MAX 4086 CHECK CPT COMBINATION ::
                                      ********************
:H3
:ONLOAD SDQ B/676/37
:REPORT
************************************:: CPT 3 TOTAL :
CPT 4  MAX 763 CHECK CPT COMBINATION ::
                                      ********************
:H4
:REPORT
************************************:: CPT 4  TOTAL :
-------------------------------------------------------
:COMPT.        |    1     |    2     |    3     |    4     |
:TRANSIT KG.   |        0 |        0 |        0 |        0 |
:RELOAD  KG.   |        0 |        0 |        0 |        0 |
:SUBTOTAL      |        0 |        0 |        0 |        0 |
:ONLOAD  KG.   |        0 |      401 |      676 |        0 |
:TOTAL   KG.   |        0 |      401 |      676 |        0 |
:MAXIMUM KG.   |      809 |     2670 |     4086 |      763 |
-------------------------------------------------------

37 CNX BAGS CPT 3

THIS AIRCRAFT HAS BEEN LOADED IN ACCORDANCE WITH THESE
INSTRUCTIONS AND THE DEVIATIONS SHOWN ON THIS REPORT.
THE CONTAINER / PALLETS AND BULK LOAD HAVE BEEN SECURED
IN ACCORDANCE WITH CURRENT REGULATIONS.
(NAME,SIGNATURE,DATE):

      PREPARED BY                        RECEIVED BY

CARLOS BIDO 22500284165-DV
 NAME        SIGNATURE          NAME        SIGNATURE
```

-NOTOC

arajet	MANUAL DE OPERACIONES TERRESTRES Control de Carga	Ref. ARA-MAN-GRH-600 Rev. 00 Fecha. 15-02-2024 Página 8 de 16

NOTIFICATION TO CAPTAIN (NOTOC)

NOTOC DISTRIBUTION:
1. Top Copy (white) — Captain
2. Middle Copy (green) — Station File
3. Bottom Copy (yellow) — Freight Agent

INSTRUCTIONS FOR COMPLETION OF NOTOC

1. A NOTOC is to be issued whenever dangerous goods (DGs) or other special load items are to be carried on DG & Safety aircraft.
2. The NOTOC form is to be prepared by the freight handling agent contracted to Jazeera Airways in accordance with Ground Handling Agreements (in U.A.E. Safety aircraft Ltd) and Special Load are consigned as freight. Still by the Pilot Crew Leader when items of Special Load are loaded on by guests are to be carried.
3. The freight agent must print and sign his/her name in the DGs Preparation Certification field in the top right-hand section of the form, whenever freight loads containing dangerous goods are dispatched.
4. The person responsible for entering the Special Load details must complete their name in the applicable name fields of the Special Load section of the form. Two fields are provided for this: one for use by the Freight Agent and one for the Pilot Crew Leader (as required).
5. Before loading, the Pilot Crew Leader or CARGO (subject NOC) qualified delegate is to check the dangerous goods items for evidence of any non-normal features such as leakage or damage. After loading on the aircraft, the person responsible for supervising loading operations is to print and sign their name in the certification field in the bottom right-hand section of the form, certifying that the items have been loaded in the locations specified on the form.
6. The NOTOC is to be given to the captain who is to certify acceptance of the NOTOC in the section at the top-left corner of the form.

PORT OF LOADING:	**DGs PREPARATION CERTIFICATION** (To be completed by a CARGO Support GO certified person when dangerous goods are to be consigned as freight.) I certify that this NOTOC has been prepared in compliance with the procedures for the acceptance and dispatch of dangerous goods as detailed in the DG & Safety Dangerous Goods aircraft
FLIGHT NUMBER:	Signature:
DATE:	Prepared By: (Print name)
AIRCRAFT REG:	

DANGEROUS GOODS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Destination	Air Waybill Number Consignment Note	Proper Shipping Name	Class or Division	UN or ID Number	Sub-risk	No. of Packages	Net Quantity Non-Radioactive Material	Transport Index Radioactive Material	Radioactive Package Category	UN Packing Group	Code	CAO	Loaded ULD Position	Emergency Response Code

SPECIAL LOAD (To be completed by the person entering the Special Load details in to print their name here: ☐ (1) Freight Agent ☐ (2) Pilot Crew Leader)

Destination	Air Waybill Number Consignment Note	Contents and Categories	No. of Packages	Quantity	Supplementary Information	Code	Loaded ULD Position

ACCEPTANCE BY CAPTAIN:
I accept the loading conditions of the items specified on this NOTOC.
Captain's Name: (Print Name)
Captain's Signature:

CERTIFICATION BY PERSON SUPERVISING LOADING OPERATIONS:
I certify that the aircraft has been loaded in accordance with the procedures detailed in the DG&Safety Volume 4/5 Airport Handling Manual and Volume 4/6 Dangerous Goods Manual, and that the items have been checked, and that this NOTOC accurately reflects the locations of the DGs and/or special load items on this aircraft.
Certified By: (Print Name)
Signature:

-TOMAR EN CUENTA LA SIGUIENTE INFORMACION

Al acoplar el puente de embarque debemos asegurar que no esté en el cuadro de seguridad del puerto estático ningún objeto como el canopy y/o el autolevel.

Los puertos estáticos deben estar libres de escarcha, nieve, aguanieve, hielo, insectos y líquido.

Este es un ejemplo de la mala practica de acoplamiento de Jet bridge en la cabina del pasajero para embarque y desembarque.

Un bloqueo estático hará que el indicador de velocidad aerodinámica muestre indicaciones inexactas

-CONFIGUARACION DE LOS COMPARTIMIENTOS DE CARGA A CONTINUACION

a. La siguiente figura ilustra la disposición general de los compartimentos de carga delanteros. *Forward Cargo Hold.*





b. La siguiente figura ilustra la disposición general de los compartimentos de carga posteriores. *AFT Cargo Hold*



-PRIORIZAR LA ENTREGA DE CONEXIONES CORTAS

-AGUA POTABLE SIEMPRE SE COMPLETA AL 100%

-PARA LOS BANOS: 10 GALONES PARA ENJUAGAR Y 6 GALONES PARA DEJAR

-LOS CALZOS Y LOS CONOS SE RETIRAN CUANDO SE CIERRA LA PUERTA DELANTERA

-EL WALKAROUND (CHEQUEO 360) DEBE HACERSE A MAS TARDAR 15 MINUTOS DESPUES DE LA LLEGADA DEL AVION.

-SIEMPRE VAN A ENCENDER EL MOTOR NO. 1 (LADO DEL CAPITAN) CUANDO TENGAN EL APU INOPERATIVO

saludos

AVIAM Ltd.
Your satisfaction is our passion

Jose A. Rodríguez
Gerente De Capacitación
M. 829 928 0937
T. 809 959 0192 ext. 2813
Aeropuerto Intl. de Punta Cana
Jrodriguez-alc@aviamltd.com
Aviamltd.com