



User Manual

Decorative Wi-Fi LED lamp · controlled by one button or your phone

Describes firmware v2.6.0 · July 2026

<https://danieldriessen.github.io/cloud-lamp/user-manual.pdf>



Contents

1. Safety information — please read first	3
2. What's in the box / on the back	3
3. Quick start	4
4. The button	4
5. Connecting the lamp to your Wi-Fi.....	5
6. The remote control app	5
7. Firmware updates.....	6
8. Moving, Wi-Fi change, troubleshooting.....	6
9. Cleaning & care	7
10. Technical data.....	7

Welcome! Your Cloud-Lamp is a small decorative LED lamp that works entirely on its own — no internet, no app and no account required. If you want more, it also has a built-in remote control web app for your phone.

Permanent address of this manual (PDF): <https://danieldriessen.github.io/cloud-lamp/user-manual.pdf> (also reachable via the QR code on the sticker on the back of the lamp and the book icon in the lamp's web app)

1. Safety information — please read first

- **Power supply:** use only the **5 V DC power adapter included with the lamp** (2 A, barrel connector 5.5 × 2.1 mm, centre pin positive — matches the icon on the sticker). Do not use USB phone chargers/cables or any adapter with a different voltage, polarity or plug size — this can damage the lamp.
- **Indoor use only.** Keep the lamp away from water, high humidity (bathrooms), heat sources and direct sunlight.
- **Do not cover** the lamp while it is on, and do not operate it inside enclosed furniture without airflow. The case must be able to dissipate heat.
- **Not a toy.** The lamp is decoration for a child's room, not a plaything. Install the lamp and its cable **out of reach of babies and small children** — the cable is a strangulation hazard, and small parts could come loose if the case is damaged.
- **Never leave a damaged lamp powered.** If the case, cable or electronics are visibly damaged, unplug it and contact the builder.
- **Do not open the case** while the lamp is plugged in. There are no user-serviceable parts inside.
- **Epilepsy note:** some effects produce slow light animation. None of the built-in effects flash rapidly, but if flickering light affects you, use the solid colours.
- This lamp is a **hand-built hobby product**, not a certified commercial device. Use it with the same care as any small electronic gadget.

2. What's in the box / on the back

On the **back of the lamp** you'll find a sticker with everything you need:

Sticker field	Meaning
Model	Product model (CL-1)
S/N	Your lamp's serial number, e.g. CFB911 — also identifies the setup Wi-Fi (below)
Hostname	Your lamp's remote control address once it's on your home Wi-Fi, ready to type straight into your browser, e.g. http://cloud-lamp-cfb911.local
WiFi-Passw.	Password for the lamp's own setup Wi-Fi hotspot (see §5)
Power-Supply	Rating of the included power adapter — see §1
QR code ("Manual")	Opens this manual

The setup Wi-Fi hotspot itself is named `Cloud-Lamp-` followed by your **S/N** — e.g. a lamp with `S/N: CFB911` opens the hotspot `Cloud-Lamp-CFB911` .

3. Quick start

1. Plug the lamp into its included 5 V power adapter. It is immediately usable with the button — Wi-Fi is optional.
2. Press the button once: the lamp turns on.
3. That's it. If you also want phone control, continue with [Wi-Fi setup](#).

4. The button

Everything can be done with the single push-button:

Action	What it does
Press once	Turn the lamp on / off
Press twice (quickly)	Switch to the next effect
Press and hold	Dim up / down while held (direction alternates each time)
Hold while plugging in power, keep holding ~10 s	Factory reset — the lamp pulses red as a warning; release early to cancel

The lamp remembers brightness and effect — also after unplugging. Whether it also turns itself back **on** after a power cut is a separate setting, **Power Behavior** — see the note in §6.

5. Connecting the lamp to your Wi-Fi

You only need this once (and again if you move or change your Wi-Fi password):

1. Plug the lamp in and wait about a minute.
2. On your phone, open **Settings** → **Wi-Fi** and connect to the network named **Cloud-Lamp-** followed by the **S/N** on the sticker (e.g. **Cloud-Lamp-CFB911**), using the **WiFi-Passw. on the sticker**.
3. A configuration page opens automatically (if not, open **192.168.4.1** in your browser). It starts in English — use the language menu at the top of the page for one of the other nine languages listed in [section 6](#).
4. Choose your home Wi-Fi, enter its password, save.
5. The lamp connects to your Wi-Fi. Reconnect your phone to your home Wi-Fi.

The lamp keeps working normally as a lamp during all of this.

6. The remote control app

Open the **Hostname from the sticker** in your phone's browser, exactly as printed (e.g. <http://cloud-lamp-cfb911.local>). You can:

- turn the lamp on/off and dim it,
- choose colours and special effects from the *Effect Presets* grid,
- pick **any colour you like** — tap *Custom color* and your device's own colour picker opens; the lamp remembers the colour even after unplugging (press the button twice to go back to the presets),
- adjust the speed of animated effects,
- change settings and install firmware updates.

The app is available in **English, German, Spanish, French, Italian, Dutch, Polish, Portuguese, Turkish and Russian** (language menu in Settings).

iPhone / iPad — install as an app: the page offers a "Create a remote control app" button with step-by-step instructions. Afterwards the lamp opens full-screen from your home screen like a normal app.

iPhone tip: if the home-screen icon shows a connection error, open **Settings** → **Apps** → **Safari** and turn off "*Not Secure Connection Warning*", then remove and re-add the icon. The lamp lives only in your home network and cannot use HTTPS — this is normal for home devices.

For smart-home users: under Settings → MQTT you can connect the lamp to your own MQTT broker (e.g. Home Assistant, ioBroker) — off by default, no account or cloud service required. Turn it on and enter your broker's address, port, and (if needed) username/password directly in the app, then tap **Save** to apply them — nothing needs to be reflashed, and your entries are kept even if you switch it off again. If you don't recognise these terms, you can safely ignore this feature.

Power Behavior: under Settings you can choose what the lamp does after a power cut — **Start switched off** (the default) or **Restore Last State** (turns itself back on, with the same brightness and effect, if it was on when the power went out). This only affects an actual power cut: after a firmware update or pressing Restart, the lamp always comes back exactly how it was beforehand either way.

7. Firmware updates

The lamp checks for updates automatically (every 6 hours). When one is available, the web app shows an **Update available** badge on the main screen, next to the "Connected" indicator — tap it (or go to **Settings** → **Firmware** yourself) to see it there too. Tap **Install update** and a full-screen guide walks you through installing, restarting and reconnecting — keep the lamp plugged in and wait until it says **Update complete**. You can also check manually with **Check for updates now**.

Updates are safe: a failed download or power cut during the update cannot break the lamp, and all your settings are kept — the lamp also comes back on (or stays off) exactly as it was right before the update, regardless of the Power Behavior setting mentioned in §6. While the update runs, the lamp may briefly stop answering the web app (that is normal — it is writing the new firmware and then restarting).

Seeing "Update failed" right after a slow-feeling update? If the lamp took a while to reconnect, the app can give up waiting and show "Update failed" even though the update actually completed. Check **Settings** → **Firmware** → **Installed version** first — if it already shows the version you just installed, nothing is wrong and you can ignore the failed message.

8. Moving, Wi-Fi change, troubleshooting

New Wi-Fi / moved house: the lamp can't find the old network, so it automatically opens its setup hotspot again after ~1 minute — just repeat [Wi-Fi setup](#). Alternatively use **Settings** → **Change Wi-Fi network...** in the web app.

Web page not reachable?

1. Make sure your phone is on the **same Wi-Fi** as the lamp.

2. Type the Hostname exactly as printed on the sticker.
3. Unplug the lamp, wait 5 seconds, plug it back in, wait a minute.

Update finished but the lamp can't be reached afterwards? In rare cases the lamp can lose its Wi-Fi connection right after installing an update and reopen its own setup hotspot, just like during initial setup (look for `Cloud-Lamp-XXXXXX` in your phone's Wi-Fi list). If so, simply repeat [Wi-Fi setup](#) — the update itself and all your other settings are unaffected.

Lamp doesn't react to the button? Unplug and replug the power. The button works even without any Wi-Fi — if it still doesn't respond, contact the builder.

Factory reset: hold the button *while* plugging in the power and keep holding for about 10 seconds while the lamp pulses red. This erases the saved Wi-Fi and all settings; afterwards the lamp opens its setup hotspot again (sticker).

9. Cleaning & care

- Unplug before cleaning.
- Wipe with a **dry or slightly damp** soft cloth. No cleaning agents, no water jets.
- The case is 3D-printed PLA plastic: keep it away from strong heat (radiators, cars in summer, > ~50 °C), which can deform it.

10. Technical data

Power supply	5 V DC / 2 A, barrel connector 5.5 × 2.1 mm, centre pin positive (included)
Light source	24 addressable RGB LEDs (WS2812)
Radio	Wi-Fi 2.4 GHz (802.11 b/g/n) — 5 GHz-only networks are not supported
Controls	1 push-button, web app (10 languages)
Effects	28 (solid colours + special effects) plus a free colour picker in the web app
Firmware	Open source: github.com/danieldriessen/cloud-lamp

Cloud-Lamp is a personal hobby project by DD Productions. This manual always describes the latest firmware; the web app's [Settings](#) → [About](#) shows the version your lamp runs.