

Quick Start Guide for Cisco 7945 IP Phone

Standard Phone User Guide



Basic Phone Use				
Ringer Volume	1. Press the VOLUME key (with phone on hook) to hear a sample ring.			
	2. Press the up and down arrows to reach the desired level.			
	3. To save, press SETTINGS and then press the SAVE key.			
Handset Volume	1. To increase or decrease the volume of your handset, lift the handset and press the up or down volume.			
	button. The volume buttons adjust the volume for the currently active condition.			
	2. To save the setting, press the SAVE soft key.			
	* Note: Volume setting should be saved near the middle, only increasing as needed per call. If you are			
	consistently needing to increase the volume contact IT Dept.			
Place a call	Either lift handset and dial, press line button and dial, or press New Call soft key and dial.			
	Dial 4 digits for internal calls. Dial 9 + number for local calls.			
	Dial 9 + 1 + number for long distance calls.			
	Dial 911 or 9 + 911 for Emergency Calls.			
Answer a call	Lift handset, press Line Appearance, or press ANSWER soft key.			
	If you receive a second call on your individual extension, you will hear a "beep."			
	To answer second call, press Line -OR- press ANSWER soft key. (First call is automatically put on			
	hold).			
End a call	Hang up handset, or press END CALL soft key for speaker mode.			
Mute a call	To mute, press MUTE. Press MUTE again to disengage.			
Place a call on	1. Press the HOLD soft key.			
Hold	2. Press the RESUME soft key or press the Line Appearance button to return to a call.			
	If multiple calls are on hold on the same Line Appearance, use the scroll key to select the desired			
	call before pressing RESUME.			
Transfer a call	1. During a call, press the TRANSFER soft key. This places the call on hold.			
	2. Dial the number to which you wish to transfer the caller.			
	3. When ringing begins, press TRANSFER again, or wait for party to answer then press TRANSFER. If party			
	refuses call, press RESUME soft key, or extension key where call is held to take the call back.			



Quick Start Guide for Cisco 7945 IP Phone

Standard Phone User Guide

Technology Integration Group.	Standard Phone User Guide
Basic Phone Use	
Blind Transfer	1. During a call, press the TRANSFER soft key. This places the call on hold.
	2. Press the MESSAGES button to call the Cisco Unity system.
	3. While you are being asked for your password, press the # key
	4. While hearing the Opening Greeting, dial the destination extension followed by "# 2" – for example,
	"2064 # 2".
	5. Press the TRANSFER button again to complete the blind transfer
Host an Ad Hoc	1. While on a call, press the MORE soft key, then the CONFRN soft key. This will put the first call on hold
Conference Call	and select a new line.
	2. Place a call to another number.
	3. When the call connects, press CONFRN again to add this party to the conference.
	4. Repeat to add up to 5 parties.
	 When call originator hangs up, no additional parties can be added.
Host a Meet Me	1. Lift the handset or press SPEAKER
Conference Call	2. Press MORE soft key
	3. Press MEETME soft key
	4. Dial Meet Me location (4-digit number)
Participate in a	1. Lift the handset or press SPEAKER
Meet Me	2. Dial Meet Me location (4-digit number)
Conference Call	Note: Calls can be transferred to a Meet Me by using the normal transfer procedure.
Call Pick-Up	1. As the phone rings at an extension within your Call Group, lift the handset or select a line button.
	2. Press the MORE soft key to view the PickUp soft key.
	3. Press the PickUp soft key to transfer the call to your extension.
	4. Press the Answer soft key to answer the re-directed call on your phone.
Call Park	1. While on a call, press MORE soft key until you see PARK tab.
	2. Press PARK. The display shows the number where the call is parked.
	3. To retrieve the parked call from any phone, lift handset and dial Park number.
Last Number	Lift handset and press REDIAL soft key. To redial from a line other than primary, press line first, then press
Redial	REDIAL.
Call Forward	1. Press the CFWDALL soft key (two beeps) and enter the internal number to which you wish to forward
(to another	your calls.
extension)	2. To cancel, press the CFWDALL soft key.
Do Not Disturb	1. Press the CFwdAll softkey
_	2. Press the MESSAGES button
Viewing/Dialing	3. Press the DIRECTORIES button. Use scroll key to select MISSED CALLS.
Missed Calls	4. Press the SELECT soft key to select MISSED CALLS from the directory menu.
	5. Press the DIAL soft key to dial a number from the missed call list.
	6. To edit a number, such as adding a 9, use the Edit Dial soft key to add digits to the front of the
	number. 7. Press the EXIT soft key twice to exit the directory menu.
Viewing/Dialing	Press the EXT soft key twice to exit the directory menu. Press the DIRECTORIES button. Use scroll key to select PLACED or RECEIVED CALLS.
Placed or	Press the SELECT soft key to select either PLACED or RECEIVED CALLS. 2. Press the SELECT soft key to select either PLACED or RECEIVED CALLS from the directory menu.
	3. Press the DIAL soft key to dial a number from the list.
Received Calls	4. To edit a number, such as adding a 9, use the EditDial soft key to add digits to the front of the
	number.
	5. Press the EXIT soft key twice to exit the directory menu.
Accessing/Dialing	1. Press the DIRECTORIES button.
from the	2. Use the scroll key to select CORPORATE DIRECTORY.
Corporate	3. Press the SELECT soft key to display the directory search options.
Directory	4. Use the SCROLL key to select a search option: First or Last Name, or Extension.
2.1.000.7	5. Use the numbers corresponding to the letters on the dialing pad to enter a name or number to find it
	in the directory.
	6. Press the DIAL soft key to speed dial a number from the corporate directory.



Quick Start Guide for Cisco 7945 IP Phone

Standard Phone User Guide

Unity Voice Mail – Setup & Basic Voice Mail Functions

Voice Mail - Initial Setup

You can access your voice mailbox from your phone by pressing the "Messages" button. You will be asked to Initialize your mailbox the first time you access voice mail. Initialization includes recording your name, recording a **greeting**, and changing your password.

Your temporary password is 12345. Your new password must be at least 3 digits in length.

NOTE: Be sure to press "#" after every entry for which the system prompts you.

Basic Voice Mail Use	
To access voice mail from your	1. Press MESSAGES button.
phone:	2. Enter your password followed by the # key when prompted.
	3. Press 1 to listen to new messages, 2 to send a message, 3 to review old
	messages, or 4 to access SETUP options.
To access voice mail when away	1. Dial the main office number or your DID (skip to #3 if DID).
from the office:	2. When the auto attendant answers, dial your extension.
	3. When voice mail answers, press * key.
	4. Enter your 4 digit mailbox I.D. number (i.e., your "Extension Number")
	followed by the # key.
	5. Enter your password followed by the # key.
While listening to a message:	Press 1 to repeat, 2 to save, 3 to delete, 5 to change volume, 7 to reverse, 8 to
	pause, 9 to fast-forward, or # to go to end of message.
After a message:	Press 3 to delete, 4 to reply to internal user, 5 to forward message, 6 to mark as
	new, or 9 to hear date/timestamp.
Setup Options	
To rerecord greeting:	1. Enter mailbox.
	2. Press 4 for Setup options.
	3. Press 1 for Greetings.
	4. Press 1 to change greetings and follow prompts.
To rerecord name:	1. Enter mailbox.
	2. Press 4 for Setup options.
	3. Press 3 personal settings.
	4. Press 2 to change name and follow prompts.
To change password:	1. Enter mailbox.
	2. Press 4 for Setup options.
	3. Press 3 for Personal settings.
	4. Press 1 to change password and follow prompts.



Quick Start Guide for Cisco 7945 IP Phone Standard Phone User Guide

Ring Settings – Setup Optio	ns	
Fast Dial Options		
To Select Ring Type	1.	Press "SETTINGS" button.
	2.	Select Ring Type by highlighting and pressing "SELECT" soft key or by pressing 2.
	3.	Press "SELECT" to set default ring type -or- highlight desired extension and press "SELECT."
	4.	Scroll through list of available ring types, press "PLAY" to hear a sample, press "SELECT" to choose that ring,
	5.	After making your selection, press "OK"
	6.	Press "EXIT" twice to return to the main menu.