IFC6501 - Wireless Data Communications

Session 1: Course Overview

Daniel Febrian Sengkey

Department of Electrical Engineering Faculty of Engineering Universitas Sam Ratulangi

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

Acknowledgement

When not specifically cited, the contents of this presentation are adapted from [1].

Outline

Course Details

The Rules

Topics

Scoring System

Important Things to Consider

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

Outline

Course Details

The Rules

Topics Scoring System Important Things to Conside

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

1. You can attend the class anytime you want, but to sign the *List of Attendees* you should not come more than 15 minutes since the class started.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.
- 3. Contact me only by the means listed in this slide.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.
- 3. Contact me only by the means listed in this slide.
- If you and your friend have something to be discussed please do it outside the class, except you are assigned to do so.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.
- 3. Contact me only by the means listed in this slide.
- If you and your friend have something to be discussed please do it outside the class, except you are assigned to do so.
- 5. If you have a question, please raise your hand anytime during the class. No need to wait until the class finished.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.
- 3. Contact me only by the means listed in this slide.
- If you and your friend have something to be discussed please do it outside the class, except you are assigned to do so.
- If you have a question, please raise your hand anytime during the class. No need to wait until the class finished.
- Plagiarism in assignments will be rated as 0. If you cheating and/or plagiarizing in final test/assignment you will have 'E' as your final grade.

- You can attend the class anytime you want, but to sign the List of Attendees you should not come more than 15 minutes since the class started.
- 2. You should attend > 80% of the meetings to get the final grade.
- 3. Contact me only by the means listed in this slide.
- If you and your friend have something to be discussed please do it outside the class, except you are assigned to do so.
- 5. If you have a question, please raise your hand anytime during the class. No need to wait until the class finished.
- Plagiarism in assignments will be rated as 0. If you cheating and/or plagiarizing in final test/assignment you will have 'E' as your final grade.
- 7. You are college students, please behave with the appropriate attitude.

Outline

Course Details

The Rules

Topics

Scoring System Important Things to Consider

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

Fundamental aspects in wireless communications.

- Fundamental aspects in wireless communications.
- Wireless networks

- Fundamental aspects in wireless communications.
- ► Wireless networks
- Simulation

- Fundamental aspects in wireless communications.
- Wireless networks
- Simulation
- See attachment for more details

Outline

Course Details

The Rules

Scoring System

Important Things to Consider

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References




Figure 1 : Scoring components

▶ 3 Evaluations 70%





Figure 1 : Scoring components


- ▶ 3 Evaluations 70%
- A comprehensive Final Test 30%



Grading system follows faculty regulation:

Figure 1 : Scoring components


- 3 Evaluations 70%
- A comprehensive Final Test 30%



- Grading system follows faculty regulation:
 - ▶ $n \ge 80$ Grade = A

Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%



- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - ▶ $75 \le n < 80 \text{ Grade} = B+$

Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%




Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - 75 ≤ n < 80 Grade = B+</p>
 - ▶ 70 ≤ *n* < 75 Grade = B+




Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - 75 ≤ n < 80 Grade = B+</p>
 - ► 70 ≤ *n* < 75 Grade = B+
 - ▶ $65 \le n < 70 \text{ Grade} = B$




Figure 1: Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - 75 ≤ n < 80 Grade = B+</p>
 - ▶ $70 \le n < 75$ Grade = B+
 - ▶ $65 \le n < 70$ Grade = B
 - ▶ $60 \le n < 65 \text{ Grade} = C+$




Figure 1: Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - ▶ 75 ≤ *n* < 80 Grade = B+
 - ▶ $70 \le n < 75$ Grade = B+
 - ▶ $65 \le n < 70 \text{ Grade} = B$
 - ▶ $60 \le n < 65 \text{ Grade} = C+$
 - ▶ $55 \le n < 60$ Grade = C




Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - 75 ≤ n < 80 Grade = B+</p>
 - ► 70 ≤ *n* < 75 Grade = B+
 - ▶ $65 \le n < 70 \text{ Grade} = B$
 - ▶ $60 \le n < 65 \text{ Grade} = C+$
 - ▶ $55 \le n < 60$ Grade = C
 - ▶ $35 \le n < 55$ Grade = D




Figure 1 : Scoring components

- 3 Evaluations 70%
- A comprehensive Final Test 30%

- Grading system follows faculty regulation:
 - n ≥ 80 Grade = A
 - 75 ≤ n < 80 Grade = B+</p>
 - ▶ $70 \le n < 75 \text{ Grade} = B+$
 - ▶ $65 \le n < 70 \text{ Grade} = B$
 - ▶ 60 ≤ *n* < 65 Grade = C+
 - ▶ $55 \le n < 60 \text{ Grade} = C$
 - ▶ 35 ≤ *n* < 55 Grade = D
 - ► *n* < 35 Grade = E

Outline

Course Details

The Rules
Topics
Scoring System
Important Things to Consider

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

Important Things to Consider

We are going to use several applications and systems. Set your schedule for your self-study. It is for your own good.

Important Things to Consider

- We are going to use several applications and systems. Set your schedule for your self-study. It is for your own good.
- Simulation: OMNeT++

Important Things to Consider

- We are going to use several applications and systems. Set your schedule for your self-study. It is for your own good.
- Simulation: OMNeT++
- Statistical processing: GNU R

Outline

Course Details

Review: Data Communications and Networking
Data Communications
Networks
TCP/IP Protocol Suite

Review: Physical Layer

Exercise

References

Data Communication

Introduction

► The advancement in data communications and networking affects how we do business and the way we live.

Data Communication

Introduction

- The advancement in data communications and networking affects how we do business and the way we live.
- Business decisions have to be done quickly,

Introduction

- The advancement in data communications and networking affects how we do business and the way we live.
- Business decisions have to be done quickly, and to achieve well qualified decision the decision maker require immediate access to accurate information.

Introduction

- ► The advancement in data communications and networking affects how we do business and the way we live.
- Business decisions have to be done quickly, and to achieve well qualified decision the decision maker require immediate access to accurate information.
- Data communications also introduces e-Learning and distance learning in the education field, that makes education contents available even for the people in the remote area.

Outline

Course Details

Review: Data Communications and Networking

Data Communications

Networks

TCP/IP Protocol Suite

Review: Physical Layer

Exercise

References

Data Communications Definitions

▶ **Telecommunication**: communication at a distance.¹

Data Communications Definitions

▶ **Telecommunication**: communication at a distance.¹

¹tele means far in Greek.

- ▶ Telecommunication: communication at a distance.¹
- ▶ **Data**: information presented in whatever form is agreed upon by the parties creating and using the data.

¹tele means far in Greek.

- ▶ Telecommunication: communication at a distance.¹
- ▶ **Data**: information presented in whatever form is agreed upon by the parties creating and using the data.
- Data communication: exchange of data between two devices via some form of transmission medium.

¹tele means far in Greek.

- ▶ Telecommunication: communication at a distance.¹
- ▶ **Data**: information presented in whatever form is agreed upon by the parties creating and using the data.
- Data communication: exchange of data between two devices via some form of transmission medium.
- Communication system: combination of hardwares and softwares used in data communication.

¹tele means far in Greek.

- ▶ Telecommunication: communication at a distance.¹
- ▶ **Data**: information presented in whatever form is agreed upon by the parties creating and using the data.
- Data communication: exchange of data between two devices via some form of transmission medium.
- Communication system: combination of hardwares and softwares used in data communication. The communicating parties in data communication are parts of a communication system.

¹ tele means far in Greek.

Fundamental Characteristics

Delivery

Fundamental Characteristics

- Delivery
- Accuracy

Fundamental Characteristics

- Delivery
- Accuracy
- ► Timeliness

Fundamental Characteristics

- Delivery
- Accuracy
- ▶ Timeliness
- Jitter

Outline

Course Details

Review: Data Communications and Networking

Data Communications

Networks

TCP/IP Protocol Suite

Review: Physical Layer

Exercise

References

▶ Interconnection of a set of devices capable of communication.

- ▶ Interconnection of a set of devices capable of communication.
- A device can be:

- Interconnection of a set of devices capable of communication.
- A device can be:
 - ▶ Host (an end system) such as workstation, server, and PC.

- Interconnection of a set of devices capable of communication.
- A device can be:
 - Host (an end system) such as workstation, server, and PC.
 - Connecting device such as router, switch, and bridge.

Criteria

Performance

Networks Criteria

- Performance
- Reliability

Criteria

- Performance
- Reliability
- Security

Criteria: Performance

Can be measured in many ways, such as:

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - ► The *elapsed time* between an inquiry and a response,

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - ► The *elapsed time* between an inquiry and a response,known as **Response Time**.

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:
 - Number of users

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:
 - Number of users
 - Type of transmission medium

- Can be measured in many ways, such as:
 - The amount of time required for a message to travel from one device to another,known as Transit Time.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:
 - Number of users
 - Type of transmission medium
 - Capabilities of connected hardware

- Can be measured in many ways, such as:
 - ► The amount of time required for a message to travel from one device to another,known as **Transit Time**.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:
 - Number of users
 - Type of transmission medium
 - Capabilities of connected hardware
 - Software efficiency

- Can be measured in many ways, such as:
 - The amount of time required for a message to travel from one device to another,known as Transit Time.
 - The elapsed time between an inquiry and a response, known as Response Time.
- Depends on a number of factors, such as:
 - Number of users
 - Type of transmission medium
 - Capabilities of connected hardware
 - Software efficiency
- Oftenly evaluated in throughput and delay.

Criteria: Reliability

Measured by:

Criteria: Reliability

- Measured by:
 - Frequency of failure

Criteria: Reliability

- Measured by:
 - Frequency of failure
 - Required time for recovery from a failure

Criteria: Reliability

- Measured by:
 - Frequency of failure
 - Required time for recovery from a failure
 - Robustness during a catastrophe

Criteria: Security

Protecting data from damage and development

Criteria: Security

- Protecting data from damage and development
- Protecting data from unauthorized access

Criteria: Security

- Protecting data from damage and development
- Protecting data from unauthorized access
- Implementing policies and procedures for recovery from breaches and data losses

Physical Structures

Type of Connection

Physical Structures

- ► Type of Connection
- Physical Topology

Physical Structures: Type of Connection - Point-to-Point




Figure 2 : Point-to-Point connection.

Point-to-Point connection provides a dedicated link between two devices.

Physical Structures: Type of Connection - Point-to-Point




Figure 2 : Point-to-Point connection.

- Point-to-Point connection provides a dedicated link between two devices.
- ► Entire link capacity is reserved for transmission between those devices.

Physical Structures: Type of Connection - Multipoint




Figure 3: Multipoint connection.

Multipoint connection_i+-¿also known as multidrop connection. shares a single link to be used by multiple devices.

Physical Structures: Type of Connection - Multipoint




Figure 3: Multipoint connection.

- Multipoint connection_{i+-¿also} known as multidrop connection. shares a single link to be used by multiple devices.
- The link capacity is shared, either spatially or temporally.

Networks Physical Structures: Physical Topology

Physical topology refers to the way in which a network is laid out physically.

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.

²usually called nodes

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.
- Basically there are four topologies:

²usually called nodes

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.
- Basically there are four topologies:
 - Bus

²usually called nodes

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.
- Basically there are four topologies:
 - Bus
 - Ring

²usually called nodes

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.
- Basically there are four topologies:
 - Bus
 - Ring
 - Star

²usually called nodes

- Physical topology refers to the way in which a network is laid out physically.
- The topology of a network is the geometric representation of the relationship of all the links and linking devices² to one another.
- Basically there are four topologies:
 - Bus
 - Ring
 - Star
 - Mesh

²usually called nodes

Physical Structures: Physical Topology - Bus




Figure 4 : Bus topology with three stations

Used in the early local-area networks.




Figure 4: Bus topology with three stations

- Used in the early local-area networks.
- In bus topology, a single cable act as a backbone to link all the devices.




Figure 4: Bus topology with three stations

- Used in the early local-area networks.
- In bus topology, a single cable act as a backbone to link all the devices.
- Nodes are connected to the bus cable by drop lines and taps.




Figure 4: Bus topology with three stations

- Used in the early local-area networks.
- In bus topology, a single cable act as a backbone to link all the devices.
- Nodes are connected to the bus cable by drop lines and taps.
- The number of supported taps, and distances between taps are limited.

Physical Structures: Physical Topology - Bus

Advantages:

- Advantages:
 - Requires less cabling than the other topologies.

- Advantages:
 - Requires less cabling than the other topologies.
 - Redundancy is eliminated.

- Advantages:
 - Requires less cabling than the other topologies.
 - Redundancy is eliminated.
- Disadvantages:

- Advantages:
 - Requires less cabling than the other topologies.
 - Redundancy is eliminated.
- Disadvantages:
 - Difficult reconnection and fault isolation

- Advantages:
 - Requires less cabling than the other topologies.
 - Redundancy is eliminated.
- Disadvantages:
 - Difficult reconnection and fault isolation
 - Signal degradation due to reflection at the taps.

- Advantages:
 - Requires less cabling than the other topologies.
 - Redundancy is eliminated.
- Disadvantages:
 - Difficult reconnection and fault isolation
 - Signal degradation due to reflection at the taps.
 - A single fault stops all transmission.




Figure 5: Ring topology with four stations

Physical Structures: Physical Topology - Ring

Each device has a dedicated point-to-point connection with only two devices on either side of it.

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.
- Advantages:

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.
- Advantages:
 - Easy to install and reconfigure

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.
- Disadvantage:

- Each device has a dedicated point-to-point connection with only two devices on either side of it.
- Signal is passed along the ring in one direction, until the destination reached.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.
- Disadvantage:
 - Unidirectional traffic can be a disadvantage. A break in can disable entire network.




Figure 6: Star topology with five stations

Physical Structures: Physical Topology - Star

Each device has a dedicated point-to-point connection only to a central controller.

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:
 - Easy to install and reconfigure

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.
 - Robustness

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.
 - Robustness
- Disadvantage:

- Each device has a dedicated point-to-point connection only to a central controller.
- Data are sent to the controller which then relays the data to the other connected devices.
- Advantages:
 - Easy to install and reconfigure
 - Fault isolation is simplified.
 - Robustness
- Disadvantage:
 - If the hub down, whole network is dead.




Figure 7: Mesh topology with five stations

Physical Structures: Physical Topology - Mesh

► Each device has a dedicated point-to-point connection to every other device.

- ► Each device has a dedicated point-to-point connection to every other device.
- Advantages:

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.
 - Robustness

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.
 - Robustness
 - Privacy and security

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.
 - Robustness
 - Privacy and security
 - Easy fault identification and isolation

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.
 - Robustness
 - Privacy and security
 - Easy fault identification and isolation
- Disadvantage:

- Each device has a dedicated point-to-point connection to every other device.
- Advantages:
 - Each dedicated links guarantees that each connection can carry its own data load.
 - Robustness
 - Privacy and security
 - Easy fault identification and isolation
- Disadvantage:
 - Requires n(n-1)/2 duplex mode links and in each device n-1 I/O ports. n represents the number of nodes.

Local Area Network (LAN)

- Local Area Network (LAN)
- ▶ Wide Area Network

- Local Area Network (LAN)
- Wide Area Network
 - Point-to-point WAN

- Local Area Network (LAN)
- Wide Area Network
 - Point-to-point WAN
 - Switched WAN

- Local Area Network (LAN)
- Wide Area Network
 - Point-to-point WAN
 - Switched WAN
- Internetwork (network of networks)

► An internet is a switched network³.

► An internet is a switched network³.

³Do not mix the term with the hardware switch.

- ► An internet is a switched network³.
- The term comes from the data that being switched from node to node in the network.

³Do not mix the term with the hardware switch.

- An internet is a switched network³.
- The term comes from the data that being switched from node to node in the network.
- The most common types of switched networks are:

³Do not mix the term with the hardware switch.

- ► An internet is a switched network³.
- The term comes from the data that being switched from node to node in the network.
- ► The most common types of switched networks are:
 - Circuit-switched network (e.g. POTS)

³Do not mix the term with the hardware switch.

- An internet is a switched network³.
- The term comes from the data that being switched from node to node in the network.
- The most common types of switched networks are:
 - Circuit-switched network (e.g. POTS)
 - Packet-switched network

³Do not mix the term with the hardware switch.

An internet is a switched network³.

- The term comes from the data that being switched from node to node in the network.
- The most common types of switched networks are:
 - Circuit-switched network (e.g. POTS)
 - Packet-switched network
 - Datagram

³Do not mix the term with the hardware switch.

An internet is a switched network³.

- The term comes from the data that being switched from node to node in the network.
- The most common types of switched networks are:
 - Circuit-switched network (e.g. POTS)
 - Packet-switched network
 - Datagram
 - Virtual Circuit switching

³Do not mix the term with the hardware switch.




Figure 8 : A simplified model of the Internet.

The Internet

▶ The **Internet** is the most notable internet.

- ▶ The **Internet** is the most notable internet.
- ► The interconnections between service providers, institutions (universities, corporation network) build the Internet.

- The Internet is the most notable internet.
- ► The interconnections between service providers, institutions (universities, corporation network) build the Internet.
- ➤ To gain access to the Internet, the LANs should have a connection to the service provider network.

- The Internet is the most notable internet.
- ► The interconnections between service providers, institutions (universities, corporation network) build the Internet.
- ➤ To gain access to the Internet, the LANs should have a connection to the service provider network.
- Later, the networks of the service providers are connected to the Backbone Network.

Accessing The Internet

Using telephone networks

- Using telephone networks
 - ► Dial-up service

- Using telephone networks
 - Dial-up service
 - DSL Service

- Using telephone networks
 - Dial-up service
 - DSL Service
- Using cable networks

- Using telephone networks
 - Dial-up service
 - DSL Service
- Using cable networks
- Using wireless networks

- Using telephone networks
 - Dial-up service
 - DSL Service
- Using cable networks
- Using wireless networks
- Direct connection to the Internet

Outline

Course Details

Review: Data Communications and Networking

Data Communications

Networks

TCP/IP Protocol Suite

Review: Physical Layer

Exercise

References

Transmission Control Protocol/Internet Protocol (TCP/IP) is the de facto protocol suite that runs in the Internet today.

- Transmission Control Protocol/Internet Protocol (TCP/IP) is the de facto protocol suite that runs in the Internet today.
- Protocol suite is a set of protocols organized in different layers.

- Transmission Control Protocol/Internet Protocol (TCP/IP) is the de facto protocol suite that runs in the Internet today.
- Protocol suite is a set of protocols organized in different layers.
- TCP/IP is a hierarchical protocol consists of interactive modules, where each module provides a specific functionality.

- Transmission Control Protocol/Internet Protocol (TCP/IP) is the de facto protocol suite that runs in the Internet today.
- Protocol suite is a set of protocols organized in different layers.
- TCP/IP is a hierarchical protocol consists of interactive modules, where each module provides a specific functionality.
- Hierarchical means an upper layer protocol is supported by the services provided by one or more lower level protocols.

- Transmission Control Protocol/Internet Protocol (TCP/IP) is the de facto protocol suite that runs in the Internet today.
- Protocol suite is a set of protocols organized in different layers.
- TCP/IP is a hierarchical protocol consists of interactive modules, where each module provides a specific functionality.
- Hierarchical means an upper layer protocol is supported by the services provided by one or more lower level protocols.
- Originally TCP/IP suite was defined as four software layers built upon the hardware, but in present condition it is considered as five-layer model.

Layers

▶ The layers⁴ in the TCP/IP Protocol Suite are:

Layers

► The layers⁴ in the TCP/IP Protocol Suite are:

⁴In the present consideration

- ► The layers⁴ in the TCP/IP Protocol Suite are:
 - 1. Physical

⁴In the present consideration

- ► The layers⁴ in the TCP/IP Protocol Suite are:
 - 1. Physical
 - 2. Data link

⁴In the present consideration

- ► The layers⁴ in the TCP/IP Protocol Suite are:
 - 1. Physical
 - 2. Data link
 - 3. Network

⁴In the present consideration

- ▶ The layers⁴ in the TCP/IP Protocol Suite are:
 - 1. Physical
 - 2. Data link
 - 3. Network
 - 4. Transport

⁴In the present consideration

- ► The layers⁴ in the TCP/IP Protocol Suite are:
 - 1. Physical
 - 2. Data link
 - 3. Network
 - 4. Transport
 - 5. Application

⁴In the present consideration

Object in Each Layer

Table 1 : Objects in the TCP/IP Protocol Suite

Layer	Object
Physical	Bits
Data link	Frames
Networks	Datagrams
Transport	Segments or User Datagrams
Application	Messages

Physical Layer

Responsible for carrying individual bits in a frame across the link.

Physical Layer

- Responsible for carrying individual bits in a frame across the link.
- Although physical layer is the lowest layer in the suite, there is still another layer: the transmission medium.

Physical Layer

- Responsible for carrying individual bits in a frame across the link.
- Although physical layer is the lowest layer in the suite, there is still another layer: the transmission medium.
- Devices are physically connected by the transmission medium, but it carries signals not bits.

Physical Layer

- Responsible for carrying individual bits in a frame across the link.
- Although physical layer is the lowest layer in the suite, there is still another layer: the transmission medium.
- Devices are physically connected by the transmission medium, but it carries signals not bits.
- Physical layer handles the bits-to-signals and signals-to-bit transformation.

Data link Layer

Data link handles data communication within the same link.

Data link Layer

- Data link handles data communication within the same link.
- Data link takes the datagram from network layer and moving it across the link.

Data link Layer

- Data link handles data communication within the same link.
- Data link takes the datagram from network layer and moving it across the link.
- No specific protocol defined for this layer, so it supports all standard and proprietary protocols.

Data link Layer

- Data link handles data communication within the same link.
- Data link takes the datagram from network layer and moving it across the link.
- No specific protocol defined for this layer, so it supports all standard and proprietary protocols.
- Several protocols provide complete error detection and correction, some only provide error correction.

Network Layer

Network layer is responsible for creating a host-to-host connection between source and destination.

Network Layer

- Network layer is responsible for creating a host-to-host connection between source and destination.
- The source and destination may located in different networks.

Network Layer

- Network layer is responsible for creating a host-to-host connection between source and destination.
- The source and destination may located in different networks.
- Routers work in this layer, and responsible to choose the best route for each packet.

Network Layer

- Network layer is responsible for creating a host-to-host connection between source and destination.
- The source and destination may located in different networks.
- Routers work in this layer, and responsible to choose the best route for each packet.
- Network layer includes the main main protocol: Internet Protocol (IP).

Transport Layer

► Transport layer provides end-to-end connection.

Transport Layer

- ► Transport layer provides end-to-end connection.
- Transport layer at the source hosts:

Transport Layer

- Transport layer provides end-to-end connection.
- Transport layer at the source hosts:
 - Takes message from application layer,

Transport Layer

- Transport layer provides end-to-end connection.
- Transport layer at the source hosts:
 - Takes message from application layer,
 - Encapsulates it in a segment or user datagram,

Transport Layer

- Transport layer provides end-to-end connection.
- Transport layer at the source hosts:
 - Takes message from application layer,
 - Encapsulates it in a segment or user datagram,
 - and sends it through the logical connection to the transport layer at the destination host.

Transport Layer

- Transport layer provides end-to-end connection.
- Transport layer at the source hosts:
 - Takes message from application layer,
 - Encapsulates it in a segment or user datagram,
 - and sends it through the logical connection to the transport layer at the destination host.
- ► In other words the transport layer is responsible for giving services to the application layer:

Transport Layer

- Transport layer provides end-to-end connection.
- Transport layer at the source hosts:
 - Takes message from application layer,
 - Encapsulates it in a segment or user datagram,
 - and sends it through the logical connection to the transport layer at the destination host.
- In other words the transport layer is responsible for giving services to the application layer: to get a message from an application running at the source host and deliver it to the corresponding application program on the destination host.

Application Layer

Two application layers exchange messages between each other as though there were a bridge between the two layers⁵.

⁵Keep in mind that the communication goes through all layers.

Application Layer

- Two application layers exchange messages between each other as though there were a bridge between the two layers⁵.
- ► The communication is between two *processes* (programs) running at this layer.

⁵Keep in mind that the communication goes through all layers.

Application Layer

- Two application layers exchange messages between each other as though there were a bridge between the two layers⁵.
- ► The communication is between two *processes* (programs) running at this layer.
- ► To communicate, a process sends a request to the process at the other host and receives a response.

⁵Keep in mind that the communication goes through all layers.

Layered Architecture Operation




Figure 9: Encapsulation and decapsulation concept

Layered Architecture Operation




Figure 10: Data communication in layered architecture.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments
Data Bate Limits

Data Rate Limit

Performance

Exercise

References

Physical Layer

Introduction

Physical layer is responsible to move data in form of electronic signals across transmission medium.

Physical Layer

Introduction

- Physical layer is responsible to move data in form of electronic signals across transmission medium.
- Physical layer sits between the transmission medium and the rest of the communicating device.

Physical Layer

Introduction

- Physical layer is responsible to move data in form of electronic signals across transmission medium.
- Physical layer sits between the transmission medium and the rest of the communicating device.
- First, let us discuss the medium.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer Transmission Medium

Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments
Data Rate Limits
Performance

Exercise

References

In data communication, nodes are always connected by physical path.

- In data communication, nodes are always connected by physical path.
- ► This physical path is known as <u>transmission medium</u>.

- In data communication, nodes are always connected by physical path.
- ► This physical path is known as transmission medium.
- Transmission medium connects the receiver and the transmitter.

- In data communication, nodes are always connected by physical path.
- ► This physical path is known as <u>transmission medium</u>.
- Transmission medium connects the receiver and the transmitter.
- Electromagnetic wave is the element that being transmitted between connected parties.

Forms of Transmission Medium

Guided Media: electromagnetic waves are guided along a solid medium, such as copper twisted pair, copper coaxial cable, or optical fiber.

Forms of Transmission Medium

- Guided Media: electromagnetic waves are guided along a solid medium, such as copper twisted pair, copper coaxial cable, or optical fiber.
- Unguided Media: the transmission occurs through the atmosphere, outer space, or water.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium

Data and Signals

Analog and Digital Data Analog and Digital Signals

Periodic and Nonperiodic Signals

Periodic Analog Signals

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Data communications is referring to data exchange between a source and a destination.

- Data communications is referring to data exchange between a source and a destination.
- ► At the physical layer, data communications means exchanging signals.

- Data communications is referring to data exchange between a source and a destination.
- At the physical layer, data communications means exchanging signals.
- The data were converted into signals so they could be transmitted via the transmission medium.

- Data communications is referring to data exchange between a source and a destination.
- At the physical layer, data communications means exchanging signals.
- The data were converted into signals so they could be transmitted via the transmission medium.
- The form of the signals could be analog or digital.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium

Data and Signals

Analog and Digital Data

Analog and Digital Signals

Periodic and Nonperiodic Signals

Periodic Analog Signals

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Analog Data: continuous information.

- Analog Data: continuous information.
- Example: sounds made by human voice.

- Analog Data: continuous information.
- Example: sounds made by human voice.
- Digital Data: discrete information.

- Analog Data: continuous information.
- Example: sounds made by human voice.
- Digital Data: discrete information.
- Example: the data stored in computer memory in binary form.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium

Data and Signals

Analog and Digital Data

Analog and Digital Signals

Periodic and Nonperiodic Signals

Periodic Analog Signals

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Signals also can be analog or digital, like the data they represent.

- Signals also can be analog or digital, like the data they represent.
- An analog signal has infinitely many levels of intensity over a period of time.

- Signals also can be analog or digital, like the data they represent.
- An analog signal has infinitely many levels of intensity over a period of time.
- On the contrary, a digital signal can only has a limited number of defined values.

- Signals also can be analog or digital, like the data they represent.
- An analog signal has infinitely many levels of intensity over a period of time.
- On the contrary, a digital signal can only has a limited number of defined values.
- Figure 11 shows an example of analog signal plotted on a pair of perpendicular axes. Figure 12 shows the plot of digital signal.

Example of Analog Signal




Figure 11: Analog signal

Example of Digital Signal




Figure 12 : Digital signal

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium

Data and Signals

Analog and Digital Data Analog and Digital Signals

Periodic and Nonperiodic Signals

Periodic Analog Signals Digital Signals Transmission Impairments Data Rate Limits

Exercise

References

Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.

- Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.
- A periodic signal completes a patter within a measurable time frame, called a <u>period</u>.

- Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.
- A periodic signal completes a patter within a measurable time frame, called a <u>period</u>.
- The pattern repeated over subsequent identical periods.

- Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.
- A periodic signal completes a patter within a measurable time frame, called a <u>period</u>.
- The pattern repeated over subsequent identical periods.
- A full pattern is known as a <u>cycle</u>.

- Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.
- A periodic signal completes a patter within a measurable time frame, called a period.
- The pattern repeated over subsequent identical periods.
- A full pattern is known as a cycle.
- On the other hand, a nonperiodic signal changes without exhibiting a pattern or cycle that repeats over time.

- Both types of signals can take one of two forms: <u>periodic</u> or <u>nonperiodic</u> signal.
- A periodic signal completes a patter within a measurable time frame, called a period.
- The pattern repeated over subsequent identical periods.
- A full pattern is known as a cycle.
- On the other hand, a nonperiodic signal changes without exhibiting a pattern or cycle that repeats over time.
- In data communication we <u>commonly</u> use periodic analog signals and nonperiodic digital signals.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals

Periodic Analog Signals

Sine Wave

Composite Signals

Bandwidth

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Periodic Analog Signals

Periodic signals can be classified as simple or composite.

Periodic Analog Signals

- Periodic signals can be classified as simple or composite.
- ▶ A composite signal is composed of multiple simple signals.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals

Periodic Analog Signals

Sine Wave

Composite Signals
Bandwidth

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

A sine wave has three parameters:

- A sine wave has three parameters:
 - ► Peak amplitude (A)

- A sine wave has three parameters:
 - ▶ Peak amplitude (A)
 - ► Frequency (f)

- A sine wave has three parameters:
 - ▶ Peak amplitude (A)
 - ► Frequency (f)
 - Phase (φ)

- A sine wave has three parameters:
 - ► Peak amplitude (*A*)
 - Frequency (f)
 - Phase (φ)
- Figure 13 shows two signals with the same phase and frequency, but different amplitudes.




Figure 13: Two sine waves, with different amplitude.

Parameters [2]

► Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).

- Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).
- ▶ Period (*T*) is the amount of time needed for one repetition.

- Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).
- ▶ Period (*T*) is the amount of time needed for one repetition.
- The relation between frequency and period can be mathematically expressed as:

- Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).
- ▶ Period (*T*) is the amount of time needed for one repetition.
- The relation between frequency and period can be mathematically expressed as:

$$T = \frac{1}{f} \Leftrightarrow f = \frac{1}{T} \tag{1}$$

Parameters [2]

- Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).
- ▶ Period (*T*) is the amount of time needed for one repetition.
- The relation between frequency and period can be mathematically expressed as:

$$T = \frac{1}{f} \Leftrightarrow f = \frac{1}{T} \tag{1}$$

Phase (ϕ) is a measure of relative position in time within a single period of signal.

- Frequency (f) is the rate at which the signal repeats. It is measured as cycle(s) per second, or Hertz (Hz).
- ▶ Period (*T*) is the amount of time needed for one repetition.
- The relation between frequency and period can be mathematically expressed as:

$$T = \frac{1}{f} \Leftrightarrow f = \frac{1}{T} \tag{1}$$

- Phase (ϕ) is a measure of relative position in time within a single period of signal.
- ► Peak amplitude (A) is the maximum value or strength of the signal over time. Typically measured in volts.

Sine Wave Parameters [2]

 Sine wave is mathematically expressed as

$$s(t) = A \cdot \sin(2\pi f t + \phi) \quad (2)$$

Sine Wave Parameters [2]

 Sine wave is mathematically expressed as

$$s(t) = A \cdot \sin(2\pi f t + \phi) \quad (2)$$

with t as time, measured in seconds.

Parameters [2]

 Sine wave is mathematically expressed as

$$s(t) = A \cdot \sin(2\pi f t + \phi) \quad (2)$$

with t as time, measured in seconds.




Figure 14 : Plot of sine waves with f = 1, A = 1, and various values of ϕ .




Figure 15: Sine waves of various frequencies and amplitudes.

Sine Wave Wavelength

▶ Wavelength (λ) binds the period (T) or the frequency (f) of a sine wave to the propagation speed of the medium.

Sine Wave Wavelength

- ▶ Wavelength (λ) binds the period (T) or the frequency (f) of a sine wave to the propagation speed of the medium.
- Wavelength is the distance a simple signal can travel in one period.

Sine Wave Wavelength

- ▶ Wavelength (λ) binds the period (T) or the frequency (f) of a sine wave to the propagation speed of the medium.
- Wavelength is the distance a simple signal can travel in one period.
- Wavelength calculated as propagation speed in the medium (v) multiplied with period (T).

Wavelength

- ▶ Wavelength (λ) binds the period (T) or the frequency (f) of a sine wave to the propagation speed of the medium.
- Wavelength is the distance a simple signal can travel in one period.
- Wavelength calculated as propagation speed in the medium (v) multiplied with period (T).

$$\lambda = v \times T \tag{3}$$

Wavelength

▶ Since
$$T = \frac{1}{f}$$
 then

Wavelength

▶ Since
$$T = \frac{1}{f}$$
 then

$$\lambda = \frac{v}{f}$$

Wavelength

▶ Since $T = \frac{1}{f}$ then

$$\lambda = \frac{v}{f}$$

► Therefore for electromagnetic signal in vacuum it becomes:

$$\lambda = \frac{c}{f} \tag{4}$$

Wavelength

► Since $T = \frac{1}{f}$ then

$$\lambda = \frac{v}{f}$$

Therefore for electromagnetic signal in vacuum it becomes:

$$\lambda = \frac{c}{f} \tag{4}$$

• with $c \approx 3 \times 10^8$ m/s, which is known as the speed of light in vacuum.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals

Periodic Analog Signals

Sine Wave

Composite Signals

Bandwidth

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Simple sine waves have many applications in daily life (e.g. in electricity).

- Simple sine waves have many applications in daily life (e.g. in electricity).
- However, in data communications, a single sine wave carries no information.

- Simple sine waves have many applications in daily life (e.g. in electricity).
- However, in data communications, a single sine wave carries no information.
- ► To communicate data, we need a composite signals.

- Simple sine waves have many applications in daily life (e.g. in electricity).
- However, in data communications, a single sine wave carries no information.
- To communicate data, we need a composite signals.
- According to Fourier analysis, any composite signal is a combination of simple sine waves with different frequencies, amplitudes, and phases.




Figure 16 : Simple sine waves and a composite signal.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals

Periodic Analog Signals

Sine Wave Composite Signals

Bandwidth

Digital Signals Transmission Impairments Data Rate Limits

Exercise

References

▶ Bandwith (*B*) is the range of frequencies in a composite signals.

- ▶ Bandwith (*B*) is the range of frequencies in a composite signals.
- Commonly, it is a difference between two numbers, the highest and the lowest frequencies.

- ▶ Bandwith (*B*) is the range of frequencies in a composite signals.
- Commonly, it is a difference between two numbers, the highest and the lowest frequencies.
- It is mathematically expressed as⁶

$$B = f_{max} - f_{min} \tag{5}$$

- ▶ Bandwith (*B*) is the range of frequencies in a composite signals.
- Commonly, it is a difference between two numbers, the highest and the lowest frequencies.
- ▶ It is mathematically expressed as⁶

$$B = f_{max} - f_{min} \tag{5}$$

⁶Forouzan uses f_h and f_l for the highest and the lowest frequencies, respectively.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Data and Signals
Periodic Analog Signals

Digital Signals

Bit Rate

Bit Length

Transmission of Digital Signals

Transmission Impairments Data Rate Limits

Performance

Exercise

References

Digital signal consists of 0 and 1.

- Digital signal consists of 0 and 1.
- ► The binary digits can be encoded by using different voltages.

- Digital signal consists of 0 and 1.
- ► The binary digits can be encoded by using different voltages.
- A digital signal can have more than two levels, which in each level we can send more than a single bit.

- Digital signal consists of 0 and 1.
- ► The binary digits can be encoded by using different voltages.
- ► A digital signal can have more than two levels, which in each level we can send more than a single bit.
- ► Figure 17 shows two digital signals with different levels.

- Digital signal consists of 0 and 1.
- The binary digits can be encoded by using different voltages.
- ► A digital signal can have more than two levels, which in each level we can send more than a single bit.
- ► Figure 17 shows two digital signals with different levels.
 - ► The first signal (a) has two levels, 1 bit per level.

- Digital signal consists of 0 and 1.
- The binary digits can be encoded by using different voltages.
- A digital signal can have more than two levels, which in each level we can send more than a single bit.
- Figure 17 shows two digital signals with different levels.
 - ► The first signal (a) has two levels, 1 bit per level.
 - The second signal (b) has four levels, 2 bits per level.

Levels




Figure 17: Two digital signals with different levels.

The relationship between levels and bits is mathematically expressed as

The relationship between levels and bits is mathematically expressed as

Number of bits per level =
$$\log_2 L$$
 (6)

 The relationship between levels and bits is mathematically expressed as

Number of bits per level =
$$\log_2 L$$
 (6)

where L is the number of levels of a signal.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Data and Signals
Periodic Analog Signals

Digital Signals

Bit Rate

Bit Length

Iransmission of Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Exercise

References

Period and frequency are not the appropriate characteristics for digital signals since most of them are nonperiodic.

- Period and frequency are not the appropriate characteristics for digital signals since most of them are nonperiodic.
- Therefore <u>bit rate</u> is used to describe digital signals instead of period or frequency.

- Period and frequency are not the appropriate characteristics for digital signals since most of them are nonperiodic.
- Therefore <u>bit rate</u> is used to describe digital signals instead of period or frequency.
- Bit rate is the number of bits sent in a second, hence the unit is <u>bits per second</u> (bps).

- Period and frequency are not the appropriate characteristics for digital signals since most of them are nonperiodic.
- Therefore <u>bit rate</u> is used to describe digital signals instead of period or frequency.
- Bit rate is the number of bits sent in a second, hence the unit is bits per second (bps).
- In Figure 17, the bit rate of the first signal is 8 bps while the second signal has 16 bps.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Data and Signals
Periodic Analog Signals

Digital Signals

Bit Rate

Bit Length

Transmission of Digital Signals
Transmission Impairments
Data Rate Limits

Exercise

References

▶ Bit length is in place of wavelength for the digital signal.

- ▶ Bit length is in place of wavelength for the digital signal.
- Bit length is the distance one bits occupies on the transmission medium.

- ▶ **Bit length** is in place of wavelength for the digital signal.
- Bit length is the distance one bits occupies on the transmission medium.
- Bit length is mathematically expressed as

- ▶ Bit length is in place of wavelength for the digital signal.
- Bit length is the distance one bits occupies on the transmission medium.
- Bit length is mathematically expressed as

Bit length = propagation speed
$$\times$$
 bit duration (7)

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Data and Signals
Periodic Analog Signals

Digital Signals

Bit Rate
Bit Length

Transmission of Digital Signals

Transmission Impairments
Data Rate Limits
Performance

Exercise

References

Transmission of Digital Signals

•	There are two	approaches	to	transmit	a	digital	signa	d:

Transmission of Digital Signals

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.

Transmission of Digital Signals

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.
 - Broadband transmission: sending digital signal by changing it to an analog signal⁷.

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.
 - Broadband transmission: sending digital signal by changing it to an analog signal⁷.

⁷The signal is *modulated*.

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.
 - ▶ Broadband transmission: sending digital signal by changing it to an analog signal⁷.
- Baseband transmission needs a low-pass channel, which has a bandwidth that starts from zero.

⁷The signal is *modulated*.

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.
 - Broadband transmission: sending digital signal by changing it to an analog signal⁷.
- Baseband transmission needs a low-pass channel, which has a bandwidth that starts from zero.
- On the other hand broadband transmission, by utilizing modulation, uses a bandpass channel, which the bandwidth does not start from zero.

⁷The signal is *modulated*.

- There are two approaches to transmit a digital signal:
 - Baseband transmission: sending digital signal without changing it to an analog signal.
 - Broadband transmission: sending digital signal by changing it to an analog signal⁷.
- Baseband transmission needs a low-pass channel, which has a bandwidth that starts from zero.
- On the other hand broadband transmission, by utilizing modulation, uses a bandpass channel, which the bandwidth does not start from zero.
- ▶ Due to the requirements, bandpass channel is more available than the low-pass channel.

⁷The signal is *modulated*.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals

Transmission Impairments

Attenuation Distortion Noise

Data Rate Limits Performance

Exercise

References

Received signal may be different from transmitted signal.

- Received signal may be different from transmitted signal.
- ► The cause is the signal suffers transmission impairments.

- Received signal may be different from transmitted signal.
- ► The cause is the signal suffers transmission impairments.
- In analog signal, the quality may be deteriorated.

- Received signal may be different from transmitted signal.
- ► The cause is the signal suffers transmission impairments.
- In analog signal, the quality may be deteriorated.
- In digital signal, there can be bit transformation: 1 received as 0 or vice versa.

- Received signal may be different from transmitted signal.
- ► The cause is the signal suffers transmission impairments.
- In analog signal, the quality may be deteriorated.
- In digital signal, there can be bit transformation: 1 received as 0 or vice versa.
- The causes of impairment are attenuation, distortion, and noise.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals

Transmission Impairments

Attenuation

Distortion Noise a Rate Lim

Performance

Exercise

References




Figure 18: Illustration of attenuation.

Attenuation means <u>a loss of energy</u>.




Figure 18: Illustration of attenuation.

- Attenuation means a loss of energy.
- ► To show whether the signal has gain or loss strength, engineers use the unit of **decibel**.

▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:

- ▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:
 - dB < 0 means attenuation.

- ▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:
 - dB < 0 means attenuation.
 - ▶ dB > 0 means amplification.

- ▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:
 - ▶ dB < 0 means attenuation.</p>
 - ▶ dB > 0 means amplification.
- Attenuation in decibel is mathematically expressed as

- ▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:
 - \rightarrow dB < 0 means attenuation.
 - ▶ dB > 0 means amplification.
- Attenuation in decibel is mathematically expressed as

$$dB = 10 \log_{10} \frac{P_2}{P_1} \tag{8}$$

- ▶ Decibel (*dB*) measures relative strength between two signals, or one signal at two different locations. Note that:
 - ▶ dB < 0 means attenuation.</p>
 - ▶ dB > 0 means amplification.
- Attenuation in decibel is mathematically expressed as

$$dB = 10 \log_{10} \frac{P_2}{P_1} \tag{8}$$

▶ P₁ and P₂ are the powers of a signal at locations 1 and 2, respectively.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals

Transmission Impairments

Attenuation

Distortion

Noise

Data Rate Limits

Performance

Exercise

References

▶ Distortion means the signal changes in for or shape.

- Distortion means the signal changes in for or shape.
- Distortion can occur in a composite signal that consists of several frequencies.

- Distortion means the signal changes in for or shape.
- Distortion can occur in a composite signal that consists of several frequencies.
- Each signal component has its own propagation speed through a medium.

- Distortion means the signal changes in for or shape.
- Distortion can occur in a composite signal that consists of several frequencies.
- Each signal component has its own propagation speed through a medium.
- Different propagation speeds cause variance of delay. It means each component arrived at different time.

- Distortion means the signal changes in for or shape.
- Distortion can occur in a composite signal that consists of several frequencies.
- Each signal component has its own propagation speed through a medium.
- Different propagation speeds cause variance of delay. It means each component arrived at different time.
- In other words, the received signal has different phases from the transmitted signal.




Figure 19: Distortion affecting the received signals.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals

Transmission Impairments

Distortion Noise

Noise

Data Rate Limits
Performance

Exercise

References




Figure 20 : Noise effect.

► Thermal noise




Figure 20 : Noise effect.

- ► Thermal noise
- Induced noise




Figure 20 : Noise effect.

- ► Thermal noise
- ► Induced noise
- Crosstalk




Figure 20 : Noise effect.

- Thermal noise
- ► Induced noise
- Crosstalk
- Impulse noise

Signal-to-noise-ratio (SNR) is the ratio between signal power to the noise power. SNR is mathematically expressed as

Signal-to-noise-ratio (SNR) is the ratio between signal power to the noise power. SNR is mathematically expressed as

$$SNR = \frac{\text{signal power}}{\text{noise power}}$$
 (9)

 Signal-to-noise-ratio (SNR) is the ratio between signal power to the noise power. SNR is mathematically expressed as

$$SNR = \frac{\text{signal power}}{\text{noise power}}$$
 (9)

 Since SNR is the ratio between two powers, then it is often described in decibel units SNR_{dB}, defined as

 Signal-to-noise-ratio (SNR) is the ratio between signal power to the noise power. SNR is mathematically expressed as

$$SNR = \frac{\text{signal power}}{\text{noise power}}$$
 (9)

 Since SNR is the ratio between two powers, then it is often described in decibel units SNR_{dR}, defined as

$$SNR_{dB} = 10log_{10}SNR \tag{10}$$

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals Transmission Impairments

Data Rate Limits

Noiseless Channel: Nyquist Bit Rate Noisy Channel: Shannon Capacity

Using Both Limits

Performance

Exercise

References

Data rate is a very important factor in data communications.

- ▶ Data rate is a very important factor in data communications.
- Data rate is depend on:

- Data rate is a very important factor in data communications.
- Data rate is depend on:
 - Available bandwidth

- ▶ Data rate is a very important factor in data communications.
- Data rate is depend on:
 - Available bandwidth
 - Level of signals

- Data rate is a very important factor in data communications.
- Data rate is depend on:
 - Available bandwidth
 - Level of signals
 - Channel quality (level of noise)

- Data rate is a very important factor in data communications.
- Data rate is depend on:
 - Available bandwidth
 - Level of signals
 - Channel quality (level of noise)
- There are two theoretical formulas to calculate the data rate: Nyquist formula and Shannon formula.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer


Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Data Rate Limits

Noiseless Channel: Nyquist Bit Rate Noisy Channel: Shannon Capacity Using Both Limits formance

Exercise

References



Nyquist bit rate formula is used to define the maximum bit rate in a noiseless channel⁸.

⁸Noise = 0; Therefore $SNR_{dB} = \infty$

- Nyquist bit rate formula is used to define the maximum bit rate in a noiseless channel⁸.
- ▶ The formula is

⁸Noise = 0; Therefore $SNR_{dB} = \infty$

- Nyquist bit rate formula is used to define the maximum bit rate in a noiseless channel⁸.
- The formula is

BitRate =
$$2 \times \text{bandwidth} \times \log_2 L$$
 (11)

⁸Noise = 0; Therefore $SNR_{dB} = \infty$

- Nyquist bit rate formula is used to define the maximum bit rate in a noiseless channel⁸.
- The formula is

BitRate =
$$2 \times \text{bandwidth} \times \log_2 L$$
 (11)

where

BitRate = bit rate (bps)

bandwidth = bandwidth of the channel (Hz)

L = number of signal levels

⁸Noise = 0; Therefore $SNR_{dB} = \infty$

- Nyquist bit rate formula is used to define the maximum bit rate in a noiseless channel⁸.
- The formula is

BitRate =
$$2 \times \text{bandwidth} \times \log_2 L$$
 (11)

where

BitRate = bit rate (bps)

bandwidth = bandwidth of the channel (Hz)

L = number of signal levels

Although more signal levels means higher data rate, unfortunately it also means more burden to the system.

⁸Noise = 0; Therefore $SNR_{dB} = \infty$

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Data Rate Limits

Noiseless Channel: Nyquist Bit Rate Noisy Channel: Shannon Capacity Using Both Limits

1 CHOITHAILOC

Exercise

References

Noiseless channel does not exist in reality.

- Noiseless channel does not exist in reality.
- ► The Shannon capacity includes noise to determine the highest data rate:

- Noiseless channel does not exist in reality.
- ► The Shannon capacity includes noise to determine the highest data rate:

Capacity = bandwidth
$$\times \log_2(1 + SNR)$$
 (12)

- Noiseless channel does not exist in reality.
- The Shannon capacity includes noise to determine the highest data rate:

```
Capacity = bandwidth \times \log_2(1 + SNR) (12)

where

Capacity = capacity of the channel (bps)

bandwidth = bandwidth of the channel (Hz)

SNR = signal-to-noise ration
```

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium Data and Signals Periodic Analog Signals Digital Signals Transmission Impairment

Data Rate Limits

Noiseless Channel: Nyquist Bit Rate Noisy Channel: Shannon Capacity

Using Both Limits

Performance

Exercise

References

We can use both methods to find the limits and signal levels.

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- ▶ By using the Shannon Capacity in Equation (12) we got

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$

= 10⁶ · \log_2(1 + 63)

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$

= 10⁶ · \log_2(1 + 63)
= 10⁶ · \log_2(64)

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- ▶ By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$
= 10⁶ · \log_2(1 + 63)
= 10⁶ · \log_2(64)
= 10⁶ · 6

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- ▶ By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$
= $10^6 \cdot \log_2(1 + 63)$
= $10^6 \cdot \log_2(64)$
= $10^6 \cdot 6$
= $6 \times 10^6 \text{ bps}$

- We can use both methods to find the limits and signal levels.
- Suppose we have a channel with 1 MHz bandwidth, SNR = 63.
- ▶ By using the Shannon Capacity in Equation (12) we got

$$C = B \log_2(1 + \text{SNR})$$
= $10^6 \cdot \log_2(1 + 63)$
= $10^6 \cdot \log_2(64)$
= $10^6 \cdot 6$
= $6 \times 10^6 \text{ bps}$

The capacity of the channel according to Shannon formula is 6 Mbps.

▶ We use lower limit for better performance, say 4 Mbps.

- ► We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

- We use lower limit for better performance, say 4 Mbps.
- ▶ By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

- We use lower limit for better performance, say 4 Mbps.
- ▶ By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $4 = 2 \times \log_2 L$

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $2 = \log_2 L$

Using Both Limits

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $2 = \log_2 L$
 $\sqrt{L} = 2$

Using Both Limits

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $2 = \log_2 L$
 $\sqrt{L} = 2$
 $L = 4$

Using Both Limits

- We use lower limit for better performance, say 4 Mbps.
- By using the Nyquist Bitrate in Equation (11) we got

BitRate =
$$2 \times B \times \log_2 L$$

 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 \times 10^6 = 2 \times 10^6 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $4 = 2 \times \log_2 L$
 $2 = \log_2 L$
 $\sqrt{L} = 2$
 $L = 4$

The number of signal levels is 4.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Performance

Bandwidth

Throughput

Latency

Bandwidth-Delay Product

Jitter

Exercise

Outline

Review: Physical Layer

Periodic Analog Signals

Performance Bandwidth

► Bandwidth is a characteristic that measures network performance.

- Bandwidth is a characteristic that measures network performance.
- ▶ There are two context of bandwidth:

- Bandwidth is a characteristic that measures network performance.
- There are two context of bandwidth:
 - Range of frequencies in a composite signal, or the range of frequencies a channel can pass. This type of bandwidth is measured in Hertz (Hz).

- Bandwidth is a characteristic that measures network performance.
- There are two context of bandwidth:
 - Range of frequencies in a composite signal, or the range of frequencies a channel can pass. This type of bandwidth is measured in Hertz (Hz).
 - Number of bits per second that a channel, link, or network can transmit.

- Bandwidth is a characteristic that measures network performance.
- There are two context of bandwidth:
 - Range of frequencies in a composite signal, or the range of frequencies a channel can pass. This type of bandwidth is measured in Hertz (Hz).
 - Number of bits per second that a channel, link, or network can transmit.
- Although they have different context, both types of bandwidth are related.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Data Rate Limits

Performance

Bandwidth

Throughput

Latency Bandwidth-Delay Produc Jitter

Exercise

Throughput is a measure of how fast we can actually send data through a network.

- Throughput is a measure of how fast we can actually send data through a network.
- ▶ A link may have a bandwidth of *B* bps, but we can only send *T* bps through this link (*T* < *B*).

- Throughput is a measure of how fast we can actually send data through a network.
- ▶ A link may have a bandwidth of B bps, but we can only send T bps through this link (T < B).</p>
- ▶ If bandwidth is the potential measurement, then throughput is the actual measurement.

- Throughput is a measure of how fast we can actually send data through a network.
- ▶ A link may have a bandwidth of B bps, but we can only send T bps through this link (T < B).</p>
- ▶ If bandwidth is the potential measurement, then throughput is the actual measurement.
- ► Throughput is affected by network congestion, bottleneck, etc.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Data Rate Limits

Performance

Bandwidth Throughput

Latency

Bandwidth-Delay Product

Exercise

Latency (delay) defines how long it takes for an entire message to completely arrive at the destination.

- Latency (delay) defines how long it takes for an entire message to completely arrive at the destination.
- ► The measurement starts when the first bit is sent out from the source.

- Latency (delay) defines how long it takes for an entire message to completely arrive at the destination.
- The measurement starts when the first bit is sent out from the source.
- Latency is the sum of four components and can be mathematically expressed as:

- Latency (delay) defines how long it takes for an entire message to completely arrive at the destination.
- The measurement starts when the first bit is sent out from the source.
- Latency is the sum of four components and can be mathematically expressed as:

Propagation Time

Propagation time measures the time required for a bit to travel from source to the destination.

Propagation Time

- Propagation time measures the time required for a bit to travel from source to the destination.
- Propagation time can be mathematically expressed as:

Propagation Time

- Propagation time measures the time required for a bit to travel from source to the destination.
- Propagation time can be mathematically expressed as:

Propagation Time =
$$\frac{\text{distance}}{\text{propagation speed}}$$
 (14)

Transmission Time

► Transmission time is the duration, started from when the first bit left the sender until the last bit arrived at the receiver.

Transmission Time

- ► Transmission time is the duration, started from when the first bit left the sender until the last bit arrived at the receiver.
- Transmission time depends on message size and bandwidth of the channel.

Transmission Time

- Transmission time is the duration, started from when the first bit left the sender until the last bit arrived at the receiver.
- Transmission time depends on message size and bandwidth of the channel.
- Transmission time can be mathematically expressed as:

Transmission Time

- ► Transmission time is the duration, started from when the first bit left the sender until the last bit arrived at the receiver.
- Transmission time depends on message size and bandwidth of the channel.
- Transmission time can be mathematically expressed as:

Transmission time =
$$\frac{\text{(Message Size)}}{\text{bandwidth}}$$
 (15)

Queuing Time and Processing Delay

Queuing is the amount of time needed by an intermediate device to hold the message before it can be processed.

Queuing Time and Processing Delay

- Queuing is the amount of time needed by an intermediate device to hold the message before it can be processed.
- The queuing time is fluctuating according to the present condition of the network.

Queuing Time and Processing Delay

- Queuing is the amount of time needed by an intermediate device to hold the message before it can be processed.
- The queuing time is fluctuating according to the present condition of the network.
- Processing delay is the amount of time needed by an device to process a message.

Queuing Time and Processing Delay

- Queuing is the amount of time needed by an intermediate device to hold the message before it can be processed.
- The queuing time is fluctuating according to the present condition of the network.
- Processing delay is the amount of time needed by an device to process a message.
- For example, a router when it receives a packet should determine whether to self-process the packet or forward it, then if the packet should be forwarded, the packet should determine where to forward it.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium
Data and Signals
Periodic Analog Signals
Digital Signals
Transmission Impairments

Performance

Bandwidth Throughput Latency

Bandwidth-Delay Product

Jitter

Exercise

Bandwidth-delay product is the number of bits that can fill a link.

- Bandwidth-delay product is the number of bits that can fill a link.
- The measurement is important if we need to send data in burst and wait for the acknowledgement of each burst before sending the next one.

- Bandwidth-delay product is the number of bits that can fill a link.
- The measurement is important if we need to send data in burst and wait for the acknowledgement of each burst before sending the next one.
- To use the maximum capability of the link, we need to make the size of our burst 2 times the bandwidth-delay product and fill up; fill up the full-duplex channel.

- Bandwidth-delay product is the number of bits that can fill a link.
- The measurement is important if we need to send data in burst and wait for the acknowledgement of each burst before sending the next one.
- To use the maximum capability of the link, we need to make the size of our burst 2 times the bandwidth-delay product and fill up; fill up the full-duplex channel.
- Consider these following cases:

- Bandwidth-delay product is the number of bits that can fill a link.
- The measurement is important if we need to send data in burst and wait for the acknowledgement of each burst before sending the next one.
- To use the maximum capability of the link, we need to make the size of our burst 2 times the bandwidth-delay product and fill up; fill up the full-duplex channel.
- Consider these following cases:

Case 1: A link with 1 bps bandwidth and 1 s delay, see Figure 21.

- Bandwidth-delay product is the number of bits that can fill a link.
- The measurement is important if we need to send data in burst and wait for the acknowledgement of each burst before sending the next one.
- To use the maximum capability of the link, we need to make the size of our burst 2 times the bandwidth-delay product and fill up; fill up the full-duplex channel.
- Consider these following cases:
 - Case 1: A link with 1 bps bandwidth and 1 s delay, see Figure 21.
 - Case 2: A link with 5 bps bandwidth and 5 s delay, see Figure 22.

Case 1




Figure 21: Bandwidth-link product, case 1.

Case 2




Figure 22 : Bandwidth-link product, case 2.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Transmission Medium

Data and Signals

Periodic Analog Signals

Digital Signals

Transmission Impairments

Data Rate Limits

Performance

Bandwidth

Throughput

Latency

Bandwidth-Delay Product

Jitter

Jitter

► Jitter is the variance of delays encountered by the transmission.

Jitter

- Jitter is the variance of delays encountered by the transmission.
- ▶ Jitter becomes a problem when the application is time-sensitive, (e.g. audio and video data).

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

1. A signal has 300 cycles per second. What is its frequency in Hertz?

- A signal has 300 cycles per second. What is its frequency in Hertz?
- 2. What is the period of a signal that has 200 cycles per second?

- A signal has 300 cycles per second. What is its frequency in Hertz?
- 2. What is the period of a signal that has 200 cycles per second?
- 3. A signal is propagating in a medium with propagation speed = $2 \times 10^8 \ m/s$. The period of the signal is 0.00005 s. Calculate its wavelength!

- A signal has 300 cycles per second. What is its frequency in Hertz?
- 2. What is the period of a signal that has 200 cycles per second?
- 3. A signal is propagating in a medium with propagation speed = $2 \times 10^8 \ m/s$. The period of the signal is 0.00005 s. Calculate its wavelength!
- 4. The wavelength of a signal is 0.125 m. Suppose it is propagating in vacuum, then what is its frequency?

- A signal has 300 cycles per second. What is its frequency in Hertz?
- 2. What is the period of a signal that has 200 cycles per second?
- 3. A signal is propagating in a medium with propagation speed = 2×10^8 m/s. The period of the signal is 0.00005 s. Calculate its wavelength!
- 4. The wavelength of a signal is 0.125 m. Suppose it is propagating in vacuum, then what is its frequency?
- 5. The frequency of a signal is 900 MHz and the wavelength is 0.25 m. What is the propagation speed of the medium?

 Suppose a signal travels through a transmission medium and its power is reduced to one-half. Calculate the attenuation of the signal (in dB)[1]!

- Suppose a signal travels through a transmission medium and its power is reduced to one-half. Calculate the attenuation of the signal (in dB)[1]!
- 7. A signal propagates from A to B. The power at A is 100 W, while the power at B is 50 W. Determine the state of the signal, whether it is amplified or attenuated!

- Suppose a signal travels through a transmission medium and its power is reduced to one-half. Calculate the attenuation of the signal (in dB)[1]!
- 7. A signal propagates from A to B. The power at A is 100 W, while the power at B is 50 W. Determine the state of the signal, whether it is amplified or attenuated!
- 8. A signal propagates through a noiseless channel. What is the SNR_{dB} of such channel for signal power *S*?

Attenuation due to path loss in wireless is mathematically expressed as

Attenuation due to path loss in wireless is mathematically expressed as

$$PL = 20 \log(f) + 20 \log(d) - 147.56 dB$$
 (16)

Attenuation due to path loss in wireless is mathematically expressed as

$$PL = 20 \log(f) + 20 \log(d) - 147.56dB$$
 (16)

Equation (8) shows the attenuation/amplification by comparing signal powers at site 2 and site 1. If the received signal power always decreased due to path loss as shown by Equation 16, modify the Equation 8 to calculate the attenuation if transmitted and received signal powers are known!

Attenuation due to path loss in wireless is mathematically expressed as

$$PL = 20 \log(f) + 20 \log(d) - 147.56dB$$
 (16)

- Equation (8) shows the attenuation/amplification by comparing signal powers at site 2 and site 1. If the received signal power always decreased due to path loss as shown by Equation 16, modify the Equation 8 to calculate the attenuation if transmitted and received signal powers are known!
- Both Equations (8) and (16) are used to calculate attenuation. If we ignore other wireless link budget parameters, give the mathematical correlation between both equations!

10. A Wireless Service provider is going to cover the customers at a new area. You are acting as the consultant for this WISP and the managers are requesting your consideration about their going-to-be-deployed wireless backbone.

If the sensitivity threshold is -67 dBm, calculate the minimum transmit power by using the mathematical correlation between Equations (8) and (16) you found in the previous question!

The following information are available to you:

- 10. A Wireless Service provider is going to cover the customers at a new area. You are acting as the consultant for this WISP and the managers are requesting your consideration about their going-to-be-deployed wireless backbone.

 If the sensitivity threshold is -67 dBm, calculate the minimum transmit power by using the mathematical correlation between Equations (8) and (16) you found in the previous question!

 The following information are available to you:
 - ► The sites are located at the coordinates shown in Figure 23.

- 10. A Wireless Service provider is going to cover the customers at a new area. You are acting as the consultant for this WISP and the managers are requesting your consideration about their going-to-be-deployed wireless backbone.

 If the sensitivity threshold is -67 dBm, calculate the minimum transmit power by using the mathematical correlation between Equations (8) and (16) you found in the previous question!

 The following information are available to you:
 - The sites are located at the coordinates shown in Figure 23.
 - These sites will form a ring topology, so a site is connected to the other two.

- 10. A Wireless Service provider is going to cover the customers at a new area. You are acting as the consultant for this WISP and the managers are requesting your consideration about their going-to-be-deployed wireless backbone.

 If the sensitivity threshold is -67 dBm, calculate the minimum transmit power by using the mathematical correlation between Equations (8) and (16) you found in the previous question!

 The following information are available to you:
 - ► The sites are located at the coordinates shown in Figure 23.
 - These sites will form a ring topology, so a site is connected to the other two.
 - This WISP uses 802.11n technology, and the frequency in-use follows the regulation issued by the Indonesian government.




Figure 23: Locations of the backbone sites.

11. If the bandwidth of the channel is 5 Kbps, how long does it take to send a frame of 100,000 bits out of this device?

- 11. If the bandwidth of the channel is 5 Kbps, how long does it take to send a frame of 100,000 bits out of this device?
- 12. What is the length of a bit in a channel with a propagation speed of $2 \times 10^8 \text{m/s}$ if the channel bandwidth is 100 Mbps?

- 11. If the bandwidth of the channel is 5 Kbps, how long does it take to send a frame of 100,000 bits out of this device?
- 12. What is the length of a bit in a channel with a propagation speed of $2 \times 10^8 \text{m/s}$ if the channel bandwidth is 100 Mbps?
- 13. How many bits can fit on a link with a 2 ms delay if the bandwidth of the link is 1 Mbps?

- 11. If the bandwidth of the channel is 5 Kbps, how long does it take to send a frame of 100,000 bits out of this device?
- 12. What is the length of a bit in a channel with a propagation speed of $2 \times 10^8 \text{m/s}$ if the channel bandwidth is 100 Mbps?
- 13. How many bits can fit on a link with a 2 ms delay if the bandwidth of the link is 1 Mbps?
- 14. What is the total delay for a frame of size 5 million bits that is being sent on a link with 10 routers, each having a queuing time of $2\mu s$ and processing time of $1\mu s$ the length of the link is 2000 Km. The propagation speed is $2\times10^8 \,\mathrm{m/s}$ The link has a bandwidth of 5 Mbps. Which component of the total delay is dominant? Which one is negligible?

Next session..

- OMNeT++
- Finish TicToc Tutorial before class!
- Have OMNeT++, R (and optionally RStudio) installed in your notebooks. Each student who has notebook is highly advised to bring his/her own notebook.

Outline

Course Details

Review: Data Communications and Networking

Review: Physical Layer

Exercise

References

References I

- [1] B. Forouzan, <u>Data Communications and Networking</u>, 5th ed. New York: McGraw-Hill Education, 2013.
- [2] W. Stallings, <u>Data and Computer Communications</u>, 8th ed. NJ: Pearson/Prentice Hall, 2007.