



LESTER B. PEARSON
Pearson Electrotechnology Centre

Installation and Repair of Telecommunications Equipment

Module 21 Telephone network systems

VOIP lab experiment#4 Configuring Zoiper

Installation and Repair of Telecommunications Equipment

Name of student: _____

Group Number: _____

Date: _____



Installation and Repair of Telecommunications Equipment


Module 21 Telephone network systems

The purpose of the lab is to demonstrate the ability of the students to configure the softphone Zoiper by assigning an extension created in lab#3.

- 1- To start assigning an extension, you need to open the software.



- 2- Click on **continue as a free user**
- 3- You want to assign an extension to the softphone. ONLY 1 Extension can be assigned to 1 softphone at a time.




- 4- In the first rectangle assign one of the 3 extensions you have created in lab#3. (1000, 2000 or 3000). In the 2nd rectangle enter the password of the extension: **pec123**



LESTER B. PEARSON
Pearson Electrotechnology Centre


Installation and Repair of Telecommunications Equipment

Module 21 Telephone network systems



The screenshot shows the Zoiper5 login interface. On the left, there is a login form with a username field containing '1000' and a password field with masked characters. Below the password field is an example: 'For example K23XWkd23'. There are two buttons: a green 'Login' button and an orange 'Create account' button. On the right, there is a large graphic of a smiling headset icon. Below the graphic, the text reads: 'Username and password', 'If you already have a VoIP account, please enter your login credentials to the left. Most often these are provided either by your VoIP provider, or by your system administrator for your office's IP PBX.', and a small note: '*we will try to automatically find the necessary configuration for your account. If such does not exist in our database, you'll be asked to enter specific details.'

- 5- The 2nd rectangle password is **pec123**, click on **login**



The screenshot shows the Zoiper5 hostname configuration screen. On the left, there is a text input field for the hostname. Below it, the text reads: 'This could also be called 'Domain', 'SIP server', 'Registrar' or 'SIP Proxy'. For example 'sip.example.com' or '123.21.123.32:5060''. At the bottom left are 'Back' and 'Next' buttons. On the right, there is a graphic of a cloud connected to a server rack. Below the graphic, the text reads: 'Hostname', 'This could also be called 'Domain', 'SIP server', 'Registrar' or 'SIP Proxy'. For example 'sip.example.com' or '123.21.123.32:5060'. You can also just search for the name of your provider, maybe we know the settings. If not – you'll be able to set it up manually.'


- 6- In the rectangle, enter your **PBX IP address**, then click on **Next**




LESTER B. PEARSON
Pearson Electrotechnology Centre

Installation and Repair of Telecommunications Equipment

Module 21 Telephone network systems



7- Press skip




8- The SIP UDP should be in green colour, found. Click next



LESTER B. PEARSON
Pearson Electrotechnology Centre

Installation and Repair of Telecommunications Equipment

Module 21 Telephone network systems



- 9- The green arrow means your extension has properly been assigned to the softphone.