

[Type here]



LESTER B. PEARSON
Pearson Electrotechnology Centre

Installation and Repair of Telecommunications Equipment

Module 21

Telephone network systems installation

VOIP lab experiment#8

Creating an inbound route

Installation and Repair of Telecommunications Equipment

Name of student:_____

Group Number:_____

Date:_____

Installation and Repair of Telecommunications Equipment


Module 21

Telephone network systems installation

The purpose of the lab is to create an inbound rate for the company in the PBX.

Go to Inbound Routes in the Menu connectivity

1- Enter a description



The screenshot shows a web browser window with the URL `192.168.100.119/admin/config.php?display=did&didfilter=&navsort=description&extdisplay=`. The browser's address bar indicates "Not secure". The page has a navigation menu with buttons for "Admin", "Applications", "Connectivity", "Reports", "Settings", and "User Panel". The "Connectivity" button is highlighted. The main content area is titled "Route: incoming" and includes a "Delete Route incoming" link and an "Edit Extension 1000 (1000)" link. Below this is a section titled "Edit Incoming Route" with a horizontal line separator. The form contains the following fields:

- Description:
- DID Number:
- CallerID Number:
- CID Priority Route: ☐

Below these fields is a section titled "Options" with a horizontal line separator. The form contains the following fields:

- Alert Info:
- CID name prefix:
- Music On Hold:
- Signal RINGING: ☐
- Pause Before Answer:

At the bottom of the form is a section titled "Privacy" with a horizontal line separator.

2- Enter a DID number: leave blank

Installation and Repair of Telecommunications Equipment

Module 21

Telephone network systems installation

Extension Routes is not registered

The free Extension Routes module is installed, but not registered.

Fax Detect

Detect Faxes :

No Yes

Set Destination

Extensions  <1000> 1000 

Submit

Clear Destination & Submit

3- Choose an extension in set destination

4- Submit and apply configuration