

DARwIn OP

Assembly Manual



DARwIn OP Assembly Manual

Created by RoMeLa at Virginia Tech

Version: 1.0.1

Created : 5/3/2011

Modified : 7/26/2011

Principal authors:

Stephen Rouleau

Coleman Knabe

Matthew Stanford

Thanh Pham

Nolawe Woldesemayat

Mark Umansky

Justin Siegel

Austin Kim

Allison McCormack

Dante Branch

Viktor Orekhov

THIS ASSEMBLY MANUAL IS TO BE USED IN CONJUNCTION WITH THE FOLLOWING DOCUMENTS:


DARwIn OP Wiring Manual

DARwIn OP Fabrication Manual




PERMISSION IS GRANTED TO COPY, DISTRIBUTE AND/OR MODIFY THIS DOCUMENT UNDER THE TERMS OF THE CREATIVE COMMONS ATTRIBUTION-NONCOMMERCIAL-SHAREALIKE 3.0 UNPORTED LICENSE. TO VIEW A COPY OF THIS LICENSE, VISIT [HTTP://CREATIVECOMMONS.ORG/LICENSES/BY-NC-SA/3.0/](http://creativecommons.org/licenses/by-nc-sa/3.0/)

Parts List 1 – Frame




Part Number	Description	Part Name	Qty.
1	Head Bracket	PR13_B01_BRKT_CAM	1
2	Neck Bracket	FR07_H104	1
3	Chest Actuator Connectors	FR07_X101	4
4	Upper Chest Bracket	PR13_B01_FRM_PCB_MAIN_T	1
5	Lower Chest Bracket	PR13_B01_FRM_PCB_MAIN_B	1
6	Mounting Bracket	PR13_B_SPACER_PELV	2
7	Battery Bracket	FR07_E130	1
8	Battery Cover Bracket	PR13_B_FRM_CVR_BAT_ASM	1
9L	Back Left Pelvic Bracket	PR13_B_BRKT_PELV_L	1
9R	Back Right Pelvic Bracket	PR13_B_BRKT_PELV_R	1
10	Angled Actuator Bracket	FR07_H102	4
11	Arm Actuator Mount	FR07_SC101	2
12	Hand	FR07_E180	2
13	U-Actuator Bracket	FR07_H120	4
14	Leg Actuator Mount	FR07_S101	6
15	Actuator Connector	FR07_X102	8
16	Thigh Bracket	FR07_H132	2
17	Knee Bracket	FR07_H133	2
18	Foot	FR07_E160	2
32	Cable Holder	DC04 HOLDER_CABLE_PRM	10

Parts List 2 - Covers











Part Number	Description	Qty.
21	Head LED Cover	1
33	Arm Cover Upper	2
34	Arm Cover Lower	2
35	Thigh Cover	2
36	Leg Cover	2
37B	Back Head Cover	1
37F	Front Head Cover	1
38B	Back Chest Cover	1
38F	Front Chest Cover	1
39L	Left Foot Cover	1
39R	Right Foot Cover	1
40L	Left Eye Cover	1
40R	Right Eye cover	1
41L	Left Pupil	1
41R	Right Pupil	1

Parts List 3 - Actuators




Actuator ID	Actuator Type	Bearing Required
M1	Dynamixel MX-28	No
M2	Dynamixel MX-28	No
M3	Dynamixel MX-28	Yes
M4	Dynamixel MX-28	Yes
M5	Dynamixel MX-28	Yes
M6	Dynamixel MX-28	Yes
M7	Dynamixel MX-28	No
M8	Dynamixel MX-28	No
M9	Dynamixel MX-28	No
M10	Dynamixel MX-28	No
M11	Dynamixel MX-28	Yes
M12	Dynamixel MX-28	Yes
M13	Dynamixel MX-28	Yes
M14	Dynamixel MX-28	Yes
M15	Dynamixel MX-28	Yes
M16	Dynamixel MX-28	Yes
M17	Dynamixel MX-28	No
M18	Dynamixel MX-28	No
M19	Dynamixel MX-28	No
M20	Dynamixel MX-28	Yes

Parts List 4 - Electronics



Part Number	Description	Qty.
19	Camera	1
20	Head PCB	1
22	FitPC	1
23	CM730	1
24	Antenna	1
25	Antenna Connector	1
26	Fan	2
27	Back Cover PCB	1
29	Speaker	1
30	Power Switch	1
31	Battery	1

Parts List 5 – Fasteners





Part Number	Description	Qty.
S1	M1.4x4	6
S2	Button Head M2x4	2
S3	Phillips Head M2x4	22
S4	Phillips Head M2x5	16
S5	Phillips Head M2x6	20
S6	Phillips Head M2.5x4	12
S7	Phillips Head M2.5x6	4
S8	Phillips Head M3x4	8
S9	Phillips Head M3x6	8
S10	Flat Head M2.5x4	4
S11	Hex Head M2x3	28
S12	Hex Head M2x4	143
S13	Hex Head M2.5x3	8
S14	Hex Head M2.5x4	48
S15	Hex Head M2.5x6	112
S16	Hex Head M2.5x8	33
S17	Hex Head M2.5x10	8
SU1	Spacer M2.5x6	4
SU2	Spacer M2.5x10	3
SU3	Spacer M3x11	4
N1	Nut M2.5	92
BC	Bearing Cap	15
BG	Bearing	15
FL	Flange Bearing	4
ID	Bearing Idler	15
MH	Horn	20
TW	Thrust Washer	20

0. Actuators

Dynamixel MX-28 Actuator ID's are recommended to be set prior to assembly. Refer to ROBOTIS e-Manual to set Actuator ID's using Dynamixel Wizard.

Horn attachment


*NOTE – All actuators require horn



Alignment of motor horn on actuator shaft


Actuator bearing attachment

*NOTE – M1, M2, M7, M8, M9, M10, M17, M18, M19 do NOT require a bearing



***WARNING – Horns must align with actuator shaft as shown. Damage to actuators and/or robot may occur if horn is not properly aligned when attached to actuator.**

1. Upper Chest




Part Number	Description	Qty.
2	Neck Bracket	1
3	Chest Actuator Connector	4
4	Upper Chest Bracket	1
10	Angled Actuator Bracket	2
23	CM730	1
24	Antenna	1
25	Antenna Connector	1
M1	Dynamixel MX-28	1
M2	Dynamixel MX-28	1
M19	Dynamixel MX-28	1
S8	Phillips Head M3x4	8
S12	Hex Head M2x4	21
S15	Hex Head M2.5x6	24
S16	Hex Head M2.5x8	3
N1	Nut M2.5	16
SU3	Spacer M3x11	4


1. Upper Chest

1-1. Upper chest actuator assembly

1-1-1. Actuator connectors to M19






1-1-2. M1 and M2 to actuator connectors




1. Upper Chest

1-1. Upper chest actuator assembly


1-1-3. Upper chest bracket assembly



M1 horn orientation



M19 horn orientation




M2 horn orientation


1. Upper Chest

1-2 Upper chest electronics assembly



1-2-1. Antenna to upper chest bracket



1-2-3. Circuit board to upper chest bracket




1-2-2. FitPC to upper chest bracket




1. Upper Chest

1-3 Upper chest unit assembly


1-3-1. [1-1] to [1-2] assembly




Front View



Back View



2. Lower Chest




Part Number	Description	Qty.
5	Lower Chest Bracket	1
6	Mounting Bracket	2
7	Battery Bracket	1
8	Battery Cover Bracket	1
9R	Back Right Pelvic Bracket	1
9L	Back Left Pelvic Bracket	1
22	FitPC	1
30	Power Switch	1
31	Battery	1
M7	Dynamixel MX-28	1
M8	Dynamixel MX-28	1
S6	Phillips Head M2.5x4	8
S10	Flat Head M2.5x4	4
S14	Hex Head M2.5x4	10
S15	Hex Head M2.5x6	10
S16	Hex Head M2.5x8	2
S17	Hex Head M2.5x10	8
N1	Nut M2.5	10
SU1	Spacer M2.5x6	4
SU2	Spacer M2.5x10	3


2. Lower Chest

2-1 Switch assembly

2-1-1. Power switch spacer assembly




2-1-2. Switch to back right pelvic bracket



2-2. Lower chest unit assembly


2-2-1. FitPC spacer assembly




2. Lower Chest

2-2. Lower chest unit assembly

2-2-2. FitPC to lower chest bracket




2-2-3. M7 and M8 to lower chest bracket




2. Lower Chest

2-2. Lower chest unit assembly

2-2-4. FitPC to lower chest bracket






2-2-5. Battery bracket to lower chest bracket




2. Lower Chest

2-2. Lower chest unit assembly

2-2-6. Lower chest unit assembly



3. Right Leg




Part Number	Description	Qty.
13	U-Actuator Bracket	2
14	Actuator Mount	3
15	Actuator Connector	4
16	Thigh Bracket	1
17	Knee Bracket	1
18	Foot	1
22	FitPC	1
32	Cable Holder	4
M11	Dynamixel MX-28	1
M13	Dynamixel MX-28	1
M15	Dynamixel MX-28	1
M17	Dynamixel MX-28	1
M19	Dynamixel MX-28	1
S3	Phillips Head M2x4	2
S4	Phillips Head M2x5	6
S11	Hex Head M2x3	8
S12	Hex Head M2x4	41
S13	Hex Head M2.5x3	4
S14	Hex Head M2.5x4	4
S15	Hex Head M2.5x6	28
S16	Hex Head M2.5x8	10
N1	Nut M2.5	20
BC	Bearing Cap	2
BG	Bearing	2
FL	Flange Bearing	2
ID	Bearing Idler	2


3. Right Leg

3-1. Right lower leg


3-1-1. Lower leg actuator mount assembly




3-1-3. M15 to lower leg actuator mount



3-1-2. Lower leg actuator mount bearing assembly




3-1-4. Actuator connectors to M15




3. Right Leg

3-1. Right lower leg


3-1-5. U-actuator bracket to foot



3-1-7. [3-1-4] to U-actuator bracket





3-1-6. M17 to U-actuator bracket



3. Right Leg

3-1. Right lower leg


3-1-8. Knee bracket to foot




3. Right Leg

3-2. Right upper leg


3-2-1. Upper leg actuator mount assembly




3-2-3. M11 to upper leg actuator mount



3-2-2. Upper leg actuator mount bearing assembly




3-2-4. Actuator connectors to M11




3. Right Leg

3-2. Right upper leg

3-2-5. M9 to U-actuator bracket




3-2-6. **3-2-4** to **3-2-5** assembly





3. Right Leg

3-2. Right upper leg

3-2-7. Thigh bracket to actuator mount




3-2-8. M13 to actuator mount



3. Right Leg

3-2. Right upper leg



3-2-9. [3-2-6] to [3-2-8] assembly




3. Right Leg

3-3. Right leg unit assembly

3-3-1. [3-1] to [3-2] assembly



4. Left Leg




Part Number	Description	Qty.
13	U-Actuator Bracket	2
14	Actuator Mount	3
15	Actuator Connectors	4
16	Thigh Bracket	1
17	Knee Bracket	1
18	Foot	1
22	FitPC	1
32	Cable Holder	4
M10	Dynamixel MX-28	1
M12	Dynamixel MX-28	1
M14	Dynamixel MX-28	1
M16	Dynamixel MX-28	1
M18	Dynamixel MX-28	1
S3	Phillips Head M2x4	2
S4	Phillips Head M2x5	6
S11	Hex Head M2x3	8
S12	Hex Head M2x4	41
S13	Hex Head M2.5x3	4
S14	Hex Head M2.5x4	4
S15	Hex Head M2.5x6	28
S16	Hex Head M2.5x8	10
N1	Nut M2.5	20
BC	Bearing Cap	2
BG	Bearing	2
FL	Flange Bearing	2
ID	Bearing Idler	2


4. Left Leg

4-1. Left lower leg


4-1-1. Lower leg actuator mount assembly




4-1-2. Lower leg actuator mount bearing assembly



4-1-3. M16 to lower leg actuator mount




4-1-4. Motor bracket assembly




4. Left Leg

4-1. Left lower leg


4-1-4. U-actuator bracket to foot



4-1-7. [4-1-4] to U-actuator bracket



4-1-6. M18 to U-actuator bracket




M18 horn orientation


4. Left Leg

4-1. Left lower leg

4-1-8. Knee bracket to foot




M16 horn orientation




4. Left Leg

4-2. Left upper leg


4-2-1. Upper leg actuator mount assembly





4-2-3. M12 to upper leg actuator mount



4-2-2. Upper leg actuator mount bearing assembly




4-2-4. Actuator connectors to M12




4. Left Leg

4-2. Left upper leg

4-2-5. M9 to U-actuator bracket




4-2-6. [4-2-4] to [4-2-5] assembly




4. Left Leg

4-2. Left upper leg

4-2-7. Thigh bracket to actuator mount




4-2-8. M14 to actuator mount




4. Left Leg

4-2. Left upper leg

4-2-9. [4-2-6] to [4-2-8] assembly





M12 horn orientation




4. Left Leg

4-3. Left leg unit assembly

4-3-1. [4-1] to [4-2] assembly



5. Right Arm




Part Number	DESCRIPTION	QTY.
10	Angled Actuator Bracket	1
11	Actuator Mount	1
12	Hand	1
M3	Dynamixel MX-28	1
M5	Dynamixel MX-28	1
S11	Hex Head M2x3	4
S12	Hex Head M2x4	10
S14	Hex Head M2.5x4	4
S15	Hex Head M2.5x6	8
S16	Hex Head M2.5x8	4
N1	Nut M2.5	8


5. Right Arm

5-1. Right arm unit assembly

5-1-1. Angled actuator bracket to hand




5-1-1. M5 to angled actuator bracket




5. Right Arm

5-1. Right arm unit assembly


5-1-3. Actuator mount to M5



5-1-4. M3 to actuator mount



6. Left Arm




Part Number	DESCRIPTION	QTY.
10	Angled Actuator Bracket	1
11	Actuator Mount	1
12	Hand	1
M4	Dynamixel MX-28	1
M6	Dynamixel MX-28	1
S11	Hex Head M2x3	4
S12	Hex Head M2x4	10
S14	Hex Head M2.5x4	4
S15	Hex Head M2.5x6	8
S16	Hex Head M2.5x8	4
N1	Nut M2.5	8


6. Left Arm

6-1. Left arm unit assembly

6-1-1. Angled actuator bracket to hand




6-1-2. M6 to angled actuator bracket





6. Left Arm

6-1. Left arm unit assembly


6-1-3. Actuator mount to M6



6-1-4. M4 to actuator mount



7. Head




Part Number	DESCRIPTION	QTY.
1	Head Bracket	1
20	Head PCB	1
S3	Phillips Head M2x4	2
S15	Hex Head M2.5x6	6
N1	Nut M2.5	6



7. Head

7-1. Head unit assembly


7-1-1. Head bracket to M20



7-1-2. Head PCB to head bracket



8. Full Assembly





Part Number	Description	Qty.
32	Cable Holder	2
S4	Phillips Head M2x5	4
S11	Hex Head M2x3	4
S12	Hex Head M2x4	20
S14	Hex Head M2.5x4	22

8. Full Assembly

8-1. Chest unit assembly


8-1-1. [1-1] to [2-1] assembly



8. Full Assembly



8-2. Legs to body assembly

8-2-1. [3-3] and [4-3] to [8-1] assembly




8-3. Arms to body assembly


8-3-1. [5-1] and [6-1] to [8-1] assembly




M9 horn orientation



M10 horn orientation



M3 horn orientation





M4 horn orientation


8. Full Assembly

8.4 Head to body assembly

8-4-1. [7-1] to [8-1] assembly



9. Covers




Part Number	Part Description	Quantity
19	Camera	1
21	Head LED Cover	1
26	Fan	2
27	Back Cover PCB	1
29	Speaker	1
33	Arm Cover Upper	2
34	Arm Cover Lower	2
35	Thigh Cover	2
36	Leg Cover	2
37B	Back Head Cover	1
37F	Front Head Cover	1
38B	Back Chest Cover	1
38F	Front Chest Cover	1
39L	Left Foot Cover	1
39R	Right Foot Cover	1
40L	Left Eye Cover	1
40R	Right Eye Cover	1
41L	Left Pupil	1
41R	Right Pupil	1
S1	M1.4x4	6
S2	Button Head M2x4	2
S3	Phillips Head M2x4	16
S5	Phillips Head M2x6	20
S6	Phillips Head M2.5x4	4
S7	Phillips Head M2.5x6	4
S9	Phillips Head M3x6	8


9. Covers

9-1. Head covers



9-1-1. Head led cover to front head cover



9-1-3 Camera to front head cover




9-1-2. Eyes assembly





9. Covers

9-1. Head covers


9-1-4. Front head cover location on head



9-1-5. Front head cover to back head cover assembly




Section View





9. Covers

9-2. Chest covers

9-2-1. Back cover PCB to back chest cover




9-2-2. Fans to back cover assembly




9. Covers

9-2. Chest covers

9-2-3. Speaker to front cover




9-2-4. 9-2-2 and 9-2-3 to 8-4 assembly



9. Covers


9-3. Thigh and foot covers

9-3-1. Thigh covers and foot covers assembly



9-4. Shin covers



9-4-1 Shin covers assembly



9. Covers

9-5. Arm covers

9-5-1. Arm covers assembly



RoMeLa

ROBOTICS & MECHANISMS LABORATORY

