Using your Thermostat

Set your room to the temperature you prefer in just a few taps. The wall-mounted thermostat controls both heating and cooling.

If the display appears blank, it has simply gone to sleep to save energy — a single tap will bring it back. The four steps on this card cover everything you need to know.

POWER	WAKE	ADJUST	MENUS
Lower-right button	Center "OK" key	Up / Down arrows	Left / Right zones

01 Make sure it's powered on.

Make sure the power button on the front of the thermostat is glowing. If it is dark, tap the power button once and watch for the light to come on.

● POWER BUTTON LIT SINGLE TAP IF DARK



02 Wake the screen with the "OK" key.

The display dims after a short period of inactivity. Tap the **OK** button in the center of the keypad once. The screen will brighten and show the current room temperature and the set point.

TAP ONCE CENTER KEY



03 Set your temperature with ▲ and ▼.

Use the **up arrow** to raise the target temperature and the **down arrow** to lower it. Each press changes the set point by one degree. The room will adjust automatically.

▲ WARMER ▼ COOLER



04 Switch menus with the left and right zones.

Tap the left or right side of the screen to move between menus — for fan speed and mode (heat / cool / auto)

◀ PREVIOUS MENU NEXT MENU ▶



Need a hand? Dial 0 from your room phone and a member of our team will be happy to assist with temperature, ventilation, or any other in-room comfort settings.