(3) Install brake lines to the HCU and tighten to 19 N·m (170 in. lbs.).

(4) Install wiring harness connector to the CAB and push down on the release to secure the connector.

(5) Install negative battery cable to the battery.

(6) Bleed ABS brake system (Refer to 5 - BRAKES - STANDARD PROCEDURE).