ENGINE SYSTEMS

TABLE OF CONTENTS

page

BATTERY SYSTEM 1
CHARGING 22
STARTING 32

BATTERY SYSTEM

TABLE OF CONTENTS

page

BATTERY SYSTEM
DESCRIPTION 1
OPERATION 2
DIAGNOSIS AND TESTING - BATTERY SYSTEM 2
CLEANING 5
INSPECTION 6
SPECIFICATIONS
BATTERY SYSTEM SPECIFICATIONS 6
TORQUE 7
SPECIAL TOOLS
BATTERY SYSTEM SPECIAL TOOLS 8
BATTERY
DESCRIPTION 8
OPERATION 8
DIAGNOSIS AND TESTING - BATTERY 9
STANDARD PROCEDURE
STANDARD PROCEDURE - BATTERY CHARGING 9
STANDARD PROCEDURE - BUILT-IN INDICATOR TEST 11
STANDARD PROCEDURE - OPEN-CIRCUIT VOLTAGE TEST 12
STANDARD PROCEDURE - IGNITION-OFF DRAW TEST 12
STANDARD PROCEDURE - USING MICRO 420 BATTERY TESTER 13
REMOVAL 14
INSTALLATION 15
BATTERY HOLDDOWN
DESCRIPTION 15
OPERATION 16
REMOVAL 16
INSTALLATION 16
BATTERY CABLES
DESCRIPTION 17
OPERATION 17
DIAGNOSIS AND TESTING - BATTERY CABLES 17
REMOVAL 19
INSTALLATION 19
BATTERY TRAY
DESCRIPTION 20
OPERATION 20
REMOVAL 20
INSTALLATION 20

BATTERY SYSTEM

DESCRIPTION

A single 12-volt battery is standard factory-installed equipment on this model. All of the components of the battery system are located within the engine compartment of the vehicle. The battery system for this vehicle covers the following related components, which are covered in further detail later in this section of the service manual:

- **Battery** - The storage battery provides a reliable means of storing a renewable source of electrical energy within the vehicle.
- **Battery Cable** - The battery cables connect the battery terminal posts to the vehicle electrical system.
- **Battery Holddown** - The battery holddown hardware secures the battery in the battery tray in the engine compartment.
- **Battery Tray** - The battery tray provides a secure mounting location in the vehicle for the battery and an anchor point for the battery holddown hardware.

For battery system maintenance schedules and jump starting procedures, see the owner's manual in the vehicle glove box. Optionally, refer to the Lubrication and Maintenance section of this manual for the recommended battery maintenance schedules and