(2) Tighten screw to 1.2 N·m (10 in. lbs.) torque.
(3) Connect vacuum line to reservoir.
(4) Install battery and battery tray. Refer to Battery Removal/Installation.