WIPERS / WASHERS

TABLE OF CONTENTS

	page		page
FRONT WIPERS/WASHERS	**1**	**REAR WIPERS/WASHERS**	**26**

FRONT WIPERS / WASHERS

TABLE OF CONTENTS

page

FRONT WIPERS/WASHERS
- DESCRIPTION . . . 2
- OPERATION . . . 3
- DIAGNOSIS AND TESTING - FRONT WIPER & WASHER SYSTEM . . . 5
- CLEANING - FRONT WIPER & WASHER SYSTEM . . . 7
- INSPECTION - FRONT WIPER & WASHER SYSTEM . . . 7
- SPECIFICATIONS
  - FRONT WIPER & WASHER SYSTEM . . . 9

FRONT CHECK VALVE
- DESCRIPTION . . . 9
- OPERATION . . . 9
- REMOVAL . . . 10
- INSTALLATION . . . 10

FRONT WASHER HOSES/TUBES
- DESCRIPTION . . . 11
- OPERATION . . . 12

FRONT WASHER NOZZLE
- DESCRIPTION . . . 12
- OPERATION . . . 12
- REMOVAL . . . 12
- INSTALLATION . . . 12

FRONT WASHER PUMP MOTOR
- DESCRIPTION . . . 13
- OPERATION . . . 13
- REMOVAL . . . 13
- INSTALLATION . . . 14

page

FRONT WIPER ARM
- DESCRIPTION . . . 14
- OPERATION . . . 14
- REMOVAL . . . 15
- INSTALLATION . . . 15

FRONT WIPER BLADE
- DESCRIPTION . . . 16
- OPERATION . . . 16
- REMOVAL . . . 16
- INSTALLATION . . . 16

FRONT WIPER MODULE
- DESCRIPTION . . . 17
- OPERATION . . . 17
- REMOVAL . . . 18
- DISASSEMBLY . . . 18
- ASSEMBLY . . . 18
- INSTALLATION . . . 18

RIGHT MULTI-FUNCTION SWITCH
- DESCRIPTION . . . 20
- OPERATION . . . 20
- DIAGNOSIS AND TESTING - RIGHT MULTI-FUNCTION SWITCH . . . 21
- REMOVAL . . . 22
- INSTALLATION . . . 23

WASHER RESERVOIR
- DESCRIPTION . . . 24
- OPERATION . . . 24
- REMOVAL . . . 24
- INSTALLATION . . . 25