A/C COMPRESSOR CLUTCH RELAY

CAVITY	CIRCUIT	FUNCTION
A6	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A7	-	-
A8	C13 18LB/OR	A/C CLUTCH RELAY CONTROL
A9	C3 20DB/YL	A/C CLUTCH RELAY OUTPUT
A10	A926 20RD	FUSED B(+)

ANTILOCK BRAKE RELAY

CAVITY	CIRCUIT	FUNCTION
B6	G4 20VT/LB	ABS WARNING INDICATOR DRIVER
B7	-	-
B8	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN)
B9	Z901 18BK	GROUND
B10	G83 18VT/WT	ABS RELAY CONTROL

AUTOMATIC SHUT DOWN RELAY

CAVITY	CIRCUIT	FUNCTION
A11	K342 18BR/WT	ASD RELAY CONTROL
A12	-	-
A13	F1 20PK/WT ▼▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F1 20PK/WT ▼▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A13	F22 20PK/TN ▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A14	K334 18BR	ASD RELAY OUTPUT
A15	A209 18RD/YL	FUSED B(+)

▼▼▼ FED ABS
▼▼▼▼ EXCEPT FED ABS