ENGINE STARTER MOTOR RELAY

CAVITY	CIRCUIT	FUNCTION
B1	A8 14RD	FUSED B(+)
B2	T750 14YL/GY	ENGINE STARTER MOTOR RELAY OUTPUT
B3	T752 20DG/OR	STARTER MOTOR RELAY CONTROL
B4	-	-
B5	F26 16PK/OR	IGNITION SWITCH OUTPUT (START)

FOG LAMP RELAY

CAVITY	CIRCUIT	FUNCTION
B16	L139 18WT/YL	FOG LAMP SWITCH SIGNAL
B17	-	-
B18	L340 14WT/OR △	HIGH BEAM INDICATOR DRIVER
B18	L300 14LG/WT	DIMMER SWITCH HIGH BEAM OUTPUT
B19	L39 16WT/OR	FOG LAMP RELAY OUTPUT
B20	Z901 18BK	GROUND

FRONT LOCKER RELAY (OFF-ROAD PACKAGE)

CAVITY	CIRCUIT	FUNCTION
D10	INTERNAL	FUSED B(+)
D11	G304 20VT/DB	FRONT LOCKER REQUEST
D12	-	-
D13	INTERNAL	FUSED B(+)
D14	A750 18TN/RD	FRONT LOCKER RELAY OUTPUT

△ DRL