FUEL PUMP RELAY

CAVITY	CIRCUIT	FUNCTION
C6	F1 20PK/WT ▼▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F1 20PK/WT ▼▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C6	F22 20PK/TN ▼▼▼	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C7	-	-
C8	K31 18BR	FUEL PUMP RELAY CONTROL
C9	A109 18OR/RD	FUEL PUMP RELAY OUTPUT
C10	A930 18RD ▼▼▼▼	FUSED B(+)
C10	A930 18RD/BK ▼▼▼	FUSED B(+)

HIGH SPEED RADIATOR FAN RELAY (2.4L)

CAVITY	CIRCUIT	FUNCTION
D10	A16 12GY	FUSED B(+)
D11	N24 12DG/DB	HIGH SPEED RADIATOR FAN RELAY CONTROL
D13	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D14	N201 18DB/LG	HIGH SPEED RADIATOR RELAY OUTPUT

HORN RELAY

CAVITY	CIRCUIT	FUNCTION
C11	A43 18RD/DG	FUSED B(+)
C12	-	-
C13	X3 20RD/YL	HORN RELAY CONTROL
C14	X2 18DG/OR	HORN RELAY OUTPUT
C15	A43 18RD/DG	FUSED B(+)

LOW SPEED RADIATOR FAN RELAY (2.4L)

CAVITY	CIRCUIT	FUNCTION
D2	A16 12GY	FUSED B(+)
D4	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D6	N112 18DB/OR	LOW SPEED RADIATOR FAN RELAY CONTROL
D8	N23 12DB/DG	LOW SPEED FAN RELAY OUTPUT

▼▼▼ FED ABS
▼▼▼▼ EXCEPT FED ABS