Component	Page
Left Front Park/ Turn Signal Lamp	8W-80-35
Left Front Position Lamp (Export)	8W-80-35
Left Front Speaker	8W-80-35
Left Front Turn Signal Lamp (Export)	8W-80-35
Left Front Wheel Speed Sensor	8W-80-36
Left Headlamp	8W-80-36
Left Headlamp Leveling Motor (Export)	8W-80-36
Left License Lamp	8W-80-36
Left Rear Lamp Assembly	8W-80-37
Left Rear Speaker	8W-80-37
Left Rear Wheel Speed Sensor	8W-80-37
Left Side Marker Lamp (Except Export)	8W-80-37
Left Side Repeater Lamp (Export)	8W-80-38
Left Speed Control Switch	8W-80-38
Manifold Absolute Pressure Sensor	8W-80-38
Multi-Function Switch C1	8W-80-39
Multi-Function Switch C2	8W-80-39
Natural Vacuum Leak Detection Assembly	8W-80-39
Output Speed Sensor (A/T)	8W-80-40
Oxygen Sensor 1/1 Upstream (2.4L)	8W-80-40
Oxygen Sensor 1/1 Upstream (4.0L)	8W-80-40
Oxygen Sensor 1/2 Downstream	8W-80-41
Oxygen Sensor 2/1 Upstream (4.0L)	8W-80-41
Oxygen Sensor 2/2 Downstream (4.0L)	8W-80-41
Passenger Airbag On-Off Switch (LHD)	8W-80-41
Passenger Airbag Squib 1	8W-80-42
Passenger Door Ajar Switch	8W-80-42
Power Outlet	8W-80-42
Power Steering Pressure Switch (2.4L)	8W-80-42
Powertrain Control Module C1	8W-80-43
Powertrain Control Module C2	8W-80-44
Powertrain Control Module C3	8W-80-46
Powertrain Control Module C4	8W-80-47
Radiator Fan Motor (2.4L)	8W-80-48
Radiator Fan Motor Circuit Breaker (2.4L)	8W-80-48
Radio C1	8W-80-48
Radio C2 (Satellite Radio)	8W-80-49
Rear Fog Lamp (Export)	8W-80-49
Rear Locker Indicator Switch (Off-Road Package)	8W-80-49
Rear Locker Pump (Off-Road Package)	8W-80-49
Rear Washer Pump (Hard Top)	8W-80-50
Rear Window Defogger Switch (Hard Top)	8W-80-50
Rear Wiper Motor (Hard Top)	8W-80-50
Rear Wiper/washer Switch (Hard Top)	8W-80-50
Receiver-Satellite C1	8W-80-51
Receiver-Satellite C2	8W-80-51
Right Courtesy Lamp	8W-80-51
Right Dome Lamp	8W-80-51
Right Fog Lamp (Except Export)	8W-80-52
Right Front Park/ Turn Signal Lamp (Except Export)	8W-80-52
Right Front Position Lamp (Export)	8W-80-52
Right Front Speaker	8W-80-52
Right Front Turn Signal Lamp (Export)	8W-80-53
Right Front Wheel Speed Sensor	8W-80-53
Right Headlamp	8W-80-53
Right Headlamp Leveling Motor (Export)	8W-80-53
Right License Lamp	8W-80-54
Right Rear Lamp Assembly	8W-80-54
Right Rear Speaker	8W-80-54
Right Rear Wheel Speed Sensor	8W-80-54
Right Side Marker Lamp (Except Export)	8W-80-55
Right Side Repeater Lamp (Export)	8W-80-55
Right Speed Control Switch	8W-80-55
Satellite Antenna	8W-80-55
Seat Belt Switch (Except LHD Export)	8W-80-56
Sentry Key Immobilizer Module	8W-80-56
Speed Control Servo	8W-80-56
Subwoofer	8W-80-56
Throttle Position Sensor (2.4L)	8W-80-57
Throttle Position Sensor (4.0L)	8W-80-57
Torque Converter Clutch Solenoid	8W-80-57
Tow/Haul Overdrive Off Switch	8W-80-57
Transfer Case Switch (Except Off-Road Package)	8W-80-58
Transfer Case Switch (Off-Road Package)	8W-80-58
Transmission Range Indicator Illumination (PRNDL)	8W-80-58
Transmission Range Sensor	8W-80-58
Transmission Solenoid/Pressure Switch Assembly	8W-80-59
Underhood Lamp	8W-80-59
Vehicle Speed Sensor	8W-80-59