


Fig. 30 STEERING COLUMN CONNECTIONS




Fig. 31 STEERING WHEEL CONNECTIONS