FRAME & BUMPERS

TABLE OF CONTENTS

page

FRAME & BUMPERS
SPECIFICATIONS
TORQUE SPECIFICATIONS 1
FRONT EXTENSION
REMOVAL 2
INSTALLATION 2
FRONT BUMPER
REMOVAL 2
INSTALLATION 2
REAR EXTENSION
REMOVAL 2
INSTALLATION 3
REAR BUMPER
REMOVAL 3
INSTALLATION 3
FRAME
STANDARD PROCEDURE - FRAME SERVICE . . 3

page

SPECIFICATIONS
FRAME DIMENSIONS 4
TRANSFER CASE SKID PLATE
REMOVAL 10
INSTALLATION 10
FUEL TANK SKID PLATE
REMOVAL 10
INSTALLATION 11
FRONT TOW HOOK
REMOVAL 11
INSTALLATION 11
REAR TOW HOOK
REMOVAL 11
INSTALLATION 11
TRANSMISSION SKID PLATE
REMOVAL 12
INSTALLATION 12

FRAME & BUMPERS

SPECIFICATIONS

TORQUE SPECIFICATIONS

TORQUE SPECIFICATIONS

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.
FRONT BUMPER SCREW	108	80	—
FRONT TOW HOOK BOLT	108	80	—
FUEL TANK SKID PLATE NUTS	16	12	141
FUEL TANK STRAP NUTS	5	—	40
MAIN FLOOR TO HOLD DOWN BOLT	68	50	—
RADIATOR TO FRAME HOLD DOWN BOLT	60	45	—
REAR BUMPER BOLT	77	57	—
REAR FLOOR TO FRAME BOLT	47	35	—
REAR TOE HOOK BOLT	77	57	—
TRANSFER CASE SKID PLATE BOLTS	45	33	—
TRANSMISSION MOUNT NUTS	35	26	—
TRANSMISSION SKID PLATE TO FRAME BOLTS	45	33	—
TRANSMISSION SKID PLATE TO TRANSFER CASE SKID PLATE BOLTS	28	21	—