SPECIAL TOOLS

FUEL SYSTEM



REMOVER/INSTALLER, LOCKRING - #9340



TEST KIT, FUEL PRESSURE - #5069



ADAPTERS, FUEL PRESSURE TEST - #6539 AND/OR #6631

REMOVER/INSTALLER, OXYGEN SENSOR - #C-4907

FUEL PRESSURE REGULATOR

DESCRIPTION

Refer to Fuel Pump Module for information. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL PUMP MODULE - DESCRIPTION)

FUEL LEVEL SEND UNIT AND SENSOR

DESCRIPTION

Refer to Fuel Pump Module for information. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL PUMP MODULE - DESCRIPTION)

FUEL LINES

DESCRIPTION

Also refer to Quick-Connect Fittings. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/QUICK CONNECT FITTING - STANDARD PROCEDURE)

WARNING: The fuel system is under a constant pressure (even with the engine off). Before servicing any fuel system hoses, fittings or lines, the fuel system pressure must be released. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY - STANDARD PROCEDURE)

The lines/tubes/hoses used on fuel injected vehicles are of a special construction. This is due to the higher fuel pressures and the possibility of contaminated fuel in this system. If it is necessary to replace these lines/tubes/hoses, only those marked EFM/EFI may be used.

If equipped: The hose clamps used to secure rubber hoses on fuel injected vehicles are of a special rolled edge construction. This construction is used to prevent the edge of the clamp from cutting into the hose. Only these rolled edge type clamps may be used in this system. All other types of clamps may cut into the hoses and cause high-pressure fuel leaks.