Use new original equipment type hose clamps.

FUEL PUMP

DESCRIPTION

Refer to Fuel Pump Module for information. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL PUMP MODULE - DESCRIPTION)