

Fig. 29 SINGLE-TAB TYPE FITTING

1 - PULL TAB
2 - QUICK-CONNECT FITTING
3 - PRESS HERE TO REMOVE PULL TAB
4 - INSERTED TUBE END



Fig. 30 DISCONNECTING SINGLE-TAB TYPE FITTING

1 - PULL TAB
2 - SCREWDRIVER
3 - QUICK-CONNECT FITTING



Fig. 31 REMOVING PULL TAB

1 - FUEL TUBE OR FUEL SYSTEM COMPONENT
2 - PULL TAB
3 - QUICK-CONNECT FITTING
4 - FUEL TUBE STOP



Fig. 32 TYPICAL 2–TAB TYPE FITTING

1 - TAB(S)
2 - QUICK-CONNECT FITTING