TRANSFER CASE - NV231

TABLE OF CONTENTS

page

TRANSFER CASE - NV231
- DESCRIPTION 173
- OPERATION 174
- DIAGNOSIS AND TESTING - TRANSFER CASE - NV231 174
- REMOVAL 175
- DISASSEMBLY 175
- CLEANING 183
- INSPECTION 183
- ASSEMBLY 188
- INSTALLATION 199
- SPECIFICATIONS TRANSFER CASE - NV231 199
- SPECIAL TOOLS NV231 200

FLUID
- STANDARD PROCEDURE - FLUID DRAIN AND FILL 202

page

FRONT OUTPUT SHAFT SEAL
- REMOVAL 202
- INSTALLATION 202

REAR OUTPUT SHAFT SEAL
- REMOVAL 203
- INSTALLATION 204

SHIFT LEVER
- REMOVAL 206
- INSTALLATION 207
- ADJUSTMENTS - SHIFT LINKAGE 207

SPEEDOMETER DRIVE ADAPTER
- REMOVAL 208
- INSTALLATION 209

VEHICLE SPEED SENSOR
- DESCRIPTION 209
- OPERATION 210
- REMOVAL 210
- INSTALLATION 210

TRANSFER CASE - NV231

DESCRIPTION

The NV231 is a part-time transfer case with a low range reduction gear system. The NV231 has three operating ranges plus a NEUTRAL position. A low range system provides a reduction ratio for increased low speed torque capability.

The geartrain is mounted in two aluminum case halves attached with bolts. The mainshaft front and rear bearings are mounted in aluminum retainer housings bolted to the case halves.

OPERATING RANGES

Transfer case operating ranges are:

- 2WD (2-wheel drive)
- 4x4 (4-wheel drive)
- 4 Lo (4-wheel drive low range

The 2WD range is for use on any road surface at any time.

The 4x4 and 4 Lo ranges are for off road use only. They are not for use on hard surface roads. The only exception being when the road surface is wet or slippery or covered by ice and snow.

The low range reduction gear system is operative in 4 Lo range only. This range is for extra pulling power in off road situations. Low range reduction ratio is 2.72:1.

SHIFT MECHANISM

Operating ranges are selected with a floor mounted shift lever. The shift lever is connected to the transfer case range lever by an adjustable linkage rod. A straight line shift pattern is used. Range positions are marked on the shifter bezel cover plate.

IDENTIFICATION

A circular ID tag is attached to the rear case of each transfer case (Fig. 1). The ID tag provides the transfer case model number, assembly number, serial number, and low range ratio.

The transfer case serial number also represents the date of build.