INSTALLATION

(1) Install sensor into transfer case rear extension and install mounting bolt. Before tightening bolt, verify speed sensor is fully seated (mounted flush) to rear extension.

(2) Tighten sensor mounting bolt to 11-16 N·m (8-12 ft. lbs.) torque.

(3) Connect electrical connector to sensor.