(2) Rotate window retainer sleeves 90°. Using a trim stick C-4755 or equivalent, pry sleeve retainers from door.

(3) Remove the screws attaching trim panel to door.

(4) Using a trim stick C-4829 or equivalent, remove push-in fasteners attaching trim panel to door.

(5) Separate the trim panel from the door.

INSTALLATION

(1) Position the trim panel on the door.

(2) Press the push-in fasteners attaching trim panel to door into place.

(3) Install the screws attaching trim panel to door.

(4) Position retainer sleeves into door. Rotate retainer sleeves 90° to secure into place.

(5) Install half door window. (Refer to 23 - BODY/ HALF DOOR/WINDOW - INSTALLATION)