(9) Disengage the headlamp wire connector.

(10) Route the fog lamp (if equipped), park lamp and side marker wire harness through the access hole in the fender well.

(11) Remove the bolts attaching the fender to the cowl (Fig. 3).