

Fig. 12 LICENSE PLATE BRACKET

1 - BOLTS (4)
2 - BRACKET



Fig. 13 LICENSE PLATE BRACKET - EXPORT

1 - NUTS (4)
2 - BOLTS (2)
3 - BUMPER
4 - ELECTRICAL CONNECTORS
5 - LICENSE PLATE BRACKET
6 - BOLTS (4)

INSTALLATION

(1) Connect the electrical connectors, if equipped.
(2) Position the bracket on the body.
(3) Install the four screws attaching the license plate bracket to the body.
(4) On export models, install the six bolts and four nuts.
(5) If removed, install the license plate.