INTERIOR

TABLE OF CONTENTS

page

ADD-A-TRUNK
REMOVAL 54
INSTALLATION 55
FRONT CARPET
REMOVAL 55
INSTALLATION 55
CENTER CARPET
REMOVAL 55
INSTALLATION 56
CARGO AREA CARPET
REMOVAL 56
INSTALLATION 56
WHEELHOUSE CARPET
REMOVAL 56
INSTALLATION 56
REAR VIEW MIRROR
REMOVAL 57
INSTALLATION 57
REAR VIEW MIRROR SUPPORT BRACKET
INSTALLATION 57
SUNVISOR
REMOVAL 57
INSTALLATION 58
SHIFT BEZEL - AUTOMATIC TRANSMISSION
REMOVAL 58
INSTALLATION 58
SHIFT BOOT
REMOVAL 58

page

INSTALLATION 59
CENTER CONSOLE
REMOVAL 59
INSTALLATION 60
CENTER CONSOLE CUP HOLDER
REMOVAL 60
INSTALLATION 60
CONSOLE LOCK CYLINDER
REMOVAL 60
INSTALLATION 61
SPORT BAR
REMOVAL 61
INSTALLATION 62
A-PILLAR TRIM
REMOVAL 63
INSTALLATION 63
REAR HEADER TRIM
REMOVAL 63
INSTALLATION 63
WINDSHIELD HEADER
REMOVAL 64
INSTALLATION 64
SPORT BAR - SPEAKER POD
REMOVAL 64
INSTALLATION 64

ADD - A - TRUNK

REMOVAL

(1) Release latches under trunk panel and lift panel up.

(2) Remove bolts attaching trunk to inner body panel (Fig. 1).

(3) Separate trunk from vehicle.



Fig. 1 ADD-A-TRUNK

1 - SCREW
2 - ADD-A-TRUNK PANEL