(15) Featheredge the repaired surface area.
(16) Prime the repaired surface area with PPG® Epoxy Primer, or an equivalent product.
(17) Apply surface primer to the surface area.
(18) Prime the surface area for the color coat.
(19) Apply color coat to the repaired surface area.

HARD TOP FRACTURE REPAIR

If it has been determined that the hard top can be repaired. The following required materials and procedures are to be used.
(1) Use a grinder to remove the paint and outline the damaged area. Use a grade 150 grit disc for paint removal.
(2) Grind the outlined surface area again with a 240 grit disc to prevent coarse scratches from appearing in the final finish.
(3) If cracks extend from the damaged area, it will be necessary to stop drill the cracks with a 3-mm (1/8-in) diameter drill bit. This will prevent the crack and/or fracture from spreading and allow repair material to be effective.
(4) Bevel the edges of the crack/fracture on both sides with a rotary file.

NOTE: The edges should be beveled on the inside and outside of the top to ensure sufficient surface area for good bonding.

(5) Complete the repairs with fiberglass cloth and resin as described in the hard top hole repair procedure. (Refer to 23 - BODY/REMOVABLE TOP - STANDARD PROCEDURE)

HARD TOP SAG REPAIR

Inspect the roof/hard top assembly for the presence of sag, or if the customer complains of water accumulation on the roof. Perform the following procedure to repair.
(1) Disengage latches at windshield frame (Fig. 1).

NOTE: The two forward bolts/nuts are not captured. Do not lose the nuts when removing.

(2) Remove the six bolts that attach the hard top to the body (Fig. 2).
(3) Depress tab on rear wiper motor connector and pull downward to disengage (Fig. 3).
(4) Make two marks on the inside of the hard top 6 cm (2.5 in.) on both sides of the center roof rib, directly above the sport bar.
(5) Move the hard top back about 10 cm (4 in.) to expose the inner rib section.
(6) Clean the roof area with isopropyl alcohol.
(7) Install the foam repair blocks by removing the protective backing tape from the adhesive side. The foam blocks must be centered above the sport bar pad.
(8) Move the hard top assembly back into position and centered at the windshield frame.
(9) Inspect the hard top seals for damage and replace, if necessary.
(10) Inspect the windshield header seal and make sure it is clean, undamaged, and free of debris.
(11) Carefully position the hard top assembly on the vehicle making sure that the latches are not pinched between the windshield frame and top.

CAUTION: Do not over tighten the top bolts. Over tightening can cause cracking of the hardtop assembly.

(12) Loosely install the six bolts. Ensure that the top is centered on the vehicle and locators are in place in the body side slots and tighten the bolts to 17 N·m (150 in. lbs.).
(13) Connect the wire wiper motor harness connector.
(14) Connect the rear washer fluid hose.
(15) Engage the latches at windshield frame and snap the clamps home.

HARD TOP

REMOVAL

(1) Disengage latches at windshield frame (Fig. 1).

NOTE: The two forward bolts/nuts are not captured. Do not lose the nuts when removing.

(2) Remove the six bolts that attach the hard top to the body (Fig. 2).
(3) Depress tab on rear wiper motor connector and pull downward to disengage (Fig. 3).
(4) Disconnect the rear washer fluid hose. Cap the hose to prevent washer fluid leakage (Fig. 4).

CAUTION: Protect the lower edges of the top from potential damage, cracks, paint chips, gouges and scratches that are not covered under warranty.

(5) Carefully remove the hard top assembly from the vehicle.