(2) Install the torx screws attaching the windshield hinge to the windshield frame.
(3) Tilt the windshield rearward.
(4) Install the torx screw closest to the hinge pivot point and lock the windshield in the upright position.
(5) Install the windshield wiper arms. (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER ARMS - INSTALLATION)
(6) Install the bolts attaching the sport bar to the windshield frame.
(7) Latch top.