PLUMBING

TABLE OF CONTENTS

page

PLUMBING
DESCRIPTION 56
OPERATION 57
WARNINGS 57
CAUTIONS 57
DIAGNOSIS AND TESTING
REFRIGERANT SYSTEM LEAKS 58
STANDARD PROCEDURE
REFRIGERANT SYSTEM SERVICE EQUIPMENT 59
REFRIGERANT SYSTEM RECOVERY 60
REFRIGERANT SYSTEM EVACUATE 60
REFRIGERANT SYSTEM CHARGE 61
A/C COMPRESSOR
DESCRIPTION
A/C COMPRESSOR 61
HIGH PRESSURE RELIEF VALVE 61
OPERATION
A/C COMPRESSOR 62
HIGH PRESSURE RELIEF VALVE 62
DIAGNOSIS AND TESTING
A/C COMPRESSOR NOISE 62
REMOVAL
2.4L ENGINE 63
4.0L ENGINE 64
INSTALLATION
2.4L ENGINE 65
4.0L ENGINE 65
A/C CONDENSER
DESCRIPTION 66
OPERATION 66
REMOVAL 66
INSTALLATION 68
A/C DISCHARGE LINE
DESCRIPTION 69
REMOVAL
2.4L ENGINE 69
4.0L ENGINE 70
INSTALLATION
2.4L ENGINE 70
4.0L ENGINE 71
A/C EVAPORATOR
DESCRIPTION 71

page

OPERATION 72
REMOVAL 72
INSTALLATION 72
A/C ORIFICE TUBE
DESCRIPTION 72
OPERATION 73
DIAGNOSIS AND TESTING
A/C ORIFICE TUBE 73
ACCUMULATOR
DESCRIPTION 73
OPERATION 74
REMOVAL 74
INSTALLATION 75
HEATER CORE
DESCRIPTION 75
OPERATION 76
REMOVAL 76
INSTALLATION 76
LIQUID LINE
DESCRIPTION 76
REMOVAL 77
INSTALLATION 78
REFRIGERANT
DESCRIPTION 78
OPERATION 79
REFRIGERANT LINE COUPLER
DESCRIPTION 79
OPERATION 79
REMOVAL 79
INSTALLATION 80
REFRIGERANT OIL
DESCRIPTION 80
OPERATION 80
STANDARD PROCEDURE
REFRIGERANT OIL LEVEL 81
SERVICE PORT VALVE CORE
DESCRIPTION 81
REMOVAL 81
INSTALLATION 82
SUCTION LINE
DESCRIPTION 82
REMOVAL 82
INSTALLATION 83

PLUMBING

DESCRIPTION

The A/C refrigerant lines and hoses are used to carry the refrigerant between the various A/C system components. The refrigerant lines and hoses for the R-134a system on this vehicle consist of a barrier-hose design with a nylon tube sandwiched between rubber layers. The nylon tube helps to contain the R-134a refrigerant, which has a smaller molecular structure than R-12 refrigerant. The ends of the