WARNING: REASSEMBLE ALL COMPONENTS BEFORE ROAD TESTING A VEHICLE. DO NOT TRY TO READ THE DRBIII® SCREEN OR OTHER TEST EQUIPMENT DURING A TEST DRIVE. DO NOT HANG THE DRBIII® OR OTHER TEST EQUIPMENT FROM THE REARVIEW MIRROR DURING A TEST DRIVE. HAVE AN ASSISTANT AVAILABLE TO OPERATE THE DRBIII® OR OTHER TEST EQUIPMENT. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY OR DEATH.

5.0 REQUIRED TOOLS AND EQUIPMENT

- 8310 Airbag System Load Tool
- 8443 Supplemental Restraints System Load Tool
- DRBIII® (diagnostic read-out box)
- jumper wires
- ohmmeter
- test light
- voltmeter

6.0 GLOSSARY OF TERMS

4WD	4-Wheel Drive
ABS	Antilock Braking System
ACM	Airbag Control Module
AECM	Airbag Electronic Control Module
AIRBAG	Also called ″squib″ initiator. Located inside the driver side airbag assembly.
ASDM	Airbag System Diagnostic System
CAB	Controller Antilock Brake
CTMM	Compass Temperature Mirror Module
DAB	Driver AirBag
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
EMIC	Electro/Mechanical Instrument Cluster
LED	Light Emitting Diode
LFW	Low Fuel Warning
MIC	Mechanical Instrument Cluster
MIL	Malfunction Indicator Lamp
NGC	Next Generation Controller
PAB	Passenger AirBag
PCI	Programmable Communication Interface
PCM	Powertrain Control Module
PDC	Power Distribution Center
S.T.A.R.	Service Technical Assistance Resource
SKIM	Sentry Key Immobilizer Module
SKIS	Sentry Key Immobilizer System
SRS	Supplemental Restraints System
TCM	Transmission Control Module
VFD	Vacuum Fluorescent Display