## Symptom:
## DRIVER SQUIB 1 CIRCUIT SHORT

**When Monitored and Set Condition:**

### DRIVER SQUIB 1 CIRCUIT SHORT

When Monitored: With the ignition on, the ACM monitors the resistance of the Driver Squib 1 circuits.

Set Condition: The ACM has detected low resistance on the Driver Squib 1 circuits.

| POSSIBLE CAUSES |
|---|
| DRIVER AIRBAG SQUIB 1 CIRCUIT SHORT |
| CLOCKSPRING, DRIVER SQUIB 1 CIRCUITS SHORT |
| DRIVER AIRBAG SQUIB 1 LINE 1 SHORT TO LINE 2 |
| ACM, DRIVER SQUIB LINE 1 SHORT TO LINE 2 |
| STORED CODE OR INTERMITTENT CONDITION |
| ACTIVE CODE PRESENT |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>**NOTE: Ensure the battery is fully charged.**<br>**NOTE: For the purpose of this test, the AECM and ORC modules will be referred to as an ACM.**<br>SELECT ACTIVE or STORED DTC:<br><br>ACM - ACTIVE DTC<br>Go To 2<br><br>ACM - STORED DTC<br>Go To 6<br><br>**NOTE: When reconnecting airbag system components the Ignition must be turned off and the Battery must be disconnected.** | All |