*NO RESPONSE FROM SATELLITE RADIO RECEIVER — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. Disconnect the Satellite Radio Receiver harness connector. Turn the ignition on. Turn the Radio on and place the radio in the Satellite mode. Using a 12-volt test light connected to ground, probe the Fused Ignition Switch Ouptut circuit. Is the test light illuminated? Yes → Go To 4 No → Replace the Radio in accordance with the service information. Perform BODY VERIFICATION TEST - VER 1.	All
4	Turn the ignition off. Disconnect the Satellite Radio Receiver harness connector. Using a 12-volt test light connected to 12-volts, probe the ground circuit. Is the test light illuminated? Yes → Replace the Satellite Radio Receiver in accordance with the service information Perform BODY VERIFICATION TEST - VER 1. No → Replace the Radio in accordance with the service information. Perform BODY VERIFICATION TEST - VER 1.	All