Symptom List:

P0131-O2 SENSOR 1/1 CIRCUIT LOW VOLTAGE
P0137-O2 SENSOR 1/2 CIRCUIT LOW VOLTAGE
P0151-O2 SENSOR 2/1 CIRCUIT LOW VOLTAGE
P0157-O2 SENSOR 2/2 CIRCUIT LOW VOLTAGE

Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be P0131-O2 SENSOR 1/1 CIRCUIT LOW VOLTAGE.

When Monitored and Set Condition:

P0131-O2 SENSOR 1/1 CIRCUIT LOW VOLTAGE

When Monitored: Engine running for less than 30 seconds and the O2 Sensor Heater Temperature is less than 251°C (484°F) with battery voltage greater 10.4 volts.

Set Condition: The oxygen sensor signal voltage is below 2.411 volts for 10.24 seconds after starting engine. One Trip Fault.

P0137-O2 SENSOR 1/2 CIRCUIT LOW VOLTAGE

When Monitored: Engine running for less than 30 seconds and the O2 Sensor Heater Temperature is less than 251°C (484°F) with battery voltage greater 10.4 volts.

Set Condition: The oxygen sensor signal voltage is below 2.411 volts for 10.24 seconds after starting engine. One Trip Fault.

P0151-O2 SENSOR 2/1 CIRCUIT LOW VOLTAGE

When Monitored: Engine running for less than 30 seconds and the O2 Sensor Heater Temperature is less than 251°C (484°F) with battery voltage greater 10.4 volts.

Set Condition: The oxygen sensor signal voltage is below 2.411 volts for 10.24 seconds after starting engine. One Trip Fault.

P0157-O2 SENSOR 2/2 CIRCUIT LOW VOLTAGE

When Monitored: Engine running for less than 30 seconds and the O2 Sensor Heater Temperature is less than 251°C (484°F) with battery voltage greater 10.4 volts.

Set Condition: The oxygen sensor signal voltage is below 2.411 volts for 10.24 seconds after starting engine. One Trip Fault.

POSSIBLE CAUSES
O2 SENSOR BELOW 2.52 VOLTS
O2 SENSOR
O2 RETURN CIRCUIT SHORTED TO GROUND
PCM